

GENERAL
MIDI

XG

XF

DISK
ORCHESTRA

STYLE
FILE

PORTATONE

PSR- A1000

OWNER'S MANUAL

Before using the PSR-A1000, be sure to read "Precautions," on pages 3-4.



YAMAHA

The serial number of this product may be found on the bottom of the unit. You should note this serial number in the space provided below and retain this manual as a permanent record of your purchase to aid identification in the event of theft.

Model No.

Serial No.

(bottom)

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

* Please keep this manual in a safe place for future reference.



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (PA-300 or an equivalent recommended by Yamaha) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.
- Do not place the AC adaptor cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.

Do not open

- Do not open the instrument or attempt to disassemble the internal parts or modify them in any way. The instrument contains no user-serviceable parts. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

Water warning

- Do not expose the instrument to rain, use it near water or in damp or wet conditions, or place containers on it containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.

Fire warning

- Do not put burning items, such as candles, on the unit. A burning item may fall over and cause a fire.

If you notice any abnormality

- If the AC adaptor cord or plug becomes frayed or damaged, or if there is a sudden loss of sound during use of the instrument, or if any unusual smells or smoke should appear to be caused by it, immediately turn off the power switch, disconnect the adaptor plug from the outlet, and have the instrument inspected by qualified Yamaha service personnel.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord.
- Unplug the AC power adaptor when not using the instrument, or during electrical storms.
- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.

Location

- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration or damage to the internal components.
- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise.
- Do not place the instrument in an unstable position where it might accidentally fall over.
- Before moving the instrument, remove all connected adaptor and other cables.
- Use only the stand specified for the instrument. When attaching the stand, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

Connections

- Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum. Also, be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

Maintenance

- When cleaning the instrument, use a soft, dry cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling caution

- Do not insert a finger or hand in any gaps on the instrument.
- Never insert or drop paper, metallic, or other objects into the gaps on the panel or keyboard. If this happens, turn off the power immediately and unplug the power cord from the AC outlet. Then have the instrument inspected by qualified Yamaha service personnel.
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors.
- Do not operate the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

Saving data

Saving and backing up your data

- Current memory data (see page 36) is lost when you turn off the power to the instrument. Save the data to a floppy disk/the User Drive (see page 36).
Saved data may be lost due to malfunction or incorrect operation. Save important data to a floppy disk.

When you change settings in a display page and then exit from that page, System Setup data (listed in the Parameter Chart of the separate Data List booklet) is automatically stored. However, this edited data is lost if you turn off the power without properly exiting from the relevant display.

Backing up the floppy disk

- To protect against data loss through media damage, we recommend that you save your important data onto two floppy disks.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

Even when the power switch is in the "STANDBY" position, electricity is still flowing to the instrument at the minimum level. When you are not using the instrument for a long time, make sure you unplug the AC power adaptor from the wall AC outlet.

Thank you for purchasing the Yamaha PSR-A1000!
We recommend that you read this manual carefully
so that you can fully take advantage of the advanced
and convenient functions of the PSR-A1000.
We also recommend that you keep this manual
in a safe and handy place for future reference.

Accessories

- PA-300 AC Adaptor*
- Floppy Disk [includes style files, song files and MIDI Driver (page 138)]
- Music Stand (page 17)
- Data List
- Owner's Manual

* May not be included in your area. Please check with your Yamaha dealer.

About this Owner's Manual and Data List

This manual consists of four main sections: Introduction, Quick Guide, Basic Operation, and Reference. Also, a separate Data List is provided.

Introduction (page 3): Please read this section first.

Quick Guide (page 20): This section explains how to use the basic functions.

Basic Operation (page 35): This section explains how to use the basic operations including display-based controls.

Reference (page 49): This section explains how to make detailed settings for the PSR-A1000's various functions.

Data List : Voice List, MIDI Data Format, etc.

- * The illustrations and LCD screens as shown in this owner's manual are for instructional purposes only, and may appear somewhat different from those on your instrument. For example, the voice or style name appearing in the LCD screens in this manual may differ from that of the actual instrument.
- * The example Operation Guide displays shown in this Manual are in English.

- * The bitmap fonts used in this instrument have been provided by and are the property of Ricoh Co., Ltd.
- * Copying of the commercially available software is strictly prohibited except for your personal use.

COPYRIGHT NOTICE

This product incorporates and bundles computer programs and contents in which Yamaha owns copyrights or with respect to which it has license to use others' copyrights. Such copyrighted materials include, without limitation, all computer software, styles files, MIDI files, WAVE data and sound recordings. Any unauthorized use of such programs and contents outside of personal use is not permitted under relevant laws. Any violation of copyright has legal consequences. DON'T MAKE, DISTRIBUTE OR USE ILLEGAL COPIES.

Trademarks:

- Apple and Macintosh are trademarks of Apple Computer, Inc.
- IBM-PC/AT is a trademark of International Business Machines Corporation.
- Windows is the registered trademark of Microsoft® Corporation.
- All other trademarks are the property of their respective holders.

Handling the Floppy Disk Drive (FDD) and Floppy Disk

Be sure to handle floppy disks and treat the disk drive with care. Follow the important precautions below.

Compatible Disk Type

- 3.5" 2DD and 2HD type floppy disks can be used.


Inserting/Ejecting Floppy Disks

To insert a floppy disk into the disk drive:

- Hold the disk so that the label of the disk is facing upward and the sliding shutter is facing forward, towards the disk slot. Carefully insert the disk into the slot, slowly pushing it all the way in until it clicks into place and the eject button pops out.

Drive lamp

When the power is turned on, the drive lamp (at the bottom left of the drive) lights to indicate the drive can be used.




To eject a floppy disk:

Before ejecting the disk, be sure to confirm that data is not being written to the floppy disk.

If data is currently being written to the floppy disk in the following operations, the messages "Now executing," "Now copying," and "Now formatting" appears in the display.

- Moving, copying, pasting, saving, or deleting data (page 39 - 41).
- Naming files and folders (page 38); creating a new folder (page 41).
- Copying a disk to an another disk (page 134); formatting the disk (page 134).



- Never attempt to remove the disk or turn the power off when the data is being written to the floppy disk. Doing so can damage the disk and possibly the disk drive. Press the eject button slowly as far as it will go; the disk will automatically pop out. When the disk is fully ejected, carefully remove it by hand.
- If the eject button is pressed too quickly, or if it is not pressed in as far as it will go, the disk may not eject properly. The eject button may become stuck in a half-pressed position with the disk extending from the drive slot by only a few millimeters. If this happens, do not attempt to pull out the partially ejected disk, since using force in this situation can damage the disk drive mechanism or the floppy disk. To remove a partially ejected disk, try pressing the eject button once again, or push the disk back into the slot and then repeat the eject procedure.
- Be sure to remove the floppy disk from the disk drive before turning off the power. A floppy disk left in the drive for extended periods can easily pick up dust and dirt that can cause data read and write errors.

Cleaning the Disk Drive Read/Write Head

- Clean the read/write head regularly. This instrument employs a precision magnetic read/write head which, after an extended period of use, will pick up a layer of magnetic particles from the disks used that will eventually cause read and write errors.
- To maintain the disk drive in optimum working order Yamaha recommends that you use a commercially-available dry-type head cleaning disk to clean the head about once a month. Ask your Yamaha dealer about the availability of proper head-cleaning disks.
- Never insert anything but floppy disks into the disk drive. Other objects may cause damage to the disk drive or floppy disks.


About the Floppy Disks

To handle floppy disks with care:

- Do not place heavy objects on a disk or bend or apply pressure to the disk in any way. Always keep floppy disks in their protective cases when they are not in use.
- Do not expose the disk to direct sunlight, extremely high or low temperatures, or excessive humidity, dust or liquids.
- Do not open the sliding shutter and touch the exposed surface of the floppy disk inside.
- Do not expose the disk to magnetic fields, such as those produced by televisions, speakers, motors, etc., since magnetic fields can partially or completely erase data on the disk, rendering it unreadable.
- Never use a floppy disk with a deformed shutter or housing.
- Do not attach anything other than the provided labels to a floppy disk. Also make sure that labels are attached in the proper location.

To protect your data (Write-protect Tab):

- To prevent accidental erasure of important data, slide the disk's write-protect tab to the "protect" position (tab open).




Data backup

- For maximum data security Yamaha recommends that you keep two copies of important data on separate floppy disks. This gives you a backup if one disk is lost or damaged. To make a backup disk use the Disk to Disk function on page 134.

About the Display Messages

A message (information or confirmation dialog) sometimes appears on the screen to facilitate operation. When such messages appear, simply follow the instructions as shown by pressing the corresponding button.



NOTE

You can select the desired language from the Help display (page 46).

For this example, press the [G] (YES) button to execute formatting.

Table of Contents

Introduction 3

PRECAUTIONS	3
Accessories	6
About this Owner's Manual and Data List	6
Handling the Floppy Disk Drive (FDD) and Floppy Disk.....	7
About the Display Messages.....	8
Application Index.....	12
What can you do with the PSR-A1000?	14
Setting Up the PSR-A1000	16
Panel Controls and Terminals.....	18

Quick Guide 20

Playing the Demos.....	20
Song Playback	21
Playback of Songs	21
Playing Voices	25
Playing a Voice	25
Playing Two Voices Simultaneously	26
Playing Different Voices with the Left and Right Hands.....	27
Playing Styles	28
Playing a style.....	28
Style Sections.....	30
Playing with the Songs	32
Playing Along with the PSR-A1000.....	32
Recording	33
Setting an Oriental Scale	34

Basic Operations

— Organizing Your Data 35

Example — Open/Save display for Voice.....	36
Selecting Files and Folders.....	37
File/Folder-related Operations	38
Naming Files/Folders	38
Moving Files/Folders	39
Copying Files/Folders.....	40
Deleting Files/Folders.....	40
Saving Files	41
Organizing Files by Creating a New Folder	41
Displaying Upper Level pages	41
Entering Characters and Changing Icons	41
Using the [DATA ENTRY] Dial	43
Direct Access — Instant Selection of Displays.....	44
Help Messages	46
Using the Metronome.....	47
Adjusting the Tempo	47
Tap Tempo	48

Reference

Playing the Demos.....49

Voices.....51

Selecting a Voice	51
Layer/Left — Playing Several Sounds	
Simultaneously	53
Layer — Layering Two Different Voices	53
Left — Setting Separate Voices for the Left and Right Sections of the Keyboard	54
Applying Voice Effects	54
PITCH BEND Wheel.....	55
Adjusting the Octave setting	55

Styles.....56

Playing a style	56
Playing a Style's Rhythm Channels only	58
Adjusting the Volume Balance/Channel Muting	58
Chord Fingerings.....	59
Arranging the Style Pattern (SECTIONS: MAIN A/ B/C/D, INTRO, ENDING, BREAK).....	61
Stopping the Style Playback While Releasing Keys (SYNC. STOP)	62
Selecting Intro and Ending Types (INTRO/ENDING)	63
Playing Fill-in patterns automatically when changing accompaniment sections — Auto Fill In.....	63

The Multi Pads64

Playing the Multi Pads	64
Chord Match	64
Multi Pad Edit.....	65

Song Playback.....66

Compatible Song Types.....	66
Song Playback	67
Playing the Internal Songs.....	67
Playing Back Songs on Disk.....	69
Other Playback-related Operations.....	69
Muting Specific Parts	
— Track1/Track2/Extra Tracks.....	70
Repeat Playback of a Specific Range	70
Displaying the Lyrics	71

Using Oriental Scales – Scale Setting/Scale Tuning/ Scale Memory 72

Setting an Oriental Scale — Scale Setting.....	72
Adjusting the Scale Tuning — Scale Tuning	72
Memorizing the Scale Setting – Scale Memory	74
Saving Your Scale Settings	74
Recalling the Scale Setting	75

Saving and Recalling Custom Panel Setups — Registration Memory 76

Registering Panel Setups	
— Registration Memory.....	76
Saving Your Registration Memory Setups.....	77
Recalling a Registration Memory Setup.....	78

Editing Voices — Sound Creator 79

Operation	79
Sound Creator Parameters	80

Recording Your Performances and Creating Songs — Song Creator 83

About Song Recording.....	83
Quick Recording.....	84
Multi Recording	85
Recording Individual Notes — Step Record	87
Operation	87
Recording Melodies — Step Record (Note).....	89
Recording Chord Changes for the Auto Accompaniment — Step Record (Chord).....	90
Select the Recording Options: Starting, Stopping, Punching In/Out — Rec Mode.....	92
Editing a Recorded Song	93
Editing Channel-related Parameters — Channel.....	93
Editing Note Events — 1 - 16.....	96
Editing Chord Events — CHD.....	97
Editing System Events — SYS/EX. (System Exclusive) ..	97
Inputting and Editing Lyrics	98
Customizing the Event List — Filter.....	98

Creating Accompaniment Styles — Style Creator 99

About Creating Accompaniment Styles	99
Style File Format	100
Operation	100
Realtime Recording — Basic	101

Step Recording.....	102
Assembling an Accompaniment Style — Assembly	103
Edit the Created Accompaniment Style	104
Change the Rhythmic Feel — Groove and Dynamics	104
Editing the Channel Data	106
Making Style File Format Settings —Parameter	107

Creating Multi Pad — Multi Pad Creator 109

Operation	109
Multi Pad Realtime Recording — Record	110
Start recording.....	110
Stop recording.....	110
Step Recording or Editing Multi Pads — Edit.....	111

Adjust the Volume Balance and Changing Voices — Mixing Console 112

Operation	112
Setting the Level Balance and Voice — Volume/Voice	113
Changing the Tone of the Voice — Filter.....	114
Changing Pitch-related Settings — Tune	114
Adjusting the Effects	115
Effect Structure	117

Making Global and Other Important Settings — Function 118

Operation	118
Fine Tuning the Pitch — Master Tune.....	120
Tuning the Overall Pitch — Master Tune.....	120
Setting Song-related Parameters — Song Settings.....	121
Setting Auto Accompaniment-related Parameters — Style Setting, Split Point, and Chord Fingering	122
Setting Auto Accompaniment-related Parameters — Style Setting and Split Point	122
Setting the Fingering Method — Chord Fingering	123
Making Settings for the Pedals and Keyboard — Controller.....	123
Making Settings for the Pedals	123
Changing the Touch Sensitivity and Transpose — Keyboard/Panel.....	125
Setting the Registration Sequence, Freeze, and Voice Set.....	126
Specifying the Order for Calling Up Registration Memory Presets — Registration Sequence.....	126

Maintaining Panel Settings — Freeze	126
Changing the Automatically Selected Voice Settings — Voice Set.....	127
Setting Harmony and Echo.....	127
Setting the MIDI Parameters.....	129
Making Overall System Settings (Local Control, Clock, etc.) — System.....	129
Transmitting MIDI Data — Transmit	130
Receiving MIDI Data — Receive	131
Setting Root Note Channels — Root	131
Setting Chord Channels — Chord Detect	131
Other Settings — Utility	132
Making Settings for Fade In/Out, Metronome, Parameter Lock, and Tap — CONFIG 1.....	132
Making Settings for the Display and Voice Number Indication — CONFIG 2.....	133
Copying and Formatting Disks — Disk.....	134
Entering Your Name and Language Preference — Owner.....	135
Restoring the Factory-programmed Settings of the PSR-A1000 — System Reset.....	135

Using Your PSR-A1000 with Other Devices..... 136

Using the Headphones (PHONES jack).....	136
Playing the sounds of the PSR-A1000 through an external audio system, and recording the sounds to an external recorder (AUX OUT/OUTPUT jacks)	136
Using the Pedal (footswitch) or Foot Controller (FOOT PEDAL 1/2 jack).....	137
Connecting external MIDI devices (MIDI terminals)	137
Connecting to a Computer (MIDI terminals/TO HOST terminal).....	138
What's MIDI?.....	139
What You Can Do With MIDI.....	142
Data Compatibility.....	142
Disk format.....	142
Sequence Format.....	143
Voice Allocation Format	143

Troubleshooting..... 144

Specifications 146

Index 148

Introduction

Quick Guide

Basic Operations - Organizing Your Data

Playing the Demos

Voices

Styles

The Multi Pad

Song Playback

Using Oriental Scales - Scale Setting/ Scale Tuning/Scale Memory

Saving and Recalling Custom Panel Setups - Registration Memory

Editing Voices - Sound Creator

Recording Your Performances and Creating Songs - Song Creator

Creating Accompaniment Styles - Style Creator

Creating Multi Pad - Multi Pad Creator

Adjust the Volume Balance and Changing Voices - Mixing Console

Making Global and Other Important Settings - Function

Using Your PSR-A1000 with Other Devices

Appendix

Application Index

Use this index to find reference pages that may be helpful for your particular application and situation.

Listening

- Listening to the internal songs page 67
- Listening to disk songs “Playing Back Songs on Disk” on page 69
- Listening to demo songs page 49
- Listening to the demo of the selected voices page 51
- Listening to songs with the special voices of the PSR-A1000 page 113

Playing

- Playing an accompaniment that matches pitch “Transpose Assign” on page 125
- Combining two voices “Layer — Layering Two Different Voices” on page 53
- Playing separate voices with the right and left hands
..... “Left — Setting Separate Voices for the Left and Right Sections of the Keyboard” on page 54

Changing the sound

- Enhancing the sound with touch and other effects “Applying Voice Effects” on page 54
..... “Adjusting the Effects” on page 115
- Adjusting the Level Balance page 113
- Combining two voices “Layer — Layering Two Different Voices” on page 53
- Playing separate voices with the right and left hands
..... “Left — Setting Separate Voices for the Left and Right Sections of the Keyboard” on page 54
- Creating voices page 79

Playing the auto accompaniment

- Playing the accompaniment automatically page 56

Practicing

- Practicing with an accurate and steady tempo “Using the Metronome” on page 47

Recording

- Recording your performance pages 84, 85
- Creating a song by entering notes page 87

Creating your original settings

- Creating voices page 79
- Creating accompaniment styles page 99
- Creating multi pads page 109

Settings

Registering Panel Setups.....	page 76
Tuning the pitch/Selecting a scale	page 120
Making detailed settings for playing back songs	page 121
Making detailed settings for the auto accompaniment.....	page 122
Making detailed settings for the keyboard voices	page 125
Making detailed settings for MIDI	page 129

Connecting the PSR-A1000 to other devices

Basic information on MIDI.....	“What’s MIDI?” on page 139
Recording your performance.....	“Playing the sounds of the PSR-A1000 through an external audio system, and recording the sounds to an external recorder (AUX OUT/OUTPUT jacks)” on page 136
Raising the volume	“Playing the sounds of the PSR-A1000 through an external audio system, and recording the sounds to an external recorder (AUX OUT/OUTPUT jacks)” on page 136
Connecting a computer.....	“Connecting to a Computer (MIDI terminals/TO HOST terminals)” on page 138

Quick solution

Basic functions of the PSR-A1000 and how you can best use it.....	pages 12, 14
Resetting the PSR-A1000 to the default setting	“Restoring the Factory-programmed Settings of the PSR-A1000 — System Reset” on page 135
Displaying the Messages	“About the Display Messages” on page 8
Troubleshooting	page 144

What can you do with the PSR-A1000?

SONG

Playback previously recorded songs (page 21, 32, 66)

Enjoy a wide variety of preset songs as well as songs on commercially available disks.


SCALE SETTING/ SCALE MEMORY

The Scale Setting feature lets you easily lower the pitches of specific notes by 50 cents to create your own oriental scales. Up to six scale settings can be stored for instant recall (Scale Memory), whenever you need them.

DEMO

Explore the Demos (page 20, 49)

These not only showcase the stunning voices and styles of the instrument, they introduce you to the various functions and features — and give you hands-on experience using the PSR-A1000!



STYLE

Back up your performance with Auto Accompaniment (page 28, 56)

Playing a chord with your left hand automatically plays the auto accompaniment backing. Select an accompaniment style — such as pop, jazz, Latin, etc. — and let the PSR-A1000 be your backing band!

DIGITAL RECORDING

Record your performances (page 83, 99)

With the powerful and easy-to-use song recording features, you can record your own keyboard performances, and create your own complete, fully orchestrated compositions — which you can then save to the USER drive or a floppy disk for future recall.

LCD

The large LCD (together with the various panel buttons) provides comprehensive and easy-to-understand control of the PSR-A1000's operations.


SCALE TUNING

You can select a desired scale template including oriental scales and create your own scales by fine tuning the scale notes.

VOICE

Enjoy a huge variety of realistic voices (page 25, 51)

The PSR-A1000 features a wealth of exceptionally authentic and dynamic voices — including piano, strings, woodwinds, and more!



TO HOST terminal


Make music with a computer — quickly and easily (page 138)

Dive in and take advantage of the wide world of computer music software. Connections and setup are exceptionally easy, and you can play back your computer recorded parts with different instrument sounds — all from a single PSR-A1000!

Multi Pads

Add spice to your performance with special dynamic phrases (page 64, 109)

By simply pressing one of the Multi Pads, you can play short rhythmic or melodic phrases. You can also create your original Multi Pad phrases by recording them directly from the keyboard.




Setting Up the PSR-A1000

Power Supply

- 1 Make sure that the PSR-A1000's STANDBY/ON switch is at the STANDBY (off) position.
- 2 Connect one end of the AC cable to the PA-300.



- 3 Connect the PA-300's DC plug to the PSR-A1000's DC IN terminal on the instrument's rear panel.



- 4 Connect the other end (normal AC plug) to the nearest electrical outlet.

⚠ WARNING

Do not attempt to use an AC adaptor other than the Yamaha PA-300 or an equivalent recommended by Yamaha. The use of an incompatible adaptor may cause irreparable damage to the PSR-A1000, and may even pose a serious shock hazard! ALWAYS UNPLUG THE AC ADAPTOR FROM THE AC POWER OUTLET WHEN THE PSR-A1000 IS NOT IN USE.

⚠ CAUTION

Never interrupt the power supply (e.g. unplug the AC adaptor) during any PSR-A1000 record operation! Doing so can result in a loss of data.


⚠ CAUTION

Even when the switch is in the "STANDBY" position, electricity is still flowing to the instrument at a minimum level. When not using the PSR-A1000 for an extended period of time, be sure to unplug the AC power adaptor from the wall AC outlet.

Power-on Procedure

When you have made all the necessary connections (page 136) between your PSR-A1000 and any other devices, make sure that all volume settings are turned down all the way to zero. Then turn on every device in your setup in the order of MIDI masters (senders), MIDI slaves (receivers), then the audio equipment (mixers, amplifiers, speakers, etc.). This ensures smooth MIDI operation and prevents speaker damage.

When powering down the setup, first turn down the volume for each audio device, then switch off each device in the reverse order (first audio devices, then MIDI).



Powering Up

⚠ CAUTION

In order to avoid possible damage to the speakers or other connected electronic equipment, always switch on the power of the PSR-A1000 before switching on the power of the amplified speakers or mixer and amplifier. Likewise, always switch off the power of the PSR-A1000 after switching off the power of the amplified speakers or mixer and amplifier.


⚠ CAUTION

Even when the switch is in the "STANDBY" position, electricity is still flowing to the instrument at a minimum level. When not using the PSR-A1000 for an extended period of time, be sure to unplug the AC power adaptor from the wall AC outlet.

NOTE

Before you switch your PSR-A1000 on or off, first turn down the volume of any connected audio equipment.

- 1 Press the [STANDBY/ON] switch.
→ The main display appears in the display.




When you're ready to turn off the power, press the [STANDBY/ON] switch again.

→ Both the display and the drive lamp (at the bottom left of the drive) will turn off.


- 2 Adjusting the display contrast
If the LCD is difficult to read, adjust the contrast with the [LCD CONTRAST] knob on the rear panel.



- 3 Setting the volume
Use the [MASTER VOLUME] dial to adjust the volume to an appropriate level.



Music Stand



The PSR-A1000 is supplied with a music stand that can be attached to the instrument by inserting it into the slot at the rear of the control panel.

The Panel Logos

The logos printed on the PSR-A1000 panel indicate standards/formats it supports and special features it includes.

GM System Level 1

"GM System Level 1" is an addition to the MIDI standard which guarantees that any data conforming to the standard will play accurately on any GM-compatible tone generator or synthesizer from any manufacturer.

XG Format

XG is a new Yamaha MIDI specification which significantly expands and improves on the "GM System Level 1" standard with greater voice handling capacity, expressive control, and effect capability while retaining full compatibility with GM. By using the PSR-A1000 XG voices, it is possible to record XG-compatible song files.

XF Format

The Yamaha XF format enhances the SMF (Standard MIDI File) standard with greater functionality and open-ended expandability for the future. The PSR-A1000 is capable of displaying lyrics when an XF file containing lyric data is played. (SMF is the most common format used for MIDI sequence files. The PSR-A1000 is compatible with SMF Formats 0 and 1, and records "song" data using SMF Format 0.)


Disk Orchestra Collection

The DOC voice allocation format provides data playback compatibility with a wide range of Yamaha instruments and MIDI devices.

Style File Format

The Style File Format (SFF) is Yamaha's original style file format, which uses a unique conversion system to provide high-quality automatic accompaniment based on a wide range of chord types. The PSR-A1000 uses the SFF internally, reads optional SFF style disks, and creates SFF styles using the Style Creator feature.

Panel Controls and Terminals



POWER

- ① [STANDBY/ON] switch P. 17

WHEEL

- ② PITCH BEND P. 55

PHONES

- ③ [PHONES] jack..... P. 136

METRONOME

- ④ [METRONOME] button P. 47

SONG

- ⑤ [EXTRA TRACKS (STYLE)] button P. 70
 ⑥ [TRACK 2 (L)] button P. 70
 ⑦ [TRACK 1 (R)] button P. 70
 ⑧ [REPEAT] button P. 70
 ⑨ [REC] button..... P. 83
 ⑩ [TOP] button..... P. 69
 ⑪ [START / STOP] button P. 67
 ⑫ [REW] button..... P. 69
 ⑬ [FF] button..... P. 69

STYLE

- ⑭ STYLE buttons P. 56

SCALE SETTING

- ⑮ [SCALE SETTING] buttons P. 72

SCALE MEMORY

- ⑯ [MEMORY] button P. 74
 ⑰ [SCALE MEMORY] buttons P. 74

MASTER VOLUME

- ⑱ [MASTER VOLUME] dial..... P. 17

STYLE CONTROL



- ⑲ [ACMP] button P. 57
 ⑳ [BREAK] button P. 61
 ㉑ [INTRO] button P. 31, 63
 ㉒ MAIN [A] button P. 61
 ㉓ MAIN [B] button P. 61
 ㉔ MAIN [C] button P. 61
 ㉕ MAIN [D] button P. 61
 ㉖ [ENDING / rit.] button P. 31, 63
 ㉗ [AUTO FILL IN] button P. 63
 ㉘ [FADE IN / OUT] button P. 62
 ㉙ [SYNC.STOP] button P. 62
 ㉚ [SYNC.START] button P. 57
 ㉛ [START / STOP] button P. 57

DIGITAL STUDIO

- ㉜ [SOUND CREATOR] button P. 79
 ㉝ [DIGITAL RECORDING] button..... P. 83, 99
 ㉞ [MIXING CONSOLE] button P. 112

MENU

- ㉟ [DEMO] button P. 49
 ㊱ [HELP] button P. 46
 ㊲ [FUNCTION] button..... P. 118



DISPLAY CONTROL

- 38 [A] - [J] buttons P. 37
- 39 [DIRECT ACCESS] button P. 44
- 40 [BALANCE] button P. 58
- 41 [CHANNEL ON / OFF] button P. 58, 69
- 42 [1▲▼] - [8▲▼] buttons P. 35 - 42
- 43 [BACK] button P. 37, 43
- 44 [NEXT] button..... P. 37, 43
- 45 VOICE PART ON / OFF [MAIN] button P. 53
- 46 VOICE PART ON / OFF [LAYER] button P. 53
- 47 VOICE PART ON / OFF [LEFT] button..... P. 53
- 48 [ENTER] button P. 43
- 49 [DATA ENTRY] dial P. 43
- 50 [EXIT] button P. 37
- 51 [LCD CONTRAST] knob P. 17

VOICE EFFECT

- 52 [LEFT HOLD] button P. 55
- 53 [TOUCH] button P. 54
- 54 [SUSUTAIN] button P. 54
- 55 [HARMONY / ECHO] button P. 55
- 56 [MONO] button P. 55
- 57 [DSP] button..... P. 54
- 58 [VARIATION] button P. 55

VOICE

- 59 VOICE buttons P. 51

TRANSPOSE

- 60 [◀] [▶] buttons P. 125

TEMPO

- 61 [◀] [▶] buttons P. 47
- 62 [TAP TEMPO] button P. 48

UPPER OCTAVE

- 63 [UPPER OCTAVE] button..... P. 55

SCALE TUNING

- 64 [SCALE TUNING] button P. 72

MULTI PAD

- 65 [1] - [4] buttons P. 64
- 66 [STOP] button..... P. 64

REGISTRATION MEMORY

- 67 [FREEZE] button P. 78
- 68 [1] - [8] buttons P. 76
- 69 [MEMORY] button P. 76

FLOPPY DISK

- 70 Floppy disk drive (3.5")..... P. 7

Connectors

- 71 [TO HOST] terminal P. 138
- 72 [HOST SELECT] switch P. 138
- 73 MIDI [OUT] [IN] terminals..... P. 137
- 74 [FOOT PEDAL 1 (SWITCH)] jack..... P. 137
- 75 [FOOT PEDAL 2] jack P. 136
- 76 AUX OUT (LEVEL FIXED) [L] [R] jacks P. 136
- 77 OUTPUT [L / L+R] [R] jacks P. 136
- 78 DC IN terminal P. 136


Quick Guide

Playing the Demos

Reference on page 49

The PSR-A1000 features an extensive variety of Demo songs, that showcase its rich, authentic voices and its dynamic rhythms and styles.

What's more, there's a special selection of Demo functions. These take you through a hands-on journey of all the important features and functions of the instrument — letting you see firsthand how to effectively use the PSR-A1000 in your own music.





1 Press the [DEMO] button automatically plays back the Demo songs at random.




For this example, FUNCTION is selected. Function Demos demonstrate each of the different functions on the PSR-A1000.

2 Press the [BACK]/[NEXT] button to select the Demo categories.




NOTE
Voice Demos showcase the voices of the PSR-A1000. Style Demos introduce you to the rhythms and accompaniment styles of the PSR-A1000 (page 49).

3 Press any of the [A] to [J] buttons or [8▼] (AUTO) button (FUNCTION page only) to select the Demo songs. For this example, press the [8▼] (AUTO) button. All of the function demos are played back in sequence.



NOTE
For details about the Demos, refer to page 49.



Press the [EXIT] button to exit from the demo mode and return to the MAIN display when you've finished playing the demo songs.


When you're done with the Demos, you can get to know your PSR-A1000 even better with these functions:

- Song playback (page 21)
- Short demo playback of the selected voice (in the Voice Open display; page 26).

Song Playback

Reference on page 67

Here's where all of the amazing voices, effects, rhythms, styles and other sophisticated features of the PSR-A1000 come together — in songs!



NOTE
Make sure that the Language setting for the instrument (page 135) is the same as that of the file name of the song that you are playing back.

The following songs are compatible for playback on the PSR-A1000. Refer to pages 66, 142 for more details on the logos.



Disks bearing this logo contain song data for voices defined in the GM standard.



Disks bearing this logo contain song data using the XG format, an extension of the GM standard that provides a wider variety of voices and more comprehensive sonic control.




Disks bearing this logo contain song data for voices defined in Yamaha's DOC format.

NOTE
Songs containing a large amount of data may not be able to be read properly by the instrument, and as such you may not be able to select them. The maximum capacity is about 200–300KB, however this may differ depending on the data contents of each song.

Playback of Songs


► **1** If you want to play back a disk song, insert an appropriate disk containing song data into the disk drive.



CAUTION
• Make sure to read the section "Using the Floppy Disk Drive (FDD) and Floppy Disks" on page 7.

2 Press the [A] button to call up the Song Open display.


If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.



NOTE
From the MAIN display (the display shown when the power is turned on), you can select songs, voices, accompaniment styles, etc.


PRESET (Songs for Demos)

FLOPPY DISK (commercially available songs, your own songs, etc.)




Press the [BACK]/[NEXT] button to select the drive. In the example display at left, the PRESET page is selected; at right, FLOPPY DISK is selected.

3 Press the [A] - [C] button to select the Voice/Style/Function folder.



▶ **4** Press one of the [A] to [J] buttons to select the song file.

▶ **5** Press the SONG [START/STOP] button to start playback.




NOTE

- To rewind or fast forward to the playback point of the song, press the [REW] or [FF] button.
- With song data software (Standard MIDI format 0) that includes lyrics, you can view the lyrics on the display during playback. See page 71 for details.

▶ **6** While the song is playing, try using the Mute function to turn certain instrument channels off or on — letting you craft dynamic arrangements on the fly!

- 1) Press the [CHANNEL ON/OFF] button.
- 2) Press the [1 - 8▲▼] button corresponding to the channel you wish to turn on or off.




If the STYLE tab is selected, press this button again.

Song Playback

- ▶ **7** Finally, take the producer's seat and try your hand at mixing. These Balance controls let you adjust the levels of the individual parts — the song, the style, and your playing.


- 1) Press the [BALANCE] button.
- 2) Press the [1 - 8▲▼] button corresponding to the part of which the volume you wish to adjust.



NOTE

You can call up a full set of mixing controls by pressing the [MIXING CONSOLE] button (page 112).

- ▶ **8** Press the SONG [START/STOP] button to stop playback.




NOTE

- The [FADE IN/OUT] button (page 62) can be used to produce smooth fade-ins and fade-outs when starting and stopping the song, as well as the accompaniment.

Reference on page 51

Playing Voices

The PSR-A1000 features a stunning variety of over 700 dynamic, rich and realistic voices. Try playing some of these voices now and hear what they can do for your music. Here, you'll learn how to select individual voices, combine two voices in a layer, and split two voices between your left and right hands.



Playing a Voice

- ▶ **1** Press the [MAIN] button to turn the MAIN part on, then press the [F] button to call up the menu for selecting MAIN voice.

If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.

Turn MAIN on.

NOTE

The voice you're selecting here belongs to the MAIN part, and is called the MAIN voice. (See page 53 for more information.)

You'll want to hear the MAIN voice all by itself — so make sure that the LAYER and LEFT parts are turned off.


- ▶ **2** Select a voice group.

For this example, STRINGS is selected.

Press the [BACK]/[NEXT] button to select the memory location of the voice. For this example, PRESET is selected.

▶ 3 Select a voice.

For this example, "Strings" is selected.



Press the corresponding buttons to select the other pages — and discover even more voices.

NOTE
• You can instantly jump back to the Main display by “double-clicking” on one of the [A] - [J] buttons.

Press the [8▲] button to start the Demo for the selected voice. To stop the Demo, press this button again. There’s more to the Demo features than just voices, though—for more information, see page 49.

▶ 4 Play the voices.

Naturally, you can play the voice yourself from the keyboard, but you can also have the PSR-A1000 demonstrate the voice for you. Simply press the [8▲] button from the display above, and a Demo of the voice plays automatically.



Playing Two Voices Simultaneously

▶ 1 Press the VOICE PART ON/OFF [LAYER] button to turn the LAYER part on.

▶ 2 Press the [G] button to select the LAYER part.

▶ 3 Select a voice group.



Here, we’ll select a lush pad to fill out the sound. Call up the “CHOIR & PAD” group.

▶ 4 Select a voice.

For example, select “Gothic Vox.”

▶ 5 Play the voices.

Now, you can play two different voices together in a rich sounding layer — the MAIN voice you selected in the previous section, plus the new LAYER voice you’ve selected here.




And that’s just the beginning. Check out these other voice-related features:

- Create your own original voices — quickly and easily — by changing the settings of existing voices (page 79).
- Set up your favorite panel settings — including voices, styles, and more — and call them up whenever you need them (page 76).

Playing Different Voices with the Left and Right Hands


▶ **1** Press the VOICE PART ON/OFF [LEFT] button to turn the LEFT part on.



▶ **2** Press the [H] button to select the LEFT part.


▶ **3** Select a voice group.

Here, we'll select the "STRINGS" group — so that you can play rich, orchestral chords with your left hand.



▶ **4** Select a voice, then press the [EXIT] button to return to the MAIN display.
For example, select "Symphon. Str."


▶ **5** Call up the SPLIT POINT display (page 122). From here, you can set the particular key on the keyboard that separates the two voices — called the Split Point. To do this, simultaneously hold down the [F] or [G] button and press the desired key on the keyboard. (For more information, see page 122.)



▶ **6** Play the voices.

The notes you play with your left hand sound one voice, while the notes you play with your right hand sound a different voice (or voices).

MAIN and LAYER voices are meant to be played with the right hand. The LEFT voice is played with the left hand.




▶ **7** Press the [EXIT] button to return to the MAIN display.



Playing Styles

The PSR-A1000 has a huge variety of musical “styles” that you can call upon to back up your own performance. They give you anything from a simple, yet effective piano backing or percussion accompaniment to a full band or orchestra.



Playing a style

- ▶ **1** Select a style group and a style.


For this example, DANCE & BALLROOM is selected.

For this example, VienneseWaltz is selected.

Press the **[BACK]/[NEXT]** button to select the memory location of the style. For this example, PRESET is selected.

- ▶ **2** Turn ACMP on.

The specified left-hand section of the keyboard becomes the “Auto Accompaniment” area, and chords played in this area are automatically detected and used as a basis for fully automatic accompaniment with the selected style.




NOTE

- The point on the keyboard that separates the auto accompaniment area and the right-hand area of the keyboard is called the “split point.” Refer to page 122 for instructions on setting the split point.

▶ **3** Turn SYNC.START on.



▶ **4** As soon as you play a chord with your left hand, the style starts.
For this example, play a C major chord (as shown below).



▶ **5** Change the tempo by using the TEMPO[◀] [▶] buttons if necessary.

Simultaneously press the TEMPO [◀] [▶] buttons to return the tempo to its original setting. Press the [EXIT] button to leave the TEMPO display.

NOTE

The Tempo can also be adjusted by using the [TAP TEMPO] button (page 48).

▶ **6** Try playing other chords with your left hand.

For information on how to enter chords, see “Chord Fingerings” on page 59.

▶ **7** Press the STYLE [START/STOP] button to stop the style.


And there’s much more. Check out these other style-related features:

- Easily create your own original styles (page 79).
- Set up your favorite panel settings — including styles, voices, and more — and call them up whenever you need them (page 76).

Embellish and enhance your melodies — with the automatic Harmony and Echo effects

This powerful performance feature lets you automatically add harmony notes to the melodies you play with your right hand — based on the chords you play with your left. Tremolo, Echo, and other effects are available, too.

1 Turn HARMONY/ECHO on.



2 Turn ACMP on (page 28).

3 Play a chord with your left hand and play some notes in the right-hand range of the keyboard.

The PSR-A1000 has various Harmony/Echo types (page 127).

The Harmony/Echo type may change according to the selected MAIN voice.

NOTE

For details about Harmony/Echo types, refer to the separate Data List.

- Harmony/Echo is just one of the many Voice Effects you can use. Try out some of the other effects and see how they can enhance your performance (page 54).


Style Sections

Each style in the auto accompaniment is made up of “sections.” Since each section is a rhythmic variation of the basic style, you can use them to add spice to your performance and mix up the beats — while you’re playing. Intros, Endings, Main patterns, and Breaks — they’re all here, giving you the dynamic elements you need to create professional-sounding arrangements.


INTRO	This is used for the beginning of the song. When the intro finishes playing, accompaniment shifts to the main section.
MAIN	This is used for playing the main part of the song. It plays an accompaniment pattern of several measures, and repeats indefinitely until another section’s button is pressed.
BREAK	This lets you add dynamic variations and breaks in the rhythm of the accompaniment, to make your performance sound even more professional.
ENDING	This is used for the ending of the song. When the ending is finished, the auto accompaniment stops automatically.

▶ **1-3** Use the same operations as in “Playing a style” on pages 28 and 29.

▶ **4** Press the [INTRO] button.




▶ **5** As soon as you play a chord with your left hand, the Intro starts. For this example, play a C major chord (as shown below).



When the playback of the intro is finished, it automatically leads into main section.


▶ **6** Press any of the MAIN [A] to [D] buttons or [BREAK] button as desired. (See the Accompaniment Structure on the next page.)




▶ **7** Press the [AUTO FILL IN] button to add a fill-in, if necessary. Fill-in patterns play automatically between each change in the Main sections.



▶ **8** Press the [ENDING] button. This switches to the ending section. When the ending is finished, the style automatically stops.



■ Accompaniment Structure



You can have the ending gradually slow down (ritardando) by pressing the **[ENDING]** button again while the ending is playing back.

NOTE


- An Intro doesn't necessarily have to be at the beginning! If you want, you can play an Intro section in the middle of your performance by simply pressing the **[INTRO]** button at the desired point.
- Watch your timing with the Break sections. If you press a **[BREAK]** button too close to the end of the measure (i.e., after the final eighth note), the Break section starts playing from the next measure. This also applies to the Auto Fill-in.
- Mix up your intros and use any of the other sections to start the style, if you want.
- If you want to come back into the style right away after an Ending, simply press the **[INTRO]** button while the Ending section is playing.
- If you press the **[BREAK]** button while the ending is playing, the break will immediately start playing, continuing with the main section.

Other Controls

<p>FADE IN/OUT</p> <p>FADE IN/OUT</p> 	<p>The [FADE IN/OUT] button can be used to produce smooth fade-ins and fade-outs (page 62) when starting and stopping the style.</p>
<p>TAP TEMPO</p> <p>TAP TEMPO</p> 	<p>The style can be started at any tempo you desire by "tapping" out the tempo with the [TAP/TEMPO] button. For details, see page 48.</p>
<p>SYNC.STOP</p> <p>SYNC.STOP</p> 	<p>When Synchro Stop is on, you can stop and start the style anytime you want by simply releasing or playing the keys (in the Auto Accompaniment area of the keyboard). This is a great way to add dramatic breaks and accents to your performance. For details, see page 62.</p>

Playing with the Songs

Reference on page 66




Playing Along with the PSR-A1000

In this section, try using the PSR-A1000's song playback features to cancel or mute the right-hand melody while you play the part yourself. It's like having a very talented and versatile playing partner accompany you while you perform.

▶ **1-4** Use the same operations as in "Song Playback" on pages 21 - 23.


▶ **5** Press the [TRACK 1] button to cancel the right hand melody part.



NOTE
To cancel the left hand part, press the [TRACK 2] button.

▶ **6** If you want to see the lyrics, press the [B] button.


If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.



NOTE
If the selected song does not contain lyric data, lyrics are not displayed.

▶ **7** Press the SONG [START/STOP] button and play the part.


If you want, you can adjust the tempo by pressing the TEMPO[◀] [▶] buttons.



NOTE

- If you want to start the song right away without an intro, use the Sync Start function. To set Sync Start to standby, simultaneously hold down the [TOP] button and press the SONG [START/STOP] button. Song playback starts automatically the moment you start playing the melody.
- If you can hear the PSR-A1000 playing the melody part as well, check the channel setting for the melody part in the song data, and change the channel assigned to Track 1 (page 121). You can also change the song channel itself permanently (page 94).


▶ **8** Press the SONG [START/STOP] button to stop playback.




Recording

The PSR-A1000 lets you record, too — quickly and easily. Try out the Quick Recording feature now and capture your keyboard performance.


- ▶ **1-3** Select a voice for recording. Use the same operations as in “Playing a Voice” on pages 25, 26.
- ▶ **4** Press the [REC] and [TOP] buttons simultaneously to select “New Song” for recording.




- ▶ **5** Simultaneously hold down the [REC] button and press the [TRACK1] button.




- ▶ **6** Recording starts as soon as you start playing the keyboard.



- ▶ **7** When you’ve finished recording, press the [REC] button.



- ▶ **8** To hear your newly recorded performance, return the song to the beginning by using the [TOP] button and press the SONG [START/STOP] button.




- ▶ **9** Save the recorded data as required (pages 35, 41).

CAUTION


The recorded data will be lost if you turn off the power. To keep your important recordings, you’ll need to save them to the User drive or floppy disk.

Setting an Oriental Scale


The Scale Setting feature lets you easily lower the pitches of specific notes by 50 cents to create your own oriental scales. Up to six scale settings can be stored for instant recall (Scale Memory), whenever you need them.



- ▶ **1** The [SCALE SETTING] buttons simulate an one-octave keyboard (C through B). Press the button corresponding to the key whose pitch you want to lower (the button lights). Press again to return to normal pitch.



- ▶ **2** The scale settings you set are memorized by the Scale Memory function. While holding the [MEMORY] button, press one of the SCALE MEMORY buttons. You can recall the memorized setting by pressing the appropriate button at any time.



NOTE
To maintain the memorized scale settings even after the power is turned off, make sure to save the settings as a file (page 74).

NOTE
In the SCALE TUNE display, you can select a desired scale template including oriental scales and create your own scales by fine tuning the scale notes (page 72).

Basic Operations — Organizing Your Data

The PSR-A1000 utilizes a variety of data types — including voices, accompaniment styles, songs, multi pads and registration memory settings. Much of this data is already programmed and contained in the PSR-A1000; you can also create and edit your own data with some of the functions on the instrument.

All this data is stored in separate files — just as is done on a computer.

Here, we'll show you how to use the basic operations of the display controls in handling and organizing the data of the PSR-A1000 in files and folders.

Files can be opened, saved, named, moved, or deleted in their respective Open/Save displays. You can select these displays according to their respective file types, as well: Song, Voice, Style, etc. Moreover, you can organize your data efficiently by putting various files of the same type into a single folder.


The Open/Save displays for Song, Voice, Style, Multi Pad Bank and Registration Bank can be called up from the MAIN display (the display shown when the power is turned on) by pressing the appropriate [A] - [J] button.

Open/Save display for Style (page 56)



handles the Style files.

Open/Save display for Song (page 67)




handles the Song files.

Open/Save display for Voice (page 51)



handles the Voice files.



NOTE


The following Open/Save display types are also available; however, these are selected from displays other than the MAIN display (page 135).

- SYSTEM SETUP
- MIDI SETUP
- USER EFFECT

NOTE


If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.

Open/Save display for Multi Pads (page 64, 109)




handles the Multi Pad Bank files.

Open/Save display for Registration Bank (page 77)



handles the Registration Bank files.

Open/Save display for Scale Bank (page 72)



handles the Scale Tune Bank files.

Example — Open/Save display for Voice

Each Open/Save display consists of PRESET, USER, and FLOPPY DISK drive pages.

PRESET drive


The files that are pre-programmed and installed internally to the PSR-A1000 are kept here. Preset files can be loaded but cannot be re-written. However, you can use a preset file as a basis for creating your own original file (which can be saved in the USER or FLOPPY DISK drive).

USER drive

Files kept here are those containing your own original data, created or edited using the various functions of the PSR-A1000. They are stored internally to the PSR-A1000.

FLOPPY DISK drive

You can also store your original data to floppy disk. Commercially available disk software can also be called up here. Naturally, these files are available only when the appropriate disk is inserted in the floppy disk drive.



Changes drives among PRESET, USER and FLOPPY DISK.

Calls up the upper level directory page. In this example, the voice folder selection page can be called up.

File

All data, both pre-programmed and your own original, are stored as "files."

Current Memory

"Current Memory" is the area where the voice is called up when you select a voice. Also it is the area where you edit your voice using the SOUND CREATOR function. Your edited voice should then be saved as a file in the USER or FLOPPY DISK drive.

Recording songs (page 83) and creating accompaniment styles (page 99) are done within the current memory. Please make sure to properly save this data to the USER/FLOPPY DISK drive as a file or files. The data will be lost if you turn off the power without saving.

Selecting Files and Folders




Select a file shown in the display. In this example, we'll select a voice file.

First, press the VOICE [PIANO] button to call up the display containing the files.

This display ("Open/Save" display) is typical of those used to call up and store files (voice files).

The PSR-A1000 already contains a variety of voices in the PRESET section. You can store your own original voices created with the **Sound Creator** function to the **USER** or **FLOPPY DISK** section.

1 Select "PRESET," "USER," or "FLOPPY DISK" by using the [BACK][NEXT] button.



NOTE
Double-clicking the appropriate [A] - [J] button calls up the corresponding file and returns to the MAIN display.

2 Use the [1▲] ~ [7▲] buttons to turn the pages.

When the available number of pages exceeds eight, the bottom of the display changes as shown below.



Press Next ↓ ↑ Press Prev.(previous)



3 Select the file/folder.

- There are two ways to select the file/folder:
 - **Press the [A] - [J] button.**
Press the letter button corresponding to the file/folder you wish to call up. (In the example display shown above, the voice files are shown.)
 - **Use the [DATA ENTRY] dial and the [ENTER] button.**
When you turn the [DATA ENTRY] dial, the highlight moves among the available files/folders. Highlight the desired file or folder (voice files are shown in the example above) and press the [ENTER] button to call up the selected item.

NOTE
Highlighting the desired file and double-clicking the [ENTER] button calls up the corresponding file and returns to the MAIN display.




Press the [EXIT] button to go back to the MAIN display.

You can go back to the previous display by pressing the [EXIT] button.

Exiting from small pop-up windows

You can also exit from small pop-up windows (such as in the illustration below) by pressing the [EXIT] button.



File/Folder-related Operations

Naming Files/Folders

You can assign names to files and folders. Any file/folder in the **USER** and **FLOPPY DISK** sections can be named or renamed. Execute the following steps when there is data in the User drive. If there are Preset files/folders you wish to rename, copy them beforehand (page 40) and use them as User files/folders.


- 1 Press the [1▼] (NAME) button (page 35).
The NAME display appears.



NOTE

A file/folder name can contain up to 50 half size letters (or 25 Hiragana and kanji letters), including the Icon ID (see the note below) and the extension.

- 2 Select the appropriate file/folder and press the [7▼](OK) button.
The currently selected file/folder is highlighted. To select another file/folder, press one of the [A] - [J] buttons.
To cancel, press the [8▼] (CANCEL) button.



NOTE

The file name will appear on your computer as follows. If you change the Icon ID or the extension, the icon may change or the file may not be properly recognized.

ABCDE.S002.MID
 File ID Icon ID Extension



Input the new name (page 42).



Press the [8▲] (OK) button.
To cancel, press the [8▼] (CANCEL) button.

Moving Files/Folders

You can move files and folders as desired, for organizing your data. Any file/folder in the **USER** and **FLOPPY DISK** sections can be moved, using the cut-and-paste operation described below.

1 Press the [2▼] (CUT) button (page 35).

The **CUT** display appears.



NOTE

This operation cannot be used to directly move a file/folder from one floppy disk to another. If you want to do this, cut and paste the file or folder from the first floppy disk to the **USER** page, then change disks and paste it to the **FLOPPY DISK** page.

2 Select the desired file/folder for moving.

Select the appropriate file/folder and press the [7▼](OK) button. The currently selected file/folder is highlighted. To select another file/folder, press one of the [A] - [J] buttons. Several files/folders can be selected together, even those from other pages. To release or cancel the selection, press the button of the selected file/folder again. Press the [6▼] (**ALL**) button to select all the files/folders in the displayed page (**USER/FLOPPY DISK**). When the [6▼] (**ALL**) button is pressed the [6▼] button changes to "**ALL OFF**" button to release or cancel the selection.

NOTE

All files/folders in a floppy disk can be copied to another disk in one batch (page 134).

NOTE

After being pasted, the files are automatically re-ordered in alphabetical order and displayed.

3 Press the [7▼] (OK) button.

To stop the operation, press the [8▼] (**CANCEL**) button.

NOTE

About files/folders in a floppy disk
In the **FLOPPY DISK** page of the Open/Save display, only the files which can be handled in that Open/Save display will appear — even though a folder in a floppy disk can contain different kinds of files.
In the case of a folder cut-and-paste operation (for floppy disk), an entire folder can be cut; however, only the specific files which can be handled in the current Open/Save display will be pasted.

4 Call up the destination display.

Only the **USER** and **FLOPPY DISK** pages can be selected as the destination.




Press the [4▼] (PASTE) button.

The file/folder you cut is now pasted at the destination.


Copying Files/Folders

You can also copy files and folders as desired, for organizing your data. Any file/folder in the **PRESET**, **USER** and **FLOPPY DISK** sections can be copied, using the copy-and-paste operation described below.



Deleting Files/Folders

You can also delete files and folders as desired, for organizing your data. Any file/folder in the **USER** and **FLOPPY DISK** sections can be deleted, using the operation described below.




Saving Files

This operation lets you save the data (such as song and voice) you created in current memory (page 36) to files. The files can be saved only to the **USER** and **FLOPPY DISK** drives.

If the Open/Save display for the type of data you wish to save is not shown, first return to the MAIN display by pressing the **[DIRECT ACCESS]** button followed by the **[EXIT]** button. Then, press the appropriate button **[A]–[J]** from the MAIN display to call up the respective Open/Save display. Finally, call up the **USER** or **FLOPPY DISK** page (pages 35, 36).

1 Press the **[6▼]** (SAVE) button.



NOTE

The internal memory capacity of the PSR-A1000 is about 260KB. Memory capacity for 2DD and 2HD floppy disks is about 720KB and 1440KB, respectively. When you store data to these locations, all file types of the PSR-A1000 (Voice, Style, Song, Registration, etc.) are stored together.


NOTE

The files of commercially available DOC software and Yamaha Disklavier software, and their edited files on the PSR-A1000, can be stored in the USER page, but cannot be copied to another floppy disk.

Organizing Files by Creating a New Folder

This operation lets you easily organize your various files into categories by creating a new folder for each category. Folders can only be created in the **USER** and **FLOPPY DISK** sections.

1 Call up the page to which you wish to create a new folder and press the **[7▼]** (NEW) button (page 35).



NOTE

Folder directories can contain up to four levels. The maximum total number of files and folders which can be stored is 400, but this may differ depending on the length of the file names. The maximum number of files which can be stored in a folder will be 250.

Displaying Upper Level pages

Press the **[8▼]** (UP) button to call up the upper level pages. For example, you can call up the folder level pages from the file level pages.

Entering Characters and Changing Icons


1 Press the **[1▼]** (NAME), **[6▼]** (SAVE), or **[7▼]** (NEW) button (page 35).

Change the type of character by using the **[1▲]** button.

The following types of characters are available:

CASE — Alphabet (capital letters, half size), numbers (half size), marks (half size)

case — Alphabet (lowercase letters, half size), numbers (half size), marks (half size)



Call up the **ICON SELECT** display by pressing the **[1▼]** button. This lets you change the icon at the left of the file name.

Entering Characters

The instructions that follow show you how to enter characters in naming your files and folders. The method is much the same as inputting names and numbers to your cell phone.

- 1** Move the cursor to the desired position by using the [DATA ENTRY] dial.
- 2** Press the appropriate button, [2▲] - [7▲] and [2▼] - [6▼], corresponding to the character you wish to enter. Several different characters are assigned to each button, and the characters change each time you press the button. To actually enter the selected character, move the cursor or press another letter-input button. If you've entered a character by mistake, move the cursor to the character letter you wish to erase and press the [7▼] (DELETE) button. If you want to delete all of the characters on the line at once, press and hold down the [7▼] (DELETE) button for a while. When the cursor appears in reverse display (highlight), only the reversed area is deleted.

- 3** To actually enter the new name, press the [8▲] (OK) button.


To cancel the operation, press the [8▼] (CANCEL) button.

■ Entering special character marks (umlaut, accent)

Select a character to which a character mark is to be added and press the [6▼] button (before actual entry of the character.)

■ Entering miscellaneous characters (marks)

You can call up the mark list by pressing the [6▼] button, after actually entering a character by moving the cursor.



Move the cursor to the desired mark by using the [DATA ENTRY] dial, then press the [8▲] (OK) or [ENTER] button.

■ Entering numbers

Press and hold down the appropriate button, [2▲] - [7▲] and [2▼] - [5▼], for a while, or press it repeatedly until the desired number is selected.

NOTE

The following half-size marks cannot be used in naming files and folders:
¥ \ / : * ? " < > |


NOTE

In the case of characters which are not accompanied by special character marks, you can call up the mark list by pressing the [6▼] button after selecting a character (before actual entry of a character).

Changing the Icon

You can also change the icon that appears at the left of the file name. Call up the **ICON SELECT** display by pressing the [1▼] (ICON) button from the character input display (page 42).

Select the desired icon by using the [A] - [J] buttons, or by using the [3▲▼] - [5▲▼] buttons, then enter the selected icon by pressing the [8▲] (OK) button.





Using the [DATA ENTRY] Dial

This convenient control lets you easily select items in the display or quickly change parameter values. The actual function of the [DATA ENTRY] dial differs depending on the selected display.


■ Adjusting values

You can change parameter values by rotating the [DATA ENTRY] dial. In the example [BALANCE] display, turning the dial adjusts the volume of the part in reverse display (highlight). To adjust the volume of another part, first select the part by pressing the [▲▼] button corresponding to the part, then rotate the [DATA ENTRY] dial.




■ Selecting items



You can select the desired item or function in the display by rotating the [DATA ENTRY] dial. The selected item can then be called up or executed by using the [ENTER] button. In the example **VOICE** display, you can select the desired voice file with the [DATA ENTRY] dial, and call up the selected item by pressing the [ENTER] button on the panel.



Direct Access — Instant Selection of Displays



With the convenient Direct Access function, you can instantly call up the desired display — with just a single additional button press. Press the **[DIRECT ACCESS]** button and a message appears in the display prompting you to press the appropriate button. Then, simply press the button corresponding to the desired setting display to instantly call up that display. In the example below, Direct Access is used to call up the display for selecting the **Chord Fingering** (page 123).



Refer to the Direct Access Chart (page 45) for a list of the displays that can be called up with the Direct Access function.



NOTE
Here's a convenient way to return to the **MAIN** display from any other display: Simply press the **[DIRECT ACCESS]** button, then the **[EXIT]** button.

Direct Access Chart

Operation: [DIRECT ACCESS] button + button listed below		Corresponding LCD display and function			See pages	
SONG	[TRACK1]	FUNCTION	SONG SETTING	TRACK1 CHANNEL selection	121	
	[TRACK2]			TRACK2 CHANNEL selection	121	
	[EXTRA TRACKS]					121
	[REPEAT]					
	[METRONOME]			UTILITY	METRONOME settings	132
	[REC]					
	[TOP]					
	[START/STOP]					
[REW]						
[FF]						
STYLE	[POP & ROCK] [LATIN & JAZZ]	FUNCTION	STYLE SETTING/SPLIT POINT	SPLIT POINT (ACMP) setting	122	
	[DANCE & BALLROOM]					
	[TÜRKÇE / ΕΛΛΗΝΙΚΑ] [عربي]					
	[ایرانی] [خليجي]					
	[USER]					
SCALE SETTING buttons						
SCALE MEMORY	[MEMORY]	SCALE TUNE BANK	SCALE TUNE BANK		72	
	[1]–[6]		SCALE TUNE EDIT		74	
STYLE CONTROL	[ACMP]	FUNCTION	CHORD FINGERING	FINGERING TYPE selection	122	
	[BREAK]					
	[INTRO]	MIXING CONSOLE (STYLE PART)	VOLUME/VOICE	VOICE settings	113	
	MAIN [A]			PANPOT settings		
	MAIN [B]			VOLUME settings		
	MAIN [C]		FILTER	HARMONIC CONTENT settings	114	
	MAIN [D]			BRIGHTNESS settings		
	[ENDING/rit.]			REVERB settings		
	[AUTO FILL IN]	FUNCTION	EFFECT	CHORUS settings	115	
	[FADE IN/OUT]			DSP settings		
	[SYNC. STOP]		UTILITY	FADE IN/OUT setting	122	
	[SYNC. START]		STYLE SETTING/SPLIT POINT	SYNC. STOP WINDOW setting		
	[START/STOP]					
DIGITAL STUDIO	[SOUND CREATOR]					
	[DIGITAL RECORDING]					
	[MIXING CONSOLE]					
MENU	[DEMO]	FUNCTION	UTILITY	LANGUAGE selection	135	
	[HELP]			LCD BRIGHTNESS settings	133	
	[FUNCTION]		MIDI	MIDI settings	129	
[DIRECT ACCESS]	Exit from the Direct Access mode					
[BALANCE]	MIXING CONSOLE (SONG PART)	VOLUME/VOICE	VOLUME settings	113		
[CHANNEL ON/OFF]			VOICE settings			
[NEXT]						
[BACK]						
VOICE PART	[MAIN]	MIXING CONSOLE	TUNE	OCTAVE settings	114	
	[LAYER]					
	[LEFT]					
[SCALE TUNING]	SCALE TUNE BANK	SCALE TUNE BANK		32		
[EXIT]	Return to the MAIN display					
[ENTER]						
VOICE EFFECT	[LEFT HOLD]	FUNCTION	STYLE SETTING/SPLIT POINT	SPLIT POINT (LEFT) setting	122	
	[TOUCH]		CONTROLLER	KEYBOARD TOUCH assignment	125	
	[SUSTAIN]	MIXING CONSOLE	EFFECT	REVERB settings	115	
	[HARMONY/ECHO]	FUNCTION	HARMONY/ECHO		127	
	[MONO]	MIXING CONSOLE	TUNE	PORTAMENTO TIME settings	114	
	[DSP]		EFFECT	DSP settings	115	
	[VARIATION]			EFFECT TYPE selection		
VOICE	[PIANO]	FUNCTION	VOICE SET settings		127	
	[ORGAN & ACCORDION]					
	[GUITAR]					
	[TRUMPET]					
	[SAX & FLUTE]					
	[STRINGS]					
	[CHOIR & PAD]					
	[SYNTHESIZER]					
	[XG]					
	[اورينتال]					
	[PERCUSSION]					
[USER]						
TRANSPOSE	[◀]	FUNCTION	CONTROLLER	TRANSPOSE assignment	125	
	[▶]	MIXING CONSOLE	TUNE	TRANSPOSE settings	114	
TEMPO	[◀]	FUNCTION	MIDI	MIDI CLOCK setting	129	
	[▶]					
[TAP TEMPO]			UTILITY	TAP settings	133	
UPPER OCTAVE	[◀]					
	[▶]					
MULTI PAD	[1]	MULTI PAD	MULTI PAD EDIT		64	
	[2]					
	[3]					
	[4]					
	[STOP]					
REGISTRATION MEMORY	[FREEZE]	DIGITAL RECORDING	MULTI PAD CREATOR	REPEAT / CHORD MATCH settings	110	
		FUNCTION	FREEZE		126	
REGISTRATION BANK	[1]	REGISTRATION BANK	REGISTRATION EDIT (Editing the REGISTRATION)		77	
	[2]					
	[3]					
	[4]					
	[5]					
	[6]					
	[7]					
	[8]					
	[MEMORY]					
PEDAL	[PEDAL1]	FUNCTION	CONTROLLER	PEDAL1 function assignment	123	
	[PEDAL2]			PEDAL2 function assignment		
WHEEL	[PITCH BEND]	MIXING CONSOLE	TUNE	PITCH BEND RANGE settings	114	

Help Messages

The Help messages give you explanations and descriptions of all the main functions and features of the PSR-A1000.



2

CONTENTS [Basic Operations] Operation Buttons Select Items and Change Settings Direct Access Using the Functions Setting the Split Point Setting the Tempo Using Channel On/Off [File Operations] Drive (PRESET/USER/FLOPPY DISK) Open/Save Display [Demonstration] Playing the Demos [Voices] Selecting Voices		LANGUAGE ENGLISH GERMAN FRENCH
--	--	--

2-1 Select the desired Help topic.

2-2 Call up the topic.

Select the Language, if necessary. The language selected here are also used for various "Messages" shown during operations.

NOTE
Help messages can be displayed in any one of the following languages:
ENGLISH
GERMAN
FRENCH

NOTE
The language can also be selected in the FUNCTION "LANGUAGE" (page 135) display.

3

1. Call up the FUNCTION MENU display by pressing [FUNCTIONS].
2. Select the appropriate Function display by pressing [A] - [I].
3. Call up the appropriate page by using [BACK]/[NEXT].
4. Select the desired parameter with [A] or [B], then make the settings by using [1▲▼] - [8▲▼].

When two or more pages available, use this to select different pages.


Help messages also feature links to the detailed explanation or actual setting display of the selected topic. Simply select the underlined word (using the [DATA ENTRY] dial), and press the [ENTER] button to jump to the detailed explanation or actual setting display of the selected topic.

END

Press this to return to the previous display.

Using the Metronome

The **metronome** provides a click sound, giving you an accurate tempo guide when you practice, or letting you hear and check how a specific tempo sounds.




The **metronome** starts by pressing the [METRONOME] button. Adjust the tempo by using the **TEMPO**[◀] [▶] buttons (see below). To stop the **metronome**, press the [METRONOME] button again.

NOTE

The sound, volume level, and the beat (time signature) of the metronome can all be changed (page 132).

Adjusting the Tempo

This section shows you to adjust the playback tempo — which not only affects the metronome, but also the playback of a song or an accompaniment style.



1

Press either the **TEMPO** [◀] button or the [▶] button.

Press this to close the **TEMPO** display.

2

Adjust the tempo by using either the **TEMPO** [◀] [▶] buttons or the [DATA ENTRY] dial. The number in the display indicates how many quarter-note beats there are in one minute. The range is between 5 and 500. The higher the value, the faster the tempo.

When you change the tempo, both tempos of the current song and style will be changed to the same tempo. To restore their respective default (initial) tempo settings, press both the **TEMPO** [◀] [▶] buttons simultaneously. Also refer to the “Tempo Indications — MAIN display” (page 48) for more about tempo.

NOTE


Songs and accompaniment styles have been given default (initial) tempo settings, designed to best suit the song/style.

Tap Tempo

This useful feature lets you tap out the tempo for a song or an accompaniment style. Simply tap the **[TAP TEMPO]** button at the desired speed, and the tempo of the song or the accompaniment style changes to match your tapping.

1 Playback the song or the accompaniment style (page 56, 67).

2 Tap the **[TAP TEMPO]** button twice to change the tempo.



NOTE Hitting the **[TAP TEMPO]** button produces a tapping sound. You can change this sound, if desired (page 133).

NOTE You can also use Tap Tempo to automatically start the song or accompaniment style at the desired tempo. While both the song and accompaniment style are stopped, tap the **[TAP TEMPO]** button several times, and the selected accompaniment style starts automatically at the tempo you tapped. While a song is set to Sync. Start stand-by (page 57, 67), tapping the **[TAP TEMPO]** button starts the song playback in the same manner. For songs and styles in 2/4 and 4/4 time, tap four times; for 3/4 time, tap three times; for 5/4 time, tap five times.


Tempo Indications — MAIN Display

There are three different tempo indications in the Main display, as shown below.

Indicates the default (initial) tempo setting for the currently selected song (unless the tempo has been changed manually).


Indicates the current tempo for the selected song, accompaniment style or the metronome which is now playing back. When nothing is playing back (stopped), this indicates the tempo for the selected style. When the song and style are played back simultaneously, the tempo of the style is automatically changed to match the tempo of the song, and is displayed here. This tempo is used for recording when recording a song or accompaniment style.

Indicates the default (initial) tempo setting for the currently selected accompaniment style (unless the tempo has been changed manually).



Playing the Demos

The PSR-A1000 is an extraordinarily versatile and sophisticated instrument, featuring a wide variety of dynamic voices and rhythms, plus a wealth of advanced functions. Three different types of Demo songs have been specially prepared showcasing the stunning sound and features of the PSR-A1000.



1 Pressing the [DEMO] button automatically plays back the Demo songs at random.




2

2-1 Use the [BACK][NEXT] buttons to select the desired Demo category.

Function Demos..... These demonstrate each of the different functions on the PSR-A1000.


Voice Demos These showcase the voices of the PSR-A1000.

Style Demos These introduce you to the rhythms and accompaniment styles of the PSR-A1000.



2-3 Press one of these buttons twice — once to select the desired demo, and once again to start it.

2-2 Use these to select different display pages.



Press this to play back all Demo songs/items continuously, starting from the first item at the top left of the display. This is available only from the FUNCTION page.



All of the available demos are played back in sequence, starting from the one at top left. The **VOICE** and **STYLE** pages do not have the [AUTO] button; however, all demo songs are played back in sequence.

Pressing this button cancels the interactive features of the Function Demos (otherwise available in step 3 below).




3 For the Function demos, an introduction screen appears in the display and the Demo starts playing.

This example shows the Sound System in the FUNCTION demo.



Select the desired word or item by using the [DATAENTRY] dial, then press the [ENTER] button or number buttons ([1 ▼], [2 ▼], etc.) to call it up.



NOTE

Use the [BACK][NEXT] buttons in the introduction screen to call up the previous or next page.

NOTE


Press the SONG [START/STOP] button to stop the Demo song. To start the Demo again from the point at which it was stopped, press the SONG [START/STOP] button again. Rewind and fast-forward can also be used with the Demo songs (page 69).



Return to the MAIN screen.

Voices

The PSR-A1000 gives you an enormous selection of authentic voices, including various keyboard instruments, strings and brass — and many, many more.






Selecting a Voice

- 1 Press the [MAIN] button to turn the MAIN part on, then press [F] button to call up the menu for selecting the MAIN voice.

NOTE

The voice you're selecting here belongs to the MAIN part, and is called the MAIN voice. (See page 53 for more information.)




Turn MAIN on.

You'll want to hear the MAIN voice all by itself — so make sure that the LAYER and LEFT parts are turned off.

- 2 Select the desired voice group.


NOTE

When you select a voice group, the last selected voice will automatically be selected.



Layer/Left — Playing Several Sounds Simultaneously


The PSR-A1000 lets you set three voices for simultaneous play: MAIN, LAYER, and LEFT. By effectively combining these three, you can create richly textured, multi-instrument setups for your performance.




Playing a layer of two voices



Playing two voices separately — on the left and right sections of the keyboard



Playing three different voices — one on the left section of the keyboard, plus a layer of two on the right



Layer — Layering Two Different Voices

1 Press this to turn the LAYER function on. To turn it off, press the button again.

2 Select Layer with the [G] button. Press the same button to call up the VOICE display, from which you can select the specific voice you want to play in a layer with the Main voice. The method of selecting a voice here is the same as that in VOICE (MAIN) display (page 51).

NOTE
There is an alternate way for quickly selecting both the MAIN and LAYER voices from the panel: While holding down one panel voice button, press a second voice button. The first selected voice becomes the MAIN voice, and the second becomes the LAYER.

Press this to return to the MAIN display.

Left — Setting Separate Voices for the Left and Right Sections of the Keyboard

1 Set the **LEFT** to **ON**. Press this button again to set it to **OFF**.

2 Select **LEFT** with the **[H]** button. Press the same button to call up the **VOICE** display, from which you can select the specific voice you want to play in a left. How to select the voice is the same as the way of **VOICE (MAIN)** screen (page 51).

NOTE
The split point can be freely set to any key on the keyboard. (page 122).


NOTE
Each part (**MAIN**, **LAYER**, and **LEFT**) can have its own volume setting (page 58).

NOTE
You can also use the **LAYER** and **LEFT** functions together, to create a combination layer/split. To do this, set separate voices for the left and right sections of the keyboard (as indicated), and set up a layer of two different voices on the right.

Press this to return to the **MAIN** display.

Applying Voice Effects

This section of the panel lets you add a variety of effects to the voices you play on the keyboard.



Press one of the effect buttons to turn the corresponding effects on. Press it again to turn the effect off. For explanations on each of the effects, see below.

TOUCH

This button turns the touch response of the keyboard on or off. When this is set to off, the same volume is produced no matter how strongly or softly you play the keyboard.

SUSTAIN

When this Sustain feature is on, all notes played on the keyboard (**MAIN/LAYER** parts only) have a longer sustain. You can also set the Sustain depth (page 82).

DSP

The PSR-A1000 features a variety of dynamic built-in digital effects, letting you process the sound in various ways. You can use DSP to enhance the voices in subtle ways — such as by applying chorus to add animation and depth, or using a symphonic effect to give the sound warmth and richness. DSP also has effects such as distortion that can completely change the character of the sound. DSP is set for the currently selected part (**MAIN/LAYER/LEFT**).

NOTE
The **DSP** and **VARIATION** effect types and their depth can be selected and adjusted in the **MIXING CONSOLE** display (page 115).

■ VARIATION

This control changes the Variation effect settings, letting you alter some aspect of the effect, depending on the selected type. For example, when the Rotary Speaker effect is selected (page 115), this lets you switch the rotor speed between slow and fast.

■ HARMONY/ECHO

This control adds Harmony or Echo effects to the voices played on the right hand section of the keyboard (page 127).

■ MONO

This control determines whether the voice is played monophonically (only one note at a time) or polyphonically for each part (MAIN/LAYER/LEFT). This is set to MONO when the lamp is lit, and set to polyphonic when the lamp is off. When set to MONO, only the last note played will sound. This lets you play wind instrument voices more realistically. Depending on the selected voice, the MONO setting also lets you effectively use the Portamento effect, when playing in legato.

■ LEFT HOLD

This function causes the left part voice to be held even when the keys are released — the same effect as when the sustain pedal is pressed. This function is especially effective when used with the auto accompaniment. For example, if you play and release a chord in the auto accompaniment area of the keyboard (with the left part on and the Left voice set to Strings), the strings part sustains, adding a natural richness to the overall accompaniment sound.

NOTE

The Portamento effect creates a smooth pitch glide between successively played notes.


HINT

You can add special emphasis to melody lines you play over chords by using the Layer function with a monophonic voice. Set the Main voice to play polyphonically and set the Layer voice to play monophonically (MONO). In this case, the melody you play — including the top notes of any chords — sounds monophonically. Try this using the following voices.

MAIN voice: Brass Section (polyphonic) + **LAYER voice:** Sweet Trump (monophonic)

PITCH BEND Wheel

Use the PSR-A1000 PITCH BEND wheel to bend notes up (roll the wheel away from you) or down (roll the wheel toward you) while playing the keyboard. The PITCH BEND wheel is self-centering and will automatically return to normal pitch when released.




NOTE

The maximum pitch bend range can be changed (page 114).

Adjusting the Octave setting

The [UPPER OCTAVE] button allows the MAIN and LAYER parts to be simultaneously transposed up or down by one octave.




NOTE



More detailed octave-related settings for each part can be made by using the Mixing Console function (page 114).

Styles

The PSR-A1000 features styles (accompaniment patterns) in a variety of different musical genres including pops, jazz, Latin and dance. To use it, all you have to do is play the chords with your left hand as you perform and the selected Accompaniment Style (style) matching your music will automatically play along, instantly following the chords you play. Try selecting some of the different styles (refer to separate Data List (Style List)) and play them.



Playing a style



NOTE
For a list of the available accompaniment styles, refer to the separate Data List.

3 When the [ACMP] button is set on, you can play/indicate chords from the auto accompaniment area of the keyboard. (Depending on the settings, this may be the range of the Left voice, or the entire keyboard.)

STYLE CONTROL

ACMP BREAK INTRO MAIN A B C D ENDING /rit. AUTO FILL IN IN/OUT FADE IN/OUT SYNC STOP SYNC START START/STOP

NOTE
You can set the key range for auto accompaniment (page 122).

4 Turn SYNC. (SYNCHRONIZED) START on.

STYLE CONTROL

ACMP BREAK INTRO MAIN A B C D ENDING /rit. AUTO FILL IN IN/OUT FADE IN/OUT SYNC STOP SYNC START START/STOP

NOTE
Sync. Start
Enabling this lets you start the style simply by playing the keyboard.

5 As soon as you play a chord with the auto accompaniment area, the style starts. For details about chord fingerings, refer to page 59.

The Tempo can be adjusted using the TEMPO [◀][▶] or [TAP TEMPO] button. If you tap the [TAP TEMPO] button, the tempo will adjust to the same speed that you tapped.

Split point

Auto Accompaniment area

NOTE

- You can begin the rhythm channels (tracks) of the Style by pressing the [START/STOP] button.
- The rhythm channels of the style can also be started by tapping the [TAP TEMPO] button. With the style stopped, tap the [TAP TEMPO] button three, four or five times (three for 3/4 time, four for 2/4 or 4/4 time, five for 5/4 time).

6 Stop the style.

STYLE CONTROL

ACMP BREAK INTRO

END Turn ACMP off.

STYLE CONTROL

ACMP BREAK INTRO

NOTE
When you simultaneously play back accompaniment styles with a song, the accompaniment parts recorded to the song (channels 9 - 16) are temporarily replaced by the selected accompaniment style — letting you try out and use different accompaniment with the song (page 68).

Accompaniment Style Characteristics

The defining characteristics of some of the accompaniment styles are indicated above the relevant style names in the Open/Save display.

Session!

These styles provide even greater realism and authentic backing by mixing in original chord types and changes, as well as special riffs with chord changes, with the Main sections. These have been programmed to add “spice” and a professional touch to your performances of certain songs and in certain genres. As a result, the styles may not necessarily be appropriate — or even harmonically correct — for all songs and for all chord playing. In some cases for example, playing a simple major triad may result in a seventh chord, or playing an on-bass chord may result in incorrect or unexpected accompaniment.

Piano Combo! (Floppy Disk)

These accompaniment styles feature a basic piano trio (piano, bass, and drums), augmented in some cases with other instruments. Since this is a small combo sound, the accompaniment backing is appropriately sparse, making it useful and effective for a wide variety of songs.

Playing a Style's Rhythm Channels only

1 Select a style (page 56).

2

STYLE CONTROL

ACMP BREAK INTRO MAIN A B C D ENDING /rt. AUTO FILL IN IN/OUT FADE SYNC. STOP SYNC. START START/STOP

Set to off. Rhythm starts.

NOTE
The Rhythm channels are part of the styles. Each style has different rhythm patterns.

NOTE
You can also start the rhythm simply by playing a key on the keyboard, if Sync Start is enabled (turn on the [SYNC.START] button).

3 Play along with the rhythm playback.
The Tempo can be adjusted using the TEMPO [◀||▶] or [TAP TEMPO] buttons. If you tap the [TAP TEMPO] button, the tempo will adjust to the same speed that you tapped.

END Press the STYLE [START/STOP] button again to stop the rhythm playback.

Adjusting the Volume Balance/Channel Muting

BALANCE display

Call up the **BALANCE** display.

BALANCE

Adjust the output level of the Part.

MULTI PAD part

STYLE part (Auto Accompaniment area)

SONG part

Parts played from the keyboard (MAIN/LAYER/LEFT)

CHANNEL ON/OFF display

Call up the **Channel ON/OFF** display.

Call up the STYLE display by pressing the [CHANNEL ON/OFF] button, then turn the instrument you want to cancel off. To listen to only one instrument by itself, hold down the appropriate button for the channel to set the channel to SOLO. To cancel SOLO, simply press the appropriate channel button again.

NOTE
Channel
Refers to the MIDI channel in the song data (page 141). The channels are assigned as shown below.
Song
1 - 16
Accompaniment Style
9 - 16


Chord Fingerings

The style playback can be controlled by the chords you play in the keys to the left of the split point. There are 7 types of fingerings as described below. Go to the CHORD FINGERING page (page 123), and select the Chord Fingerings. The page shows how to play chords with your left hand.


SINGLE FINGER

Single Finger accompaniment makes it simple to produce beautifully orchestrated accompaniment using major, seventh, minor and minor-seventh chords by pressing a minimum number of keys on the auto accompaniment area of the keyboard. The abbreviated chord fingerings described below are used.


For a major chord, press the root key only.




For a minor chord, simultaneously press the root key and a black key to its left.



For a seventh chord, simultaneously press the root key and a white key to its left.



For a minor-seventh chord, simultaneously press the root key and both a white and black key to its left.



MULTI FINGER

The Multi Finger mode automatically detects Single Finger or Fingered chord fingerings, so you can use either type of fingering without having to switch fingering modes. If you want to play minor, seventh, or minor-seventh chords using the SINGLE FINGER operation in the MULTI FINGER Mode, always press the closest white/black key(s) to the root of the chord.

FINGERED

This mode lets you produce accompaniment by playing full chords on the auto accompaniment area of the keyboard. The Fingered mode recognizes the various chord types listed on the next page.

FINGERED ON BASS

This mode accepts the same fingerings as the FINGERED mode, but the lowest note played in the auto accompaniment area of the keyboard is used as the bass note, allowing you to play "on bass" chords. For example, to indicate a C-on-E chord, play a C major chord with E as the lowest note (E, G, C).

FULL KEYBOARD

This method detects chords in the entire key range. Chords are detected in a way similar to Fingered, even if you split the notes between your left and right hands — for example, playing a bass note with your left hand and a chord with your right, or by playing a chord with your left hand and a melody note with your right.

AI FINGERED

This mode is basically the same as FINGERED, with the exception that less than three notes can be played to indicate the chords (based on the previously played chord, etc.).

AI FULL KEYBOARD

When this advanced auto accompaniment mode is engaged, the PSR-A1000 will automatically create appropriate accompaniment while you play just about anything, anywhere on the keyboard using both hands. You don't have to worry about specifying the accompaniment chords. Although the AI Full Keyboard mode is designed to work with many songs, some arrangements may not be suitable for use with this feature.

This mode is similar to FULL KEYBOARD, with the exception that less than three notes can be played to indicate the chords (based on the previously played chord, etc.). 9th and 11th chords cannot be played.

NOTE

Chord detection in the AI Full Keyboard mode occurs at approximately 8th-note intervals. Extremely short chords — less than an 8th note in length — may not be detected.


NOTE

In Full Keyboard mode, chords are detected based on the lowest and second lowest notes you play. If the two lowest notes fall within a single octave, those two notes determine the chord. If the lowest note and the second lowest note are separated by more than one octave, the lowest note becomes the bass and the chord is determined from the second lowest note and the other notes played in the same octave.

NOTE

AI
Artificial Intelligence

Chord Types Recognized in the Fingered Mode (Example for “C” chords)



Chord Name [Abbreviation]	Normal Voicing	Display for root “C”
Major [M]	1 - 3 - 5	C
Ninth [9]	1 - 2 - 3 - 5	C9
Sixth [6]	1 - (3) - 5 - 6	C6
Sixth ninth [6 ⁹]	1 - 2 - 3 - (5) - 6 or 3 - 6 - 2*	C6 ⁹
Major seventh [M7]	1 - 3 - (5) - 7	CM7
Major seventh ninth [M7 ⁹]	1 - 2 - 3 - (5)j - 7	CM7 ⁹
Major seventh add sharp eleventh [M7 ^{#11}]	1 - (2) - 3 - #4 - 5 - 7 or 1 - 2 - 3 - #4 - (5) - 7	CM7 ^{#11}
Flatted fifth [b5]	1 - 3 - b5	C ^{b5}
Major seventh flatted fifth [M7 ^{b5}]	1 - 3 - b5 - 7	CM7 ^{b5}
Suspended fourth [sus4]	1 - 4 - 5	Csus4
Augmented [aug]	1 - 3 - #5	Caug
Major seventh augmented [M7aug]	1 - (3) - #5 - 7	CM7aug
Minor [m]	1 - b3 - 5	Cm
Minor ninth [m9]	1 - 2 - b3 - 5	Cm9
Minor sixth [m6]	1 - b3 - 5 - 6	Cm6
Minor seventh [m7]	1 - b3 - (5) - b7	Cm7
Minor seventh ninth [m7 ⁹]	1 - 2 - b3 - (5) - b7 or b3 - b7 - 2	Cm7 ⁹
Minor seventh eleventh [m7 ¹¹]	1 - (2) - b3 - 4 - 5 - (b7)	Cm7 ¹¹
Minor major seventh [mM7]	1 - b3 - (5) - 7	CmM7
Minor major seventh ninth [mM7 ⁹]	1 - 2 - b3 - (5) - 7	CmM7 ⁹
Minor seventh flatted fifth [m7 ^{b5}]	1 - b3 - b5 - b7	Cm7 ^{b5}
Minor major seventh flatted fifth [mM7 ^{b5}]	1 - b3 - b5 - 7	CmM7 ^{b5}
Diminished [dim]	1 - b3 - b5	Cdim
Diminished seventh [dim7]	1 - b3 - b5 - 6	Cdim7
Seventh [7]	1 - 3 - (5) - b7 or 1 - (3) - 5 - b7	C7
Seventh flatted ninth [7 ^{b9}]	1 - b2 - 3 - (5) - b7	C7 ^{b9}
Seventh add flatted thirteenth [7 ^{b13}]	1 - 3 - 5 - b6 - b7	C7 ^{b13}
Seventh ninth [7 ⁹]	1 - 2 - 3 - (5) - b7 or 3 - b7 - 2*	C7 ⁹
Seventh add sharp eleventh [7 ^{#11}]	1 - (2) - 3 - #4 - 5 - b7 or 1 - 2 - 3 - #4 - (5) - b7	C7 ^{#11}
Seventh add thirteenth [7 ¹³]	1 - 3 - (5) - 6 - b7 or 3 - 6 - b7	C7 ¹³
Seventh sharp ninth [7 ^{#9}]	1 - #2 - 3 - (5) - b7	C7 ^{#9}
Seventh flatted fifth [7 ^{b5}]	1 - 3 - b5 - b7	C7 ^{b5}
Seventh augmented [7aug]	1 - 3 - #5 - b7	C7aug
Seventh suspended fourth [7sus4]	1 - 4 - 5 - b7	C7sus4
Suspended second [sus2]	1 - 2 - 5	Csus2

NOTE

- Notes in parentheses can be omitted.
- For FINGERED, FIN-GERED ON BASS, and AI FINGERED, if you play any three adjacent keys (including black keys), the chord sound will be canceled and only the rhythm instruments will continue playing (Chord Cancel function). This let you play back only the rhythm.
- Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
- A perfect fifth (1 + 5) produces accompaniment based on the root and the fifth.
- The auto accompaniment Style will sometimes not change when related chords are played in sequence (e.g. some minor chords followed by the minor seventh).
- You can also have the PSR-A1000 “teach” you how to play Fingered chords. From the CHORD FINGERING display (page 123), specify the chord you want to learn, and the notes you should press are indicated in the display.

* Only this voicing (inversion) is recognized. Other chords not marked with an asterisk can be played in any inversion.

Arranging the Style Pattern (SECTIONS: MAIN A/B/C/D, INTRO, ENDING, BREAK)


The PSR-A1000 features various types of Auto Accompaniment Areas that allow you to vary the arrangement of the Style. They are: Intro, Main, Break and Ending. By switching among them as you play, you can easily produce the dynamic elements of a professional-sounding arrangement in your performance.

1 Select a style (page 56).



2

2-1 Turn the ACMP function on.




2-3 Turn the SYNC. START function on.

2-2 Press the [INTRO] button. To cancel the INTRO section before starting the style, press the [INTRO] button again.




3

The Intro section starts as soon as you play a key in the Auto Accompaniment area of the keyboard, and changes to the Main section.



4

Main sections can be shifted.



Press this button to add breaks.



NOTE


You can also use this function to play only rhythms (page 58).

NOTE

- If you press the [INTRO] button, you can play back an Intro section while an accompaniment is playing.
- Section button indications — [BREAK], [INTRO], [MAIN], [ENDING] buttons
LED is green — The section is not selected.
LED is red — The section is currently selected.
LED is off — No section data; the section cannot be played.
- You can dynamically control the level of the accompaniment by how softly or strongly you play the keys in the Auto Accompaniment area of the keyboard (page 122).
- If you press the [SYNC. START] button while an accompaniment is playing, the accompaniment will stop and the PSR-A1000 will enter Synchronized Start standby status.
- You can also change style sections by using the pedal (page 123).
- The Break section lets you add dynamic variations and breaks in the rhythm of the accompaniment, to make your performance sound even more professional. If you press the [BREAK] button while an accompaniment is playing, the fill-in will play back for one measure.
- The indicator of the destination section (MAIN A/B/C/D) will flash while the Break is playing.
- When the [AUTO FILLIN] button is set to on and the MAIN [A][B] [C][D] button is pressed after the final half beat (eighth note) of the measure, the fill-in will begin from the next measure.

5

This switches to the ending section. When the ending is finished, the Style stops automatically. You can have the ending gradually slow down (ritardando) by pressing the same [ENDING/rit.] button again while the ending is playing back.



NOTE

- Styles can also be started by pressing the **STYLE [START/STOP]** button.
- You can select the Intro and Ending type by pressing the **[E]** button in the **MAIN** window (page 63).
- If you press the **[INTRO]** button while the ending is playing, the Intro section will begin playing after the ending is finished.
- When the **[AUTO FILL IN]** button is set to on and you press a **MAIN** button while the ending is playing, fill-in accompaniment will immediately start playing, continuing with the Main section.
- You can begin the accompaniment by using the Ending instead of the Intro section. In this case, the auto accompaniment doesn't stop when the ending is finished.
- If you select a different style while the style is not playing, the "default" tempo for that style is also selected. If the style is playing, the same tempo is maintained even if you select a different style.
- When **STOP ACMP** is set to on and the accompaniment is not playing, you can play both chords and bass in the Auto Accompaniment area in the keyboard (page 122).

Fade-in/Fade-out

The accompaniment style also include a convenient Fade-in/Fade-out function that gradually fades in and fades out the accompaniment. To start the style with a fade-in, press the **[FADE IN/OUT]** button, then turn **SYNC. START** on. To cancel the fade-in before starting the style, press the button again.

To fade out and stop the Style, press this button while the style is playing. The time of the fade-in/fade-out can also be set (page 132).


Stopping the Style Playback While Releasing Keys (SYNC. STOP)

When the Synchro Stop function is engaged, style playback will stop completely when all keys in the Auto Accompaniment area of the keyboard are released. Style playback will start again as soon as the key in the Auto Accompaniment area is played.


1 Turn ACMP (Accompaniment) on.



2 Turn SYNC. STOP on. SYNC. START is also automatically set to on when SYNC. STOP is turned on.



3 As soon as you play a chord with your left hand, the style starts.



4 The style stops when you release your left hand from the keys.



5 Playing a chord with your left hand automatically restarts the style.



Press the **[SYNC. STOP]/[SYNC. START]** button again to stop the style.

NOTE

You can also use the SYNC. STOP function by pressing the auto accompaniment area/left-hand range briefly (page 122).

NOTE

Synchro Stop cannot be set to on when the fingering mode is set to Full Keyboard/All Full Keyboard or the auto accompaniment on the panel is set to off.

Selecting Intro and Ending Types (INTRO/ENDING)

1

The screenshot shows the MAIN display with various settings. A hand is shown pressing the E slider, which is highlighted with a red box.

NOTE
To call up the [MAIN] display, first press the [DIRECT ACCESS] button, then press the [EXIT] button.

2

Select a Intro
Select a Ending

The diagram shows two sliders, D and E, with arrows pointing to a table of Intro and Ending types.

INTRO	CountIn	4bar1	4bar2
ENDING	Fill:Hit	3bar	4bar

3 Play the style using the Intro or Ending section (page 30, 31).

Playing Fill-in patterns automatically when changing accompaniment sections — Auto Fill In

NOTE
Fill
A short phrase used to add variation to the style.

1

The screenshot shows the STYLE CONTROL panel with various buttons. The AUTO FILL IN button is highlighted with a red box and a hand icon.

2 Play the style and switch among the accompaniment sections as they play (page 30, 31).
Fill-in patterns play automatically between each change in the Main sections.


NOTE
You can also add a fill-in by pressing the selected MAIN button again.

END To cancel the Auto Fill, press the [AUTO FILLIN] button again.

NOTE
You can temporarily disable Auto Fill In during a performance by pressing the next Main section's button twice quickly.


The Multi Pads

The PSR-A1000 Multi Pads can be used to play a number of short pre-recorded rhythmic and melodic sequences that can be used to add impact and variety to your keyboard performances.



Playing the Multi Pads

- 1 Select the desired bank in the MULTI PAD Bank display (page 35).
- 2 Press any of the Multi Pads.



The corresponding phrase (in this case, for Pad 4) starts playing back in its entirety as soon as the pad is pressed.

The Multi Pad function provides two different ways to stop in the middle of the phrase :


- To stop all pads, press and release the [STOP] button.
- To stop specific pads, simultaneously hold down the [STOP] button and press the pad or pads you wish to stop.

NOTE

- Simply tap any of the Multi Pads at any time to play back the corresponding phrase at the currently set tempo.
- You can even play two, three, or four Multi Pads at the same time.
- Pressing the pad during its playback will stop playing and begin playing from the top again.

Chord Match

- 1 Turn ACMP on (page 57).
- 2 Play a chord with your left hand and press any of the Multi Pads.



NOTE


The Chord Match on/off status depends on the selected Multi Pad Bank.

In this example, the phrase for Pad 1 will be transposed into F major before playing back. Try playing other chords and pressing the pads. Keep in mind that you can also change chords while a pad is playing back.


Multi Pad Edit

This function lets you copy individual Multi Pad settings from one Multi Pad bank to another.

Open/Save display for Multi Pads (page 35)



Select the desired Multi Pad(s).




The same as the Open/Save display on pages 38 and 41.

Calls up the upper level directory page.

Song Playback

Here you'll learn how to play back songs. Songs include the internal songs of the instrument, performances you've recorded yourself using the recording functions (page 83), and commercially available song data. You can use this highly versatile feature in a variety of ways — playing along on the keyboard with the recorded song. You can also display the lyrics in the LCD.



Compatible Song Types



Disks having this logo mark feature song data compatible with GM (General MIDI).



Disks having this logo mark feature song data compatible with Yamaha's XG format. XG is a significant enhancement of the "GM system level 1" standard, providing more voices, greater editing control, and support for multiple effect sections and effect types.



Disks having this logo mark feature song data compatible with Yamaha's DOC (Disk Orchestra Collection) format.



Disks having this logo mark feature song data compatible with Yamaha's original MIDI file format.

NOTE

Commercially available music data is subject to copyright restrictions, and is intended only for your own personal use.

NOTE

For more information on the song file types compatible with the PSR-A1000, see page 143.

Song Playback

Playing the Internal Songs

1

BACK NEXT

TRANS-POSE UPPER OCTAVE SPLIT POINT F#2 F#2 MAIN

SONG 4/4 J=120

NewSong

GrandPiano

Lyrics BAR 001- 1 J=148 CHORD

OrchStrings

STYLE 4/4 J=148

HeartBeat

GalaxyEP

MULTI PAD

Tom Flam

NewBank

SCALE TUNE BANK

REGISTRATION BANK

INTRO ENDING

4bar2 4bar

NewBank

BALANCE

100 100 100 100 100 100

(SONG) (STYLE) (M.PAD) (LEFT) (LAYER) (MAIN)

NOTE
If the **MAIN** screen (at left) is not displayed, press the **[DIRECT ACCESS]** button followed by the **[EXIT]** button.

NOTE
You can also make a variety of other settings (such as tempo, voice selection, etc.) and have them automatically called up when you play back the song (page 95).

NOTE
You can enable the Synchro Start for the song by simultaneously pressing the **[TOP]** button and the **SONG [START/STOP]** button. The song starts as soon as you play the keyboard. You can also use this function along with the Style's Synchro Start function (page 57).

NOTE
You can have the volume automatically fade in and fade out at the beginning and end of the song. Simply press the **[FADEIN/OUT]** button at the start of song playback to fade in the song, and press it again at the end of the song to fade out.

2

2-1 Select the **PRESET** tab with the **[BACK]** button.

BACK NEXT

SONG

PRESET [PRESET] [RECALL] [F#2] [F#2]

Voice

Style

Function

SONG

P1

NEW COPY PASTE DELETE SAVE REC

2-2 Open a folder and select a song to be played back.

3 The song starts.

SONG

EXTRA TRACKS TRACK 2 TRACK 1 REPEAT METRO-NOME

(STYLE) (L) (R)

REC TOP START/STOP REW FF

NEW SONG START

Adjust the tempo by using the **TEMPO** [**◀**][**▶**] buttons (page 47) or the **[TAP TEMPO]** button. You can even change the playback speed by tapping out the tempo — simply tap the **[TAP TEMPO]** button twice.

To stop the song immediately, press the **[START/STOP]** button again.

Press the **[EXIT]** button in order to go back to the previous screen.

NOTE
Songs can also be played back continuously. Set **SONG CHAIN PLAY** to ON from the **SONG SETTING** display (page 121).

NOTE
Make sure that the Language setting for the instrument (page 135) is the same as that of the file name of the song that you are playing back.

Simultaneously Playing a Song and an Accompaniment Style

When playing back a song and an accompaniment style at the same time, channels 9 - 16 of the song data are replaced with accompaniment style channels — allowing you to use the auto accompaniment styles and features in place of the accompaniment parts of the song. Make the settings below and play your own chord substitutions in place of the song's chord data.

- [ACMP] buttonON
- [AUTO FILL IN] buttonON

- 1** Select the song and start playback by pressing the SONG [START/STOP] button.
- 2** Select the desired accompaniment style.
- 3** Start the style by pressing the STYLE [START/STOP] button.
- 4** While the song is playing, insert a break or change sections (with the STYLE section buttons.)
Fill-in patterns play when you switch sections.



The style automatically stops when the song finishes or is stopped.

NOTE


Some of the internal songs have been created using the accompaniment styles. For these songs, the accompaniment styles are automatically started when starting song playback.

NOTE

The accompaniment stops when you stop the song. If the accompaniment style is playing and you start the song, the accompaniment automatically stops. However, for internal songs that use accompaniment styles, the accompaniment style is not stopped.

Playing Back Songs on Disk


Insert the disk into the drive.



The method for playing back is the same as in the “Playing the Internal Songs” instructions (page 67), except that you should select **FLOPPY DISK** page in the **SONG** display.


Other Playback-related Operations

Repeat / Rewind / Fast forward




SONG POSITION display

When “**BAR**” is selected, you can specify a measure number (counted from the beginning of the song) by using the **[REW]** and **[FF]** buttons.
When “**PHRASE MARK**” is selected, specify the phrase mark number by using the **[REW]** and **[FF]** buttons.



“**PHRASE MARK**” is shown only when the song contains phrase marks. Press the **[J]** button to toggle between “**BAR**” and “**PHRASE MARK**,” then use the **[REW]** and **[FF]** buttons to select the desired measure or phrase mark.

Adjusting the Volume Balance / Muting Specific Channels



CHANNEL ON/OFF display



Select the **[SONG]** tab with the **[CHANNEL ON/OFF]** button, and mute the desired channel by setting it to **[OFF]**. To **solo** a channel (only that channel will sound), hold down the appropriate button corresponding to the channel. To release the solo for the channel, press that channel’s button again.

NOTE

Before proceeding, make sure to read the section “Handling the Floppy Disk Drive (FDD) and Floppy Disk” (page 7).

NOTE

You can set whether or not the PSR-A1000 automatically calls up the first disk song when a disk is inserted (page 134).

NOTE

Some song data for the PSR-A1000 has been recorded with special “free tempo” settings. During playback of such song data, the measure numbers shown in the display will not correspond to the actual measure; this only serves as a reference as to how much of the song has been played back.

NOTE

Songs containing a large amount of data may not be able to be read properly by the instrument, and as such you may not be able to select them. The maximum capacity is about 200–300KB, however this may differ depending on the data contents of each song.

NOTE

Phrase Mark

This data specifies a certain location in the song data.

NOTE

Channel

Refers to the MIDI channel in the song data. The channels are assigned as shown below for the PSR-A1000.

Song

1 - 16

Accompaniment Style


9 - 16

Muting Specific Parts — Track 1/Track 2/Extra Tracks

This feature lets you mute certain parts of the song (Track 1, Track 2, Extra Tracks), and play back only those parts you want to hear. For example, if you want to practice the melody of a song, you can mute just the right-hand part and play that part yourself.

1 Select the song to be played back (page 66).

2 Use this button to turn on/off the additional performance parts (all but the right hand/left hand).




NOTE

You can change the channel assignments for Track 1 and Track 2 (page 121), letting you specify which parts are muted when pressing the [TRACK 1]/[TRACK 2]/[EXTRA TRACKS] buttons.

NOTE

All tracks are automatically set to on when selecting a different song.

3 Start the song. Adjust the tempo by using the TEMPO [◀|▶] buttons (page 47).



To stop the song, press the



Repeat Playback of a Specific Range


This feature allows you to specify a certain range of the song (between Point A and Point B), and play it back repeatedly.

1 Play back the song (page 67, 69).

NOTE

You can also specify Points A and B when the song is stopped. Set Point A by pressing the [REPEAT] button, then use the [FF] button to move to the desired end location, then set Point B by pressing the [REPEAT] button again.

2 Press this button at the point you want the repeating phrase to start (Point A). Press this button at the point you want the repeating phrase to end (Point B).



NOTE

Point B cannot be selected unless Point A has been selected first.

NOTE

Specifying only Point A results in repeat playback between Point A and the end of the song.

NOTE

The specified A and B points will be erased when selecting a different song number, cancelling the Repeat function, or selecting a different repeat mode — such as Phrase Repeat or repeat in Song Chain Play (page 118).

3 After an automatic lead-in (to help guide you into the phrase), the range from point A to point B is played back repeatedly. Regardless of whether the song is playing back or is stopped, pressing the [TOP] button returns to point A.

4 Stop the song.




To cancel the Repeat function, press the




Displaying the Lyrics

This function lets you display the lyrics while the song is playing back — making it easy to sing along with your performance or song playback.


1 Select the desired song (page 67, 69).




3



4 Start the song.



5 The lyrics are in reverse display along with song playback.



NOTE
If the selected song does not contain lyric data, lyrics are not displayed.


NOTE
In this example, select "Lyrics" in the Function folder of the PRESET (SONG) page.

NOTE
If the selected song contains chord data, chord names are displayed with the lyrics.

NOTE
The lyrics can be changed (page 98).

Using Oriental Scales – Scale Setting/Scale Tuning/Scale Memory

The Oriental Scales feature lets you simply and easily raise or lower the pitches of specific notes and create your own scales. You can change the scale settings at any time — even when you are playing. Up to six scale settings can be stored for instant recall, whenever you need them.



Setting an Oriental Scale — Scale Setting

The [SCALE SETTING] buttons simulate an one-octave keyboard (C through B). You can easily change the scale setting at any time by pressing one of the [SCALE SETTING] buttons, located at the left side of the panel. Pressing each button turns the Scale Setting feature for the specific note on and off. The Scale Setting feature affects all the notes having the same note name in all octaves. When set to on (the selected button itself is lit), you can play the keyboard in the selected oriental scale. The scale setting for each note is -50 cents. You can also adjust the scale tuning in 1-cent units in the SCALE TUNE display.

NOTE

The [SCALE SETTING] buttons will light or go out according to the song playback data.

NOTE

The Scale Setting function has no effect on the Drum Kit/SFX Kit voices.

Adjusting the Scale Tuning — Scale Tuning

You can select a desired scale template including oriental scales and create your own scales by fine tuning the scale notes.

Press the [SCALE TUNING] button located at the right side of display to call up the SCALE TUNE display.

NOTE

The [SCALE SETTING] buttons will light when the tuning values of the corresponding notes are set to something other than "0". Also, the values you set by using the [SCALE SETTING] buttons are automatically reflected in the SCALE TUNE display.

NOTE


Cent
A unit of pitch equal to 1/100 of a semitone (100 cents = 1 semitone).

NOTE

You can register your original scale tunings to a REGISTRATION MEMORY button. To do this, checkmark "SCALE" in the REGISTRATION MEMORY display (page 76).

Selects the desired scale template. BAYAT and RAST are two typical oriental scale settings.

Determines the base note for each scale. When the base note is changed, the pitch of the keyboard is transposed, yet maintains the original pitch relationship between the notes.



Selects the note to be tuned.

When you adjust the scale tuning, the scale template name shown at the top of the display will change to "EDITED SCALE" indicating some adjustment has been done from the preset scale template.

Selects which parts should be affected by the scale setting. Select the part to be set by pressing 6 or 7 [▲/▼] and set the function ON or OFF by pressing [8▲/▼].

Adjusts the scale tuning of the selected note.
[4▲/▼]: in 50-cent steps
[5▲/▼]: in 1-cent steps (-64 through +63)

Press the 4 or 5 [▲/▼] buttons simultaneously to instantly reset the value to the factory setting.

Scale

■ Equal Temperament

The pitch range of each octave is divided equally into twelve parts, with each half-step evenly spaced in pitch. This is the most commonly used tuning in music today.

■ Bayat/Rast

Use these tunings when playing Arabic music.

■ Pure Major/Pure Minor

These tunings preserve the pure mathematical intervals of each scale, especially for triad chords (root, third, fifth). You can hear this best in actual vocal harmonies — such as choirs and acapella singing.

■ Pythagorean

This scale was devised by the famous Greek philosopher and is created from a series of perfect fifths, which are collapsed into a single octave. The 3rd in this tuning are slightly unstable, but the 4th and 5th are beautiful and suitable for some leads.

■ Mean-Tone

This scale was created as an improvement on the Pythagorean scale, by making the major third interval more “in tune.” It was especially popular from the 16th century to the 18th century. Handel, among others, used this scale.

■ Werckmeister/Kirnberger

This composite scale combines the Werckmeister and Kirnberger systems, which were themselves improvements on the mean-tone and Pythagorean scales. The main feature of this scale is that each key has its own unique character. The scale was used extensively during the time of Bach and Beethoven, and even now it is often used when performing period music on the harpsichord.

Pitch settings for each scale (in cents; example scale of C)

The values shown in this chart are actually rounded off to the nearest whole number for use on the instrument.

	C	C [#]	D	E ^b	E	F	F [#]	G	A ^b	A	B ^b	B
Equal Temperament	0	0	0	0	0	0	0	0	0	0	0	0
Bayat	0	0	-50	0	0	0	0	0	0	-50	0	0
Rast	0	0	0	0	-50	0	0	0	0	0	0	-50
Pure Major	0	-29.7	3.9	15.6	-14.1	-2.3	-9.4	2.3	-27.3	-15.6	18.0	-11.7
Pure Minor	0	33.6	3.9	15.6	-14.1	-2.3	31.3	2.3	14.1	-15.6	18.0	-11.7
Pythagorean	0	14.1	3.9	-6.3	7.8	-2.3	11.7	2.3	15.6	6.3	-3.9	10.2
Mean-Tone	0	-24.2	-7.0	10.2	-14.1	3.1	-20.3	-3.1	-27.3	-10.2	7.0	-17.2
Werckmeister	0	-10.2	-7.8	-6.3	-10.2	-2.3	-11.7	-3.9	-7.8	-11.7	-3.9	-7.8
Kirnberger	0	-10.2	-7.0	-6.3	-14.1	-2.3	-10.2	-3.1	-7.8	-10.2	-3.9	-11.7


Memorizing the Scale Setting – Scale Memory

The scale settings you set (using the [SCALE SETTING] buttons or in the SCALE TUNE display) are memorized by the Scale Memory function. Up to six scale settings can be stored for instant recall, whenever you need them.

1 Set up the scale settings as desired using the [SCALE SETTING] buttons or in the SCALE TUNE display.




2 While holding the [MEMORY] button, press one of the SCALE MEMORY [1]–[6] buttons. The corresponding SCALE MEMORY button will light. Any data that was previously in the selected location is erased and replaced by the new settings.



NOTE
The memorized scale settings here will be lost when the power is turned off, unless you perform the Save operation (see next section).

Saving Your Scale Settings

The scale settings memorized to the SCALE MEMORY [1]–[6] buttons are saved as a single file.



All settings memorized to the buttons [1]–[6] are referred to as a “bank.” The banks can be saved to “USER” or “FLOPPY DISK” as Scale Tune Bank files.



NOTE
Press the [DIRECT ACCESS] button and [EXIT] button to call up the MAIN display.

1





2 Save the settings you've made to the **SCALE MEMORY** buttons as a single Scale Tune Bank file (page 41).



The **SCALE TUNE EDIT** display appears. For details on this display, see below.

SCALE TUNE EDIT display

The contents of the current Scale Tune Bank are listed in the **SCALE TUNE EDIT** screen. The names of the stored Scale Settings are shown in the display.

From this screen, you can select, name, or delete each of the Scale Settings.

Select.... Press the [A]–[C]/[F]–[H] buttons. The **SCALE TUNE EDIT** display is linked to the **SCALE MEMORY [1]–[6]** buttons. When you select the Scale Settings in the display, the corresponding **SCALE MEMORY** button lights.

Name This operation is the same as that in “Naming Files and Folders” (page 38) in “Basic Operations — Organizing Your Data.”

Delete.... This operation is the same as that in “Deleting Files/Folders” (page 40) in “Basic Operations — Organizing Your Data.”

NOTE

The result of the Name/Delete operation will be lost when the power is turned off unless you return to the **SCALE TUNE BANK** display by pressing the [8] (▲) button and save the data (page 41).

Recalling the Scale Setting

To recall the memorized scale settings, select the desired bank in the **SCALE TUNE BANK** display (page 72). Press the appropriate **SCALE MEMORY [1]–[6]** button to which you memorized the setting. The corresponding **SCALE MEMORY** button will light.


The Scale Memory function can be turned off by pressing the **SCALE MEMORY** button which is currently lit, so that the light goes out. The default Equal Temperament Scale settings (pitch settings for all notes are “0” will be restored.

NOTE

If you press a **SCALE MEMORY** button to which nothing is memorized, the current scale settings remain and nothing changes.

Saving and Recalling Custom Panel Setups — Registration Memory

Registration Memory is a powerful feature that lets you set up the PSR-A1000 just as you want — selecting specific voices, styles, effect settings etc. — and save your custom panel setup for future recall. Then, when you need those settings, simply press the appropriate REGISTRATION MEMORY button.



Registering Panel Setups — Registration Memory

This shows you how to register your custom panel settings to the REGISTRATION MEMORY buttons. Make all the settings you want with the panel controls, and Registration Memory will “remember” them for you.

1 Set up the panel controls as desired.
For a list of the settings that can be registered, refer to the separate Data List (Parameter Chart).

NOTE
Keep in mind that songs or styles on disk cannot be registered to Registration Memory. If you want to register a disk-based song or style, copy the relevant data to “USER” in the SONG/STYLE display (page 35) and register the data separately.

2

3

Select the desired parameter groups for the settings you want to register. You can also use the [DATA ENTRY] dial to navigate in this display. To register a parameter group, checkmark the corresponding box. Groups left without checkmarks will not be included in the Registration Memory setting. This allows you to maintain certain settings, even when switching among Registration Memory presets. You can also use the Freeze function (page 78) to override the Registration Memory changes — letting you prevent certain panel settings from being changed.

Cancel — Cancels the registration and returns to the MAIN display. You can also use the [EXIT] button.

MARK — Enters a checkmark to the selected box. You can also use the [ENTER] button.

REMOVE — Removes the checkmark from the selected box. You can also use the [ENTER] button.

END Press the desired number button for registering the settings.


NOTE
Any data that was previously registered to the selected REGISTRATION MEMORY button (indicator is green or red) will be erased and replaced by the new settings.

Indicator is green The panel setting is registered, but not selected.
Indicator is red The panel setting is registered and is currently selected.
Indicator is off The panel setting is not registered.

NOTE
The registrations registered here will be lost when the power is turned off, unless you perform the Save operation explained on the next page.


Saving Your Registration Memory Setups

The settings registered to the **REGISTRATION MEMORY [1]-[8]** buttons are saved as a single file.




All settings registered to buttons [1]-[8] are referred to as a “bank.” The banks can be saved to “USER” or “FLOPPY DISK” as Registration bank files.

NOTE
Keep in mind that the size of the Registration bank files and the memory space they occupy depends on the amount of functions set in each.



NOTE
Press the **[DIRECT ACCESS]** button and **[EXIT]** button to call up the MAIN display.



2 Save the settings you’ve made to the Registration Memory buttons as a single Registration bank file (page 41).

The **REGISTRATION EDIT** display appears. For details on this display, see below.

REGISTRATION EDIT display

The contents of the current Registration Memory bank (REGIST.) are listed in the **REGISTRATION EDIT** screen. The names of the stored Registration Memory presets are shown in the display and the indicators of the relevant REGISTRATION MEMORY buttons are lit in green.

From this screen, you can select, name, or delete the Registration Memory presets.

Select Press the **[A] - [J]** buttons. The REGIST. display is linked to the REGISTRATION MEMORY **[1] - [8]** buttons. When you select the Registration Memory preset in the display, the related button turns on (indicator is red).

Name This operation is the same as that in “Naming Files and Folders” (page 38) in “Basic Operations — Organizing Your Data.”

Delete This operation is the same as that in “Deleting Files/Folders” (page 40) in “Basic Operations — Organizing Your Data.”

NOTE


The result of the Name/Delete operation will be lost when the power is turned off unless you return to the REGISTRATION BANK display by pressing the **[8▼]** (UP) button and save the data (page 41).

Recalling a Registration Memory Setup

You can recall all of the panel settings you've made — or only those you specifically want or need. For example, if you de-select "STYLE" in the **REGISTRATION MEMORY** display, you can keep the currently selected style even when you change the Registration Memory preset.

Recalling the Registered Settings

Select the desired bank in the **REGISTRATION BANK** display (page 77). Press the appropriate **REGISTRATION MEMORY** button (any whose indicators are green) to recall the desired settings.



NOTE

You can program your Registration Memory presets to be called up in sequence, in any order you desire. Once programmed, the presets 1 - 8 can be selected in sequence with the **[BACK][NEXT]** buttons or the pedal (page 126).

Selecting the Freeze Settings

1 Call up the "FREEZE" page from the **REGIST.SEQUENCE/FREEZE/VOICE SET** screen (page 126).

2

REGIST. SEQUENCE / FREEZE / VOICE SET

REGISTRATION SEQUENCE FREEZE VOICE SET

Mark the group(s) that you want to remain unchanged, even when a Registration Memory is selected.

FREEZE GROUP SETTING


GROUP SELECT		MARK
<input checked="" type="checkbox"/> STYLE	<input type="checkbox"/> HARMONY	<input checked="" type="checkbox"/>
<input type="checkbox"/> VOICE	<input checked="" type="checkbox"/> TEMPO	<input type="checkbox"/> ON
<input type="checkbox"/> TUNE TRANS	<input type="checkbox"/> PEDAL	<input type="checkbox"/> OFF
<input type="checkbox"/> SCALE	<input checked="" type="checkbox"/> MULTI PAD	

3 Press the **[FREEZE]** button. When Freeze is active (lamp is lit), the settings you specified in the Freeze page will be maintained or left unchanged, even when changing Registration Memory presets.

4 Press the appropriate **REGISTRATION MEMORY** button (any whose indicators are green) to recall the desired settings.

Editing Voices — Sound Creator

The PSR-A1000 has a Sound Creator feature that allows you to create your own voices by editing some parameters of the existing voices. Once you've created a voice, you can save it as a USER voice for future recall.




NOTE

- The Voice can be edited in realtime while playing back a song/style.
- Keep in mind that adjustments made to the parameters may not make much change in the actual sound depending on the original settings of the voice.

Operation

- 1 Press the [F], [G] or [H] button to select the Part (MAIN, LAYER or LEFT) containing the voice you wish to edit.



- 2 Press the [SOUND CREATOR] button.



NOTE

The voice can also be selected in the SOUND CREATOR display.

CAUTION

The settings are lost if the edited part's voice is switched to another voice. Important data should be saved to User Drive or floppy disk.

- 3 Edit the voice parameters.

The operations for each function selected in this step are covered in detail starting on page 81.

Select the desired menu by pressing the [NEXT]/[BACK] button.

Indicates the parameters available for editing in this display. These correspond to the parameters/values shown at the bottom of the display.

Can be used during editing to compare the sound of the original voice with the edited voice.

Select the desired menu. The selected menu is highlighted.

Opens the Save (Voice) display for saving the edited voice as a User voice (page 41).

- 4 Save the edited voice to the USER drive (Flash ROM) as a USER voice (page 41).

- 5 Press the [USER] button to select the edited voice, and play the keyboard.

Sound Creator Parameters

COMMON	Determines the common settings such as voice volume or octave.
SOUND	Determines the timbre/EG (Envelope Generator)/vibrato of the voice.
EFFECT	Determines the effect depth/type and equalizer settings.
HARMONY	Determines the Harmony/Echo settings.


NOTE
Keep in mind that there are certain parameters whose Sound Creator settings affect only the Main part's voice.

The following parameters are linked to the ones in each display.

Common parameter	Other location	
MONO	VOICE EFFECT (TOP PANEL)	page 55
PORTAMENTO TIME	MIXING CONSOLE	page 114
FILTER BRIGHTNESS	MIXING CONSOLE	page 114
FILTER HARMONIC CONTENT	MIXING CONSOLE	page 114
REVERB DEPTH	MIXING CONSOLE	page 115
CHORUS DEPTH	MIXING CONSOLE	page 115
DSP ON/OFF	VOICE EFFECT (TOP PANEL)	page 54
DSP DEPTH	MIXING CONSOLE	page 115
DSP TYPE/VARIATION	MIXING CONSOLE/VOICE EFFECT (TOP PANEL)	page 55,115
HARMONY/ECHO TYPE	HARMONY/ECHO (FUNCTION)	page 127
HARMONY/ECHO VOLUME	HARMONY/ECHO (FUNCTION)	page 127
HARMONY/ECHO SPEED	HARMONY/ECHO (FUNCTION)	page 127
HARMONY/ECHO ASSIGN	HARMONY/ECHO (FUNCTION)	page 127
HARMONY/ECHO CHORD NOTE ONLY	HARMONY/ECHO (FUNCTION)	page 127
HARMONY/ECHO TOUCH LIMIT	HARMONY/ECHO (FUNCTION)	page 127

COMMON

The explanations here apply to step #3 on page 79.



Set the volume of the current edited voice.

Determines the touch sensitivity, or how greatly the volume responds to your playing strength.
 0 — Produces more dramatic level drops, the more softly you play.
 64 — Normal response.
 127 — Produces high volume for any playing strength (fixed)



Set the portamento time of each part (MAIN/LAYER/VOICE) (page 114).

This determines whether the voice is played monophonically (page 55).

Shift the octave range of the selected voice up or down in octaves. When the Main or Layer part's voice is used, the M/LYR parameter is available; when the Left part's voice is used, the LEFT parameter is available.

SOUND

The explanations here apply to step #3 on page 79.




Determines the filter, EG, and vibrato settings (see below).

■ FILTER

FILTER settings determine the overall timbre of the sound by boosting or cutting a certain frequency range.

• BRIGHTNESS


Determines the cutoff frequency or effective frequency (resonance) range of the filter (see diagram). Higher values result in a brighter sound.



NOTE
In addition to making the sound either brighter or more mellow, Filter can be used to produce electronic, synthesizer-like effects.

• Harmonic Content


Determines the emphasis given to the cutoff frequency, set in BRIGHTNESS above (see diagram). Higher values result in a more pronounced effect.



■ EG

The EG (Envelope Generator) settings determine how the level of the sound changes in time. This lets you reproduce many sound characteristics of natural acoustic instruments — such as the quick attack and decay of percussion sounds, or the long release of a sustained piano tone.

- **ATTACK**..... Determines how quickly the sound reaches its maximum level after the key is played. The higher the value, the slower the attack.
- **DECAY**..... Determines how quickly the sound reaches its sustain level (a slightly lower level than maximum). The higher the value, the slower the decay.




- **RELEASE** Determines how quickly the sound decays to silence after the key is released. The higher the value, the slower the release.

NOTE
If RELEASE is set to a large value, the sustain becomes long.

■ VIBRATO

- **DEPTH**..... Determines the intensity of the Vibrato effect (see diagram). Higher settings result in a more pronounced Vibrato.
- **SPEED**..... Determines the speed of the Vibrato effect (see diagram).
- **DELAY** Determines the amount of time that elapses between the playing of a key and the start of the Vibrato effect (see diagram). Higher settings increase the delay of the Vibrato onset.


NOTE
VIBRATO
 Creates a wavering in the sound by periodically changing the pitch.




EFFECT

The explanations here apply to step #3 on page 79.

Determines the DSP type.
 For information on the effect structure, see page 117; for a list of available effect types, refer to the separate Data List.




The same as the "Mixing Console" on page 115.



Determines the Sustain depth of each voice when the [SUSTAIN] button is set to on.

HARMONY

The explanations here apply to step #3 on page 79.




The parameters are the same as for HARMONY/ECHO display of FUNCTION. For details, see page 128.

Recording Your Performances and Creating Songs

— Song Creator

With these powerful yet easy-to-use song creating features, you can record your own keyboard performances and store them for future recall. Several different recording methods are available: Quick Recording (page 84), which lets you record easily and quickly; Multi Recording (page 85), which lets you record several different parts; and Step Recording (page 87), which lets you enter notes one by one. Songs can include not only the voice settings for the keyboard performance (Main, Layer, Left), but also the effects and auto accompaniment parts. The recorded song can be stored to internal memory or floppy disk (page 35, 41).



About Song Recording

■ Quick Recording (page 84)

This is the easiest recording method, and lets you quickly record the piano song you are practicing. You can select from four parts: right hand, left hand and auto accompaniment/multi pad. For example, you can record only your right hand performance, or you can simultaneously record both your right hand and the auto accompaniment.

■ Multi Recording (page 85)

This lets you record a song with several different instrument sounds, and create the sound of a full band or orchestra. Record the performance of each instrument individually and create fully orchestrated compositions. You can also record over an existing part on an internal song or a song on disk with your own performance.

■ Step Recording (page 87)

This method is like writing music notation on paper. It lets you enter each note individually, by specifying the pitch and length. This is ideal for making precise recordings, or for recording parts that are difficult to play.

■ Song Editing (page 93)

The PSR-A1000 also lets you edit the songs you've recorded by the Quick Recording, Multi Recording and Step Recording methods.

NOTE


- The internal memory capacity of the PSR-A1000 is about 260KB. Memory capacity for 2DD and 2HD floppy disks is about 720KB and 1.44MB, respectively. When you store data to these locations, all file types of the PSR-A1000 (Voice, Style, Song, Registration, etc.) are stored together.
- Songs recorded on the PSR-A1000 are automatically recorded as SMF (Standard MIDI File format 0) data. For details on SMF, see page 143.
- Playback of the recorded song data can be transmitted from MIDI OUT, letting you play the sounds of a connected external tone generator (page 130).
- The volume level of each channel of the song can be adjusted from the Mixing Console and the settings can be saved. Moreover, even after you've set a voice for your keyboard play during recording, you can record voice selections, so that the voice changes automatically during playback (page 95).

Quick Recording

This is the easiest recording method — perfect for quickly recording and playing back a piano song you're practicing, so you can check your progress.

■ When creating a new song:

1



■ When recording over the part of an internal song or a song on disk with your own performance:

1 Select the desired song (page 67, 69).

2 Select the voice and accompaniment style you want to use in the song.

If you want to record to the MAIN/Layer/Left voices, make sure to set the [MAIN]/[LAYER]/[LEFT] buttons to ON. Make any other desired settings (Reverb, Chorus, etc.) as well.

3 Simultaneously hold down the [REC] button and press the button corresponding to the track you want to record.

You can select TRACK 1 or TRACK 2 and the EXTRA TRACKS for recording at the same time.


To record your keyboard performance:

Press either the [TRACK 1] or [TRACK 2] button.

To record the auto accompaniment and multi pad performance:

Press the [EXTRA TRACKS] button.

To stop recording, press the [REC] button again.



NOTE

If the "LAYER" or "LEFT" button is on before pressing the REC button, the corresponding Layer and Left parts are automatically recorded to different channels.

NOTE

The performance of track 1/2 is recorded to the channel specified in the SONG SETTING display (page 121).

NOTE

You can overdub a second right-hand performance onto Track 2 after recording the first right-hand performance (including the layer voices) on Track 1. To do this, set the [LEFT] button to OFF and repeat steps 2 and 3.

NOTE

To pause, press the SONG [START/STOP] button. To resume recording, press the SONG [START/STOP] button again.

NOTE

You can also use the metronome click as a guide while recording. The sound of the metronome is not recorded.

4 Recording starts as soon as you play the keyboard.

You can also start recording by pressing the SONG/STYLE [START/STOP] button. Recording can also be started by pressing down the foot pedal, if the song start/stop function is properly assigned to the pedal (page 123).



To stop recording, press the [RECORD] button again.

Recording can also be stopped by pressing down the foot pedal, if the song start/stop function is properly assigned to the pedal (page 123).

■ Play back your new song

To play back the performance you just recorded, return the song to the beginning by using the [TOP] button and press the SONG [START/STOP] button.

Playback stops automatically at the end of the song, and returns to the beginning of the song.

You can edit the recorded song data from the SONG CREATOR (1 - 16) displays (page 96).

Press the [6▼] button from the Open/Save display for Song to store the recorded data (page 35, 41).

CAUTION

Turning off the power automatically deletes your recorded performance. If you wish to save the recording, make sure to store it to internal memory (USER drive) or floppy disk (page 35, 41).

Multi Recording

This lets you record a song with several different instrument sounds on up to sixteen channels, and create the sound of a full band or orchestra.

The structure of the channels and parts are shown in the chart below.

Channels	Parts (default settings)	Available parts	Channels	Parts (default settings)	Available parts
1	Voice MAIN	Voice MAIN, LAYER, LEFT Multi Pad1 Multi Pad2 Multi Pad3 Multi Pad4 Accompaniment style RHYTHM 1 Accompaniment style RHYTHM 2 Accompaniment style BASS Accompaniment style CHORD1 Accompaniment style CHORD2 Accompaniment style PAD Accompaniment style PHRASE1 Accompaniment style PHRASE2 MIDI	9	Accompaniment style RHYTHM 1	Voice MAIN, LAYER, LEFT Multi Pad1 Multi Pad2 Multi Pad3 Multi Pad4 Accompaniment style RHYTHM 1 Accompaniment style RHYTHM 2 Accompaniment style BASS Accompaniment style CHORD1 Accompaniment style CHORD2 Accompaniment style PAD Accompaniment style PHRASE1 Accompaniment style PHRASE2 MIDI
2	Voice MAIN		10	Accompaniment style RHYTHM 2	
3	Voice MAIN		11	Accompaniment style BASS	
4	Voice MAIN		12	Accompaniment style CHORD1	
5	Voice MAIN		13	Accompaniment style CHORD2	
6	Voice MAIN		14	Accompaniment style PAD	
7	Voice MAIN		15	Accompaniment style PHRASE1	
8	Voice MAIN		16	Accompaniment style PHRASE2	

About the accompaniment style parts

Rhythm This is the basis for the accompaniment, containing the drum and percussion rhythm patterns. Usually one of the drum kits is used.


Bass The Bass part uses various appropriate instrument sounds to match the style, such as acoustic bass, synth bass, and others.

Chord This is the rhythmic chord backing, commonly used with piano or guitar voices.


Pad This part features sustained chords and commonly uses lush sounds such as strings, organ, and choir.

Phrase This part is used for various embellishments and riffs that enhance the song, such as brass section accents and chord arpeggios.

■ When creating a new song:



■ When recording over the part of an internal song or a song on disk with your own performance:



2 Select the desired channel for recording (set it to "REC") simultaneously holding down the [REC] button and pressing the appropriate button [1▲▼] - [8▲▼]. Several channels can be selected at the same time.

REC..... Enables recording for the channel
ON Enables playback of the channel
OFF..... Mutes the channel


To cancel or disable recording, press the [REC] button once again.

NOTE
The part is automatically selected when setting the several channels to "REC" at the same time.

3 Select the part you want to assign to the channel to be recorded.

This determines which of the keyboard-played parts (Main/Layer/Left) and the accompaniment style parts (RHYTHM 1/2, BASS, etc.) are recorded to the recording channels selected in step #2.

For a list of the initial default assignments, see page 85.



4 Recording starts as soon as you play the keyboard.

You can also start recording by pressing the SONG/STYLE [START/STOP] button. The recording can be started/stopped by pressing the foot pedal if the recording punch in/out function is set to the pedal (page 92).



5 To stop recording, press the [REC] button again.

You can also use the foot pedal to stop recording by releasing it, if the recording punch in/out function has been assigned to the pedal (page 92).



6 Play back your new song.

To play back the performance you just recorded, return the song to the beginning by using the [TOP] button and press the SONG [START/STOP] button.

Playback stops automatically at the end of the song, and returns to the beginning of the song.



To record a new part, repeat steps 2 - 6 above.

You can set previously recorded parts to play back, and monitor them while you record a new part. Continue in this way until you have a finished song.

You can edit the recorded song data from the SONG CREATOR (1 - 16) displays (page 96).

Press the [6▼] button from the Open/Save display for Song to store the recorded data (page 35, 41).

NOTE

When selecting the MIDI part

• Setting a single channel to MIDI

All incoming data received via any of the MIDI channels 1 - 16 is recorded. When using an external MIDI keyboard or controller to record, this lets you record without having to set the MIDI transmit channel on the external device.

• Setting several channels to MIDI

When using an external MIDI keyboard or controller to record, this records data only over the set MIDI channel — meaning the external device must also be set to the same channel.

NOTE

A single part (with the exception of MIDI parts) cannot be assigned to several channels.

NOTE

The settings of the recorded parts is stored temporarily until you execute Quick Recording, select a song, or turn the power off.

NOTE

To pause, press the SONG [START/STOP] button. To resume recording, press the SONG [START/STOP] button again.

NOTE

You can also use the metronome click as a guide while recording. The sound of the metronome is not recorded.



CAUTION

Turning off the power automatically deletes your recorded performance. If you wish to save the recording, make sure to store it to internal memory (USER drive) or floppy disk (page 35, 41).

Recording Individual Notes — Step Record

This method lets you create a song by entering notes one by one, without having to perform them in real time. This is also convenient for recording the chords and the melody separately.

Operation


1 Select an existing song (page 67, 69) to which you want to add parts or re-record. If you want to create a new song, simultaneously press the [RECORD] button and the [TOP] button.




2 Press the [DIGITAL RECORDING] button.




3 Press the [A] button to call up the Song Creator display.



4 Using the [BACK]/[NEXT] buttons, select the “1 -16” tab for recording melodies and other parts, or select the “CHD” (Chord) tab for recording chords, and after selecting the “1 - 16” tab, select a record channel with the [F] (CH) button.



5 Call up the Step Record display by pressing the [G] button.



NOTE
Any voice, effect and other settings you make in the Mixing Console are automatically cancelled when you call up the CHD (Chord) page.

NOTE
The voices in the USER and FLOPPY DISK pages cannot be selected for Step recording. You can select voices from the PRESET page; however, these may sound slightly different from the original voice.



6 First, select the desired voice. To enter the note, first specify the length and loudness in this display, then enter the pitch by actually playing the note on the keyboard.

Moves the cursor position up and down.

Returns the cursor to the beginning of the song (the first note of the first measure).

Use these to move the selected event, in units of measures (BAR), beat, and clocks. For information on measure/beat/clock settings, see below.

Specifies the type of note to be input next. (Sixteenth notes are available only when recording the melody.) This also determines the position to which the pointer will advance after a note has been entered.

Determines the velocity (loudness) of the note to be entered (only when recording the melody). For information on velocity settings, see below.

Determines the length of the note (as a percentage) from the position at which it is to be entered. (This is available only when recording the melody.) For information on gate time settings, see below.


Each press of this button toggles among the three basic note selectors at the bottom of the display: normal, dotted, and triplet. (This is available only when recording the melody.)

Deletes the event at the cursor.



To close the STEP RECORD display, press the [EXIT] button. Make sure to store the recorded data by pressing the [I] (SAVE) button (page 41).

■ Measure/Beat/Clock



■ Velocity

The table below shows the available settings and the corresponding velocity values.

Kbd. Vel	fff	ff	f	mf	mp	p	pp	ppp
Actual playing strength	127	111	95	79	63	47	31	15

■ Gate Time

The following settings are available:

- Normal 80%
- Tenuto 99%
- Staccato 40%
- Staccatissimo 20%

Manual The gate time (note length) can be specified as a percentage by using the [DATA ENTRY] dial.

Recording Melodies — Step Record (Note)

In this section, we'll show you how to use Step Recording by guiding you through this actual music example, shown at right.

The operations here apply to step 6 on page 88.



1

1-1 Select this note.

1-2 While holding down this note...

1-3 ...press this (to input a tie).

2

2-1 Select this note.

2-2

2-3

2-4

3

3-1 Press this button to display the dotted notes.

3-2 Select this note.

3-3

4

4-1 Call up the normal notes by pressing this button.

4-2 Select this note.

4-3

NOTE

To input rests, simply move the measure/beat/clock location for the desired rest time, then input the next note.

■ Play back the newly created melody


Use the [C] (▲) button to move the cursor to the beginning of the song, and press the SONG [START/STOP] button to hear the newly entered notes. To actually enter the recorded data, press the [EXIT] button. The entered data can be edited from the SONG CREATOR (1 - 16) display (page 96).

Recording Chord Changes for the Auto Accompaniment — Step Record (Chord)

The Chord Step recording feature makes it possible to record auto accompaniment chord changes one at a time with precise timing. Since the changes don't have to be played in real time, you can easily create complex, tight chord changes — over which you can record the melody in normal fashion. The operations here apply to step 6 on page 88.


Entering Chords and Sections (Chord Step)

For example, you can input the following chord progression by the procedure described below.




NOTE
Enter the chords by using the currently selected chord fingering method in the Auto Accompaniment area of the keyboard.



1 Press the MAIN [A] button to specify the section, and enter the chords as shown at right.




Select this note value and play the chords indicated at right.




2 Press the [BREAK] button to specify the Break section, and enter the chords as shown at right.



Select this note value and play the chords indicated at right.




3 Press the MAIN [B] button to specify the section and enter the chord indicated at right.



SONG CREATOR : NewSong			
STEP RECORD			
4/4	2PPQ		
001:1:0000	Sty	8BeatModern	
001:1:0000	Sect	M	A Main A : 2
001:1:0000	Chord	C	Maj
001:1:0000	Tempo		92
001:3:0000	Chord	F	Maj
002:1:0000	Chord	G	Maj
002:3:0000	Chord		Maj
002:3:0000	Sect	F	Br Break : 1
002:4:0000	Chord	G	7
003:1:0000	Chord	C	Maj
003:1:0000	Sect	M	B Main B : 2
005:1:0000	End		

BAR : BEAT : CLK
003 2 0000



Select this note value and play the chords indicated at right.

■ Play back the newly created chord progression

Use the [C] (▲) button to move the cursor to the beginning of the song, and press the SONG [START/STOP] button to hear the newly entered notes. To actually enter the recorded data, press the [EXIT] button. The entered data can be edited from the SONG CREATOR (CHD) display (page 97). Finally, press the [F] (EXPAND) button from the SONG CREATOR (CHD) display in order to convert the input data into song data.

NOTE

To enter a fill-in, press the [AUTO FILL IN] button and press one of the MAIN [A]–[D] buttons.

NOTE

END Mark

An “END” mark is shown in the display, indicating the end of the song data.

The actual position of the End mark differs depending on the section that is input at the end of the song. When an Ending section is input, the End mark automatically follows the Ending data. When a section other than Ending is input, the End mark is set two measures after the final section.

The End mark can be freely set to any position desired.

Select the Recording Options: Starting, Stopping, Punching In/Out — Rec Mode

From this display you can set up how recording is started and stopped for either Quick Recording or Multi Recording. To call up these settings, select the REC MODE display by using the [BACK][NEXT] button, after performing operation steps 1 - 3 on page 87.

These settings determine how recording will start.

Normal

Pressing the SONG [START/STOP] button enables Synchro standby and overwrite recording starts as soon as you start playing the keyboard.



First Key On

Overwrite recording starts as soon as you start playing the keyboard. This setting also preserves the previous lead-in data, letting you record over the original lead-in without erasing it.

Punch In At


The song plays back normally up to the indicated Punch In measure (set by the [3▲▼] buttons), then starts overwrite recording at that Punch In measure.

Determines the measure at which Punch In overwrite recording starts (when "PUNCH IN AT" is selected).



Calls up the SONG display, from which you can save the edited data.

Determines the Punch Out measure — the measure at which Punch In overwrite recording stops (when "PUNCH OUT AT" is selected).



These settings determine how recording will stop as well as what happens to previously recorded data.

When this is set to ON, you can use the foot pedal 2 to control the punch-in and punch-out points. (The current function assignment of the foot pedal is cancelled.) Press and hold down the foot pedal to record. Recording stops when you release the pedal.

Replace All

This deletes all data following the point at which recording is stopped.

Punch Out


This maintains all data following the point at which recording is stopped.

Punch Out At

Overwrite recording continues until the indicated Punch Out measure (set by the [6▲▼] buttons), then stops at that Punch Out measure, after which song playback continues normally.

About Punch In/Out

This feature is useful primarily for re-recording or replacing a specific section of an already recorded channel. The illustrations below indicate a variety of situations in which selected measures in an eight-measure phrase are re-recorded.



*1 When measures 1 - 2 are not overwritten, recording starts from measure 3.

*2 You'll have to press the [REC] button at the end of 5 measures.

Legend:
 [Dark Grey Box] Previously recorded data
 [Light Grey Box] Newly recorded data
 [White Box] Deleted data

Editing a Recorded Song

Whether you've recorded a song using Quick Recording, Multi Recording, or Step Recording, you can use the editing features to change the song data.

Editing Channel-related Parameters — Channel

Calling up the operations here apply to step 4 on page 87. To call up the display shown below, use the [BACK]/[NEXT] buttons.

Quantize

Quantize lets you “clean up” or tighten the timing of a previously recorded channel. For example, the following musical passage has been written with exact quarter-note and eighth-note values.



Even though you think you may have recorded the passage accurately, your actual performance may be slightly ahead of or behind the beat. Quantize allows you to align all the notes in a channel so that the timing is absolutely accurate to the specified note value (see below).

Use this to select the desired edit operation.

Executes the Quantize operation. After the operation is completed, this button changes to [UNDO], letting you restore the original data if you're not satisfied with the Quantize results. The Undo function only has one level; only the previous operation can be undone.

Selects the desired channel to be quantized.

Calls up the **SONG** display, from which you can save the edited data.

Determines how strongly the notes will be quantized. If a value less than 100% is selected, notes will be moved toward the specified quantization beats only by the specified amount. Applying less than 100% quantization lets you preserve some of the “human” feel in the recording.

Selects the quantize size (resolution). See the below for the details.

■ About Quantize Size

Set the Quantize size to correspond to the smallest notes in the channel you are working with. For example, if the data was recorded with both quarter notes and eighth notes, use 1/8 note for the Quantize size. If you apply a 1/4 note Quantize size, the eighth notes would be moved on top of the quarter notes.


One measure of eighth notes before quantization



After 1/8 note quantization



Quantize Size



The three Quantize settings marked with asterisks (*) are exceptionally convenient, since they allow you to quantize two different note values at the same time, without compromising the quantization of either one. For example, if you have both straight 1/8 notes and 1/8 note triplets recorded to the same channel, and you quantize to straight 1/8 notes, all notes in the channel are quantized to straight 1/8 notes — completely eliminating any triplet feel in the rhythm. However, if you use the 1/8 note + 1/8 note triplet setting, both the straight and triplet notes will be quantized correctly.

Delete

This lets you delete recorded data in the specified channel.

Use these to select the desired edit operation.

Deletes all data in the selected channel. After the operation is completed, this button changes to [UNDO], letting you restore the original data. The Undo function only has one level; only the previous operation can be undone.

These select the channel to be deleted.

Calls up the **SONG** display, from which you can save the edited data.

Mix

This function lets you mix the data of two channels and place the results in a different channel. It also lets you copy the data from one channel to another.

Use these to select the desired edit operation.

Executes the Mix operation. After the operation is completed, this button changes to [UNDO], letting you restore the original data if you're not satisfied with the Mix results. The Undo function only has one level; only the previous operation can be undone.

These let you specify the two source channels to be mixed.

Determines the channel into which the mix or copy results will be placed.

If "COPY" is selected here, the data from Source 1 is copied to the Destination channel.

NOTE

All data other than the mixed note data is derived from the Source 1 channel.

Calls up the **SONG** display, from which you can save the edited data.

Channel Transpose

This allows you to transpose the recorded data of individual channels up or down by a maximum of two octaves in semitone increments.

Use these to select the desired edit operation.

Executes the Channel Transpose operation. After the operation is completed, this button changes to [UNDO], letting you restore the original data if you're not satisfied with the Channel Transpose results. The Undo function only has one level; only the previous operation can be undone.

Toggles between the two channel displays: Channels 1 - 8, and Channels 9 - 16.

To simultaneously set all channels to the same value, adjust the Channel Transpose for one of the channels while holding down this button.

Calls up the **SONG** display, from which you can save the edited data.

Determines the amount of Channel Transpose for each channel.

Set Up

You can change the initial settings of the song — such as voice, level, and tempo — to the current settings of the mixing console or panel controls.

Use these to select the desired edit operation.

Executes the SET UP operation. Once SET UP has been executed, the operation cannot be cancelled or undone.

Calls up the **SONG** display, from which you can save the edited data.

Use this to checkmark the selected item. Checkmarked items are stored with the song.

Determines which playback features and functions will be automatically called up along with the selected song. All events, with the exception of "KEYBOARD VOICE," can be recorded only at the beginning of the song.

Before you select or checkmark any of these items (other than Keyboard Voice), make sure to return the song to the beginning by using the [TOP] button, and stop playback.

Song Stores the tempo setting and all settings made from the Mixing Console.

Keyboard Voice..... This lets you automatically set the voice of the keyboard-played parts (Main/Layer/Left) when playing back the song. Stores the keyboard-played voice and the part ON/OFF settings. To record a voice change for the keyboard-played part in the middle of a song, stop the song at the desired point, make the voice change, and press the [D] (EXECUTE) button.

Editing Note Events — 1 - 16

From this display, you can edit individual note events (see below). Calling up operations here apply to step 4 on page 87. Use the [BACK]/[NEXT] buttons to call up the display below.

Use these to move the cursor up/down and select the desired event.

Returns to the beginning position of the current song (the first note of the first measure).

Use these to move the cursor left/right and select the desired parameter of the highlighted event. Keep in mind that moving the cursor away from the just-edited value automatically enters that value.




Determines the current position of the event being edited.

For coarse adjustment of the event value.

For fine adjustment of the event value.

Cuts (deletes) all selected events. The cut events are copied and can be pasted to another location.

Adds a new event to the Event List.



Determines the channel to be edited.

Calls up the **Step Recording** display (page 88).

Calls up the **Filter** display (page 98), letting you select only the events you wish to shown in the Event List.

Calls up the **SONG** display, from which you can save the edited data.

Holding this button down while using the [A] and [B] buttons lets you select multiple events.

Pastes all cut or copied events to the selected location.

If the value at the cursor has been changed, pressing this restores the original value.

Copies all selected events. The copied events can be pasted to another location.

Deletes the event at the cursor position.

NOTE

To actually enter an edited value, move the cursor away from the value or press the SONG [START/STOP] button.

Note Events

Parameter	Description
Note	Determines the pitch, velocity (volume) and length of the note.
Ctrl (Control change)	Determines the control change number and value. For details on control change messages, refer to the separate Data List booklet (MIDI Data Format).
Prog (Program change)	Determines the voice (program) number. For details on program change messages and how to set them, refer to the separate Data List booklet (Voice List).
P.Bnd (Pitch bend)	Determines the pitch bend value.
A.T. (After touch)	Determines the after touch value.

NOTE

The sound of the voices recorded with Step recording may sound slightly different from the original.

Editing Chord Events — CHD

From this display, you can edit the chord events you've recorded to the song. Calling up operations here apply to step 4 on page 87. Use the [BACK]/[NEXT] buttons to call up the display below. With the exception of the [F] (EXPAND) button, the operations here are the same as those in Editing Note Events (page 96).

Press this to convert the recorded chord and section entries into song data.

NOTE
To actually enter an edited value, move the cursor away from the value or press the SONG [START/STOP] button.

Chord Events

Parameter	Description
Style (Accompaniment style)	Displays the accompaniment style name. To enter an accompaniment style, call up the STYLE display and select the desired style.
Tempo	Determines the tempo value.
Chord	Specifies the chord — its root note, chord type, and on-bass note.
Sect (Section)	Specifies the section — its name and variation.
OnOff (Channel on/off)	Determines whether specific channels (rhythm, bass, etc.) are turned on/off.
CH.Vol (Channel volume)	Determines the level of specific channels (rhythm, bass, etc.).
S.Vol (Style volume)	Determines the level of the entire accompaniment style.

Editing System Events — SYS/EX. (System Exclusive)

From this display, you can edit recorded System events. Calling up operations here apply to step 4 on page 87. Use the [BACK]/[NEXT] buttons to call up the display below. The operations here are the same as those in Editing Note Events (page 96).

System Events

Parameter	Description
ScBar (Score initial measure)	This determines the number of the top measure. The measure number is indicated in the MAIN display. Only one value can be specified at the beginning of the song data.
Tempo	Determines the tempo value.
Time (Time signature)	Determines the time signature.
Key	Determines the key, as well as the major/minor setting.
XG Prm (XG parameters)	Allows you to make various detailed changes to the data. For more information on XG parameters, refer to the separate Data List booklet (MIDI Data Format).
SYS/EX. (System Exclusive)	Displays the System Exclusive data in the song. This does not let you change the actual contents of the data; however, it lets you delete, cut, copy, and paste the data.
Meta (Meta event)	Displays the SMF meta events in the song. This does not let you change the actual contents of the data; however, it lets you delete, cut, copy, and paste the data.

Inputting and Editing Lyrics

This convenient function lets you enter the song name and the lyrics for the song. It also lets you change or correct already existing lyrics. For more information on lyric events, see the chart below. Calling up operations here apply to step 4 on page 87. Use the [BACK]/[NEXT] buttons to call up the display below. The operations here are the same as those in Editing Note Events (page 96).

In the following example, we'll rewrite a portion of the lyrics to one of the songs, "Twinkle Twinkle Little Star." Select the internal song "Twinkle Twinkle Little Star." The method for selection is the same as described on pages 67 and 71.

1 Move the cursor to the event containing the lyric "star."

2 Move the cursor to the word "star."

3 Use these buttons to call up the Lyric display, from which you can input lyrics. From the Lyric display (page 42), enter the new word, "(your name)."

4 Press this button to save the newly changed lyric data.

NOTE
To actually enter an edited value, move the cursor away from the value or press the SONG [START/STOP] button.

Lyrics Events

Parameter	Description
Name (Song name)	Determines the song name. This calls up the NAME display, from which you can enter the name.
Lyrics	Allows you to enter lyrics.
Code (Other controls)	CR : Enters a line break in the lyrics text. LF : Deletes the currently displayed lyrics and displays the next set of lyrics.

Customizing the Event List — Filter

This function lets you determine which event types will be shown in the event editing displays. To select an event for display, checkmark the box corresponding to the event name. To filter out an event so that it is not shown on the list, remove the checkmark so that the box is empty.

To call up the display below, press the [H] (FILTER) button from any of the following displays: CHD, 1 - 16, SysEX, or LYRICS (page 96 - page 98).

Calls up the Main Filter display. For more information on each event type, refer to the separate Data List booklet (MIDI Data Format).

Calls up the Control Change Filter display. For more information on each event type, refer to the separate Data List booklet (MIDI Data Format).

Calls up the Accompaniment Filter display. For more information on each event type, refer to the separate Data List booklet (MIDI Data Format).

Enters checkmarks for all items.

Selects only note data; checkmarks for all other boxes are removed.

Reverses the checkmark settings for all boxes. In other words, this enters checkmarks to all boxes that were previously un-checked and vice versa.

Executes the settings by pressing the [EXIT] button.


Enters/removes the checkmark for the selected item.

Selects the item, scrolling up/down one item at a time.

When "MAIN FILTER" or "ACCOMPANIMENT FILTER" is selected, these select the item, scrolling up/down to the top or the bottom. When "CONTROL CHANGE FILTER" is selected, these select the item, scrolling up/down eight items at a time.

Creating Accompaniment Styles — Style Creator

This powerful feature lets you create your own original styles, which can then be used for auto accompaniment — just as with the preset styles.



About Creating Accompaniment Styles

The chart at right shows the basic parts (or “channels”) that make up each section of an accompaniment style. To create an accompaniment style, record patterns to the various channels one by one, for each of the sections you want to create.

■ Realtime Recording (page 101)

You can record accompaniment styles by simply playing the parts from the keyboard in real time. However, you don't have to record every part yourself — you can choose an existing preset accompaniment style that is close to the style you want, then add or replace parts in that style as needed to create your own custom style.

Realtime Recording Characteristics

• Loop recording

Since auto accompaniment playback repeats the accompaniment patterns of several measures in a “loop,” you can also record patterns in a loop. For example, if you start recording with a two-measure Main section, the two measures are repeatedly recorded. Notes that you record will play back from the next loop (repetition), letting you record new material while hearing the parts you previously recorded.

• Overdub recording

This feature lets you record new material to a track already containing recorded data, without deleting the original data. In style recording, the recorded data remains intact, unless you specifically delete it yourself. For example, if you start recording with a two-measure Main section, the two measures are repeated. As you record notes to each pass of the loop (repetition), those notes play back from the next loop, letting you overdub new material while hearing the previous parts.

■ Step Recording (page 102)

This method is like writing music notation on paper, since it allows you to enter each note or individually, and specify its length. This is ideal for making precise recordings, or for recording parts that are difficult to play.

■ Assembling an Accompaniment Style (page 103)

This convenient feature lets you create composite styles by combining various patterns from the internal preset accompaniment styles. For example, if you want to create your own original 8-beat style, you could take rhythm patterns from the “8 Beat 1” style, use the bass pattern from “8 Beat 2,” and import the chord patterns from the “60's 8 Beat” style — combining the various elements to create one accompaniment style.


■ Editing the created Accompaniment Style (page 104)

With the editing features, you can custom edit the styles you've created by real time recording, step recording, and assembling from other styles.

Section	Channel
INTRO A - D	
MAIN A - D	RHYTHM 1, RHYTHM 2, BASS, CHORD 1, CHORD 2, PAD, PHRASE 1, PHRASE 2
FILL IN A - D	
BREAK	
ENDING A - D	


NOTE

For information on the part structure of accompaniment styles, see page 85.




Style File Format

The Style File Format (SFF) combines all of Yamaha's auto accompaniment know-how into a single unified format. By using the edit functions, you can take full advantage of the SFF format and freely create your own styles. The chart at right indicates the process by which the accompaniment is played back. (This does not apply to the rhythm tracks.) The basic or "source" pattern in the chart is the original style data. This source pattern is recorded using accompaniment style recording (see below). As shown in the chart at right, the actual output of the accompaniment is determined by various parameter settings and chord changes (played in Auto Accompaniment area of the keyboard) entered to this source pattern.




Operation


- 1 Select the desired accompaniment style for editing.** To record a new accompaniment style from scratch, call up the **BASIC** page in the **Style Creator** display and select "New Style" by pressing the [C] button.



3



- 4 Record and edit the accompaniment style.** For details on the operations for each display, refer to the explanations starting on the next page.



- 5 Call up the Style display by pressing the [I] (SAVE) button (in Assembly page: [J] button), then save the recorded / edited data to the USER or FLOPPY DISK page.**

Press the [EXIT] button to close the **STYLE CREATOR** display.

Realtime Recording — Basic

You can use the Realtime Recording features to create your own accompaniment style — either from scratch or based on the preset accompaniment data. The operations here apply to step 4 on page 100.

1 Select the desired channel for recording by simultaneously holding down the [F] (REC CH) button and pressing the appropriate [1▲▼] - [8▲▼] button.

Before recording to one of the non-rhythm channels (**BASS - PHR 2**), make sure to delete the existing data of the appropriate channel. You can make other settings (see the box “Other Parameters in the **BASIC** page” on page 102) after closing the **REC CHANNEL** display by pressing the [EXIT] button. To call up the **REC CHANNEL** display again, press the [F] (REC CH) button.

Calls up the display for changing the tempo or beat (time signature).

Selects an empty style, allowing you to create a new style from scratch.

Available only when the channel is set to [RHY1] or [RHY2], this lets you delete specific percussion sounds during recording. Simultaneously hold down this button and press the key corresponding to the instrument you want to delete.



When this button is pressed, “DELETE” will appear over channels containing data. To delete data from a specific channel, simultaneously hold down this button and press the appropriate [1▲] - [8▲] button. To release or cancel the selection, press the [1▼] - [8▼] button corresponding to the channel you wish to cancel. As long as you continue to hold down the [J] button, you can toggle between deleting and restoring the selected data. **Releasing the [J] button permanently deletes the data.** Before recording to one of the non-rhythm channels (**BASS - PHR 2**), make sure to delete the existing data of the appropriate channel.

REC Channel is enabled for recording.
ON Channel is enabled for playback.
OFF Channel is muted.

2 First, select the desired voice. Start recording by pressing the STYLE [START/STOP] button.

The selected section of the style starts playing back. Since the rhythm pattern loops repeatedly, you can record new sounds and notes on each pass while listening to the pattern. Icons above the keys conveniently indicate the percussion instruments assigned to the keys.

[J] NOTE

If you've enabled Sync Start (by pressing the **SYNC START** button), you can start recording by simply pressing a key on the keyboard.

3 Stop recording by pressing the STYLE [START/STOP] button again.



With the **REC CHANNEL** display shown, close the display by pressing the [EXIT] button.

[J] NOTE

- Only Drum Kit/SFX Kit can be selected for the RHY 2 channel.
- For the non-rhythm channels (BASS - PHR 2), all-voices with the exception of the Drum Kit/SFX Kit can be selected.

Other Parameters in the Basic Display

[I] (SAVE) button

Calls up the Style display for saving the accompaniment style data.

[3▲▼][4▲▼] (Section) buttons

Determines the section to be recorded.

[5▲▼][6▲▼] (Pattern Length) buttons

Determines the length of the selected section's pattern in measures (1 - 32). The Fill In/Break section is fixed at a length of one measure.

[D] (Execute) button


Executes the Pattern Length change.

NOTE

You can also select the desired section for recording by pressing appropriate panel button. Pressing one of the Section buttons calls up the SECTION display, from which you can change sections by using the [6▲▼]/[7▲▼] buttons. To actually enter the change, press the [8▲] button. To select the Fill In section, press the [AUTO FILL IN] button.

Recording — Precautions

- The basic chord used for the accompaniment style is called the source chord. All chords that play and the pitches that sound are derived from the source chord. When recording the Main and Fill In sections (for a source chord of CM7), keep the following points in mind:
 - When recording to the Bass or Phrase channels, try to use only the recommended notes; this will ensure that you can play various chords with the accompaniment style and get optimum results. (Other notes may work, providing you use them as short passing tones.)
 - When recording to the Chord or Pad channels, use only the notes of the CM7 chord; this will ensure that you can play various chords with the accompaniment style and get optimum results. (Other notes may work, providing you use them as short passing tones.)




C = chord note
C, R = recommended note

The source chord is set by default to CM7; however, you can change this to any chord you prefer. Refer to the section "Making Style File Format Settings – Parameter" on page 107.

- When recording Intro and Ending sections, you can ignore the source chord and use any notes or chord progressions you like. In this case, if you set the NTR parameter to "ROOT TRANSPOSE" and NTT to "HARMONIC MINOR" or "MELODIC MINOR" (in the PARAMETER page), the normal pitch conversions that would result from playing different chords are cancelled (for playback) — meaning that the accompaniment pitch conversion will only occur for changes in the root note or major/minor shifts.

Step Recording

With this method, you can create a style pattern by entering notes and other data individually, without having to perform them in real time. The operations here apply to step 4 on page 100.



The actual recording process is the same as in Step Recording of songs (page 87), with the exception of the points described below. You can also edit each event from the Edit page, and the editing process the same as in editing songs (page 96).


- In song recording, the end mark position can be changed freely. However, it cannot be changed when creating accompaniment styles. This is because the length of the accompaniment style is automatically fixed according to the selected section. For example, when creating an accompaniment style based on a four-measure section, the end mark position is automatically set to the end of the fourth measure, and cannot be changed from the Step Record screen.
- When editing the data recorded on the Edit page, you can switch between the type of data you want to edit (event data or control data). Press the [F] (TRACK EVT) button to switch between the Event display (Note, Control Change, etc.) and the Control display (System Exclusive, etc.).
Make sure to set the record channel from another display (e.g., BASIC display; page 100) beforehand.

Assembling an Accompaniment Style — Assembly

This convenient function lets you combine accompaniment elements — such as rhythm, bass, and chord patterns — from existing styles, and use them to create your own original accompaniment styles. The operations here apply to step 4 on page 100.

1 These let you select the accompaniment style that will be used for each channel of your original style. Select the desired channel by pressing the [A] – [D], [F] – [I] buttons and press the same button to call up the **Style** screen, from which you can select the accompaniment style.

3 After repeating steps 1 and 2 as desired, press the [J] (SAVE) button to save the assembled style data. From here, you can store the settings of all channels (RHYTHM 1, RHYTHM 2, BASS, etc.) to a single accompaniment style.



2 Selects the style section and channel that will be copied to the corresponding channels, selected with the [A]-[D] and [F]-[I] buttons above.

NOTE
If you change the section and channel in steps #1 and #2, the currently specified section and channel are also changed. The channels being recorded are also changed and recording is stopped automatically.

NOTE
The PLAY TYPE parameter affects only the playback, and does not change the actual accompaniment style data.

Determines the playback settings for each channel. You can assemble the accompaniment style while the style section and channel that will be copied are playing.

- SOLO**Mutes all but the selected channel. RHYTHM channels set to REC in the REC CHANNEL display (page 102) are played back simultaneously.
- ON**Plays back the selected channels. Any channels set to ON in the REC CHANNEL display (page 101) are played back simultaneously.
- OFF**If the selected channel is set to ON in the REC CHANNEL display (page 101), OFF does not appear and is not available.


Edit the Created Accompaniment Style

Change the Rhythmic Feel — Groove and Dynamics


These versatile features give you a wide variety of tools for changing the rhythmic feel of your created accompaniment style. The operations here apply to step 4 on page 100.

■ Groove


Use these to select the desired edit operation.




Executes the Groove operation. After the operation is completed, this button changes to [UNDO], letting you restore the original data if you're not satisfied with the Groove results. The Undo function only has one level; only the previous operation can be undone.



Calls up the **Style** display and lets you store the edited accompaniment style data.



Determines the settings for each of the Groove parameters (see the list below).



Groove parameters

Original Beat	Specifies the beats to which Groove timing is to be applied. In other words, if "8 Beat" is selected, Groove timing is applied to the 8th notes; if "12 Beat" is selected, Groove timing is applied to 8th-note triplets.
Beat Converter	Actually changes the timing of the beats (specified in the ORIGINAL BEAT parameter above) to the selected value. For example, when ORIGINAL BEAT is set to "8 Beat" and BEAT CONVERTER is set to "12," all 8th notes in the section are shifted to 8th-note triplet timing. The "16A" and "16B" Beat Converter which appear when ORIGINAL BEAT is set to "12 Beat" are variations on a basic 16th-note setting.
Swing	Produces a "swing" feel by shifting the timing of the back beats, depending on the ORIGINAL BEAT parameter above. For example, if the specified ORIGINAL BEAT value is 8th notes, the Swing parameter will selectively delay the 2nd, 4th, 6th, and 8th beats of each measure to create a swing feel. The settings "A" through "E" produce different degrees of swing, with "A" being the most subtle and "E" being the most pronounced.
Fine	Selects a variety of Groove "templates" to be applied to the selected section. The "PUSH" settings cause certain beats to be played early, while "HEAVY" settings delay the timing of certain beats. The numbered settings (2, 3, 4, 5) determine which beats are to be affected. All beats up to the specified beat—but not including the first beat—will be played early or delayed (for example, the 2nd and 3rd beats, if "3" is selected). In all cases, "A" types produce minimum effect, "B" types produce medium effect, and "C" types produce maximum effect.

■ Dynamics

Use these to select the desired edit operation.

Executes the Dynamics operation. After the operation is completed, this button changes to **[UNDO]**, letting you restore the original data if you're not satisfied with the Dynamics results. The Undo function only has one level; only the previous operation can be undone.

Select the desired channel to which Dynamics is to be applied.

Calls up the **Style** display and lets you store the edited accompaniment style data.

Determines the settings for each of the Dynamics parameters (see the list below).

Dynamics parameters


Accent Type	Selects the type of accent.
Strength	Determines how strongly the selected Accent Type (above) will be applied. The higher the value, the stronger the effect.
Expand/Compress	Expands or compresses the range of velocity values, around a central velocity value "64." Values higher than 100% expand the dynamic range, while values lower than 100% compress it.
Boost/Cut	Boosts or cuts all velocity values in the selected section/channel. Values above 100% boost the overall velocity, while values below 100% reduce it.

NOTE
Velocity is determined by how strongly you play the keyboard. The more strongly you play the keyboard, the higher the velocity value and, hence, the louder the sound.

Editing the Channel Data

In this display, there are five different channel-related edit functions, including Quantize, for editing the recorded accompaniment style data. The operations here apply to step 4 on page 100.

See the explanations below.



NOTE

Preset channel BASS-PHRASE 2 can not be edited.

■ Quantize

Refer to page 93.

■ Velocity Change

Boosts or cuts the velocity of all notes in the specified channel (selected with the [1▲▼]/[2▲▼] (CHANNEL) buttons), according to the specified percentage (selected with the [4▲▼]/[5▲▼] (BOOST/CUT) buttons).

■ Bar Copy

This function allows data to be copied from one measure or group of measures to another location within the specified channel. Use the [4▲▼] (TOP) and [5▲▼] (LAST) buttons to specify the first and last measures in the region to be copied. Use the [6▲▼] (DEST) button to specify the first measure of the destination location, to which the data is to be copied.

■ Bar Clear


This function clears all data from the specified range of measures within the selected channel. Use the [4▲▼] (TOP) and [5▲▼] (LAST) buttons to specify the first and last measures in the region to be cleared.

■ Remove Event

This function lets you remove specific events from the selected channel. Use the [4▲▼] - [6▲▼] (EVENT) buttons to select the desired event type to be removed.

Making Style File Format Settings —Parameter

This display provides a variety of style controls— such as determining how the pitch and sound of the recorded style change when playing the chords in the left-hand range of the keyboard. For details about the relationship between the parameters, refer to “Style File Format” on page 100. The operations here are the same as described in step 4 on page 100.



See the explanations below.

NOTE
When NTR is set to “Root Fixed” and NTT is set to “Bypass,” the “Source Root” and “Source Chord” parameters are changed to “Play Root” and “Play Chord,” respectively. In this case, you can change chords and hear the resulting sound for all channels.

■ Source Root/Chord

These settings determine the original key of the source pattern (i.e., the key used when recording the pattern). The default setting of CM7 (with a Source Root of “C” and a Source Type of “M7”), is automatically selected whenever the preset data is deleted prior to recording a new style, regardless of the Source Root and Chord included in the preset data. When you change Source Root / Chord from the default CM7 to another chord, the chord notes and recommended notes will also change, depending on the newly selected chord type. For details on chord notes and recommended notes, see page 102.

When the Source Root is C:

 C R C C R	 C R C C C R	 C R C C R C	 C R C C R C C	 C C C C R	 C C C C R C	 C C C C C R
 C R C R C R	 C R R C	 C R R C C	 C R C C	 C R C R C	 C C R C	 C C R C C
 C R C C C	 C R R C C	 C C R C C	 C R C R	 C R R C R	 C C C C	 C C C C
 C R C C C	 C C C C C	 C R C C R	 C R C C C	 C C C C C	 C C R C C	 C C C R C
 C R C R R C	 C R C R C C	 C C	 C C	 C R C C	 C C R C R	

C = chord note
C, R = recommended note

■ NTR (Note Transposition Rule) and NTT (Note Transposition Table)

• NTR (Note Transposition Rule)

This determines the system for pitch conversion of the source pattern. Two settings are available.

Root Trans (Root Transpose)

When the root note is transposed, the pitch relationship between notes is maintained. For example, the notes C3, E3 and G3 in the key of C become F3, A3 and C4 when they are transposed to F. Use this setting for channels that contain melody lines.



Root Fixed

The note is kept as close as possible to the previous note range. For example, the notes C3, E3 and G3 in the key of C become C3, F3 and A3 when they are transposed to F. Use this setting for channels that contain chord parts.



• **NTT (Note Transposition Table)**

This sets the note transposition table for the source pattern. Six transposition types are available.

Bypass

No transposition.

Melody

Suitable for melody line transposition. Use this for melody channels such as **Phrase 1** and **Phrase 2**.

Chord

Suitable for chord transposition. Use for the **Chord 1** and **Chord 2** channels, especially when they contain piano or guitar-like chordal parts.

Bass

Suitable for bass line transposition. This table is basically similar to the Melody table above, but recognizes on-bass chords allowed in the **FINGERED ON BASS** fingering mode. Use this primarily for bass lines.

Melodic Minor

When the played chord changes from a major to a minor chord, this table lowers the third interval in the scale by a semitone. When the chord changes from a minor to a major chord, the minor third interval is raised by a semitone. Other notes are not changed.

Harmonic Minor

When the played chord changes from a major to a minor chord, this table lowers the third and sixth intervals in the scale by a semitone. When the chord changes from a minor to a major chord, the minor third and flatted sixth intervals are raised by a semitone. Other notes are not changed.

■ **High Key/Note Limit**

• **High Key**

This sets the highest key (upper octave limit) of the note transposition for the chord root change. Any notes calculated to be higher than the highest key are transposed down to the octave just below the highest key. This setting is effective only when the NTR parameter (page 107) is set to "Root Trans."

Example — When the highest key is F

Root changes → CM C#M . . . FM F#M . . .
 Notes played → C3-E3-G3 C#3-F3-G#3 F3-A3-C4 F#2-A#2-C#3



• **Note Limit**

This sets the note range (highest and lowest notes) for voices recorded to the style channels. By judicious setting of this range, you can ensure that the voices sound as realistic as possible — in other words, that no notes outside the natural range are sounded (e.g., high bass sounds or low piccolo sound). The actual notes that sound are automatically shifted to the set range.

Example — When the lowest note is C3 and the highest is D4

Root changes → CM C#M . . . FM . . .
 Notes played → E3-G3-C4 F3-G#3-C#4 F3-A3-C4



■ **RTR (Retrigger Rule)**

These settings determine whether notes stop sounding or not and how they change pitch in response to chord changes.

Stop

The notes stop sounding.

Pitch Shift

The pitch of the note will bend without a new attack to match the type of the new chord.

Pitch Shift to Root

The pitch of the note will bend without a new attack to match the root of the new chord.

Retrigger


The note is retriggered with a new attack at a new pitch corresponding to the next chord.

Retrigger To Root

The note is retriggered with a new attack at the root note of the next chord. However, the octave of the new note remains the same.


Creating Multi Pad — Multi Pad Creator

The PSR-A1000 lets you create your own original Multi Pad phrases — which you can use in your performances in the same way as the preset Multi Pads.




Operation


- 1 Select the desired Multi Pad Bank for editing.** To record a new Multi Pad from scratch, call up the **RECORD** page in the **Multi Pad Creator** display and select “New Bank” by pressing the [C] (NEW BANK) button.



3



- 4 Record and Edit the Multi Pad.** For details on the operations for each display, refer to the explanations starting on the next page.




- 5 Call up the Multi Pad display by pressing the [I] (SAVE) button, then save the recorded / edited data to the USER or FLOPPY DISK page.**

Press the [EXIT] button to close the **MULTI PAD** display.


Multi Pad Realtime Recording — Record

The operations here apply to step 4 on page 109.



Start recording

First, select the desired voice. Press the **[H] (REC)** button to set the Record standby mode. Recording begins automatically as soon as you play on the keyboard. You can also start recording by pressing the **STYLE [START]** button. If Chord Match (see below) is set to on for the Multi Pad to be recorded, you should record using the notes of the C major seventh scale (C, D, E, G, A and B).



C = chord note
 C, R = recommended note
 Others: non-recommended note

NOTE

- Other notes besides those of the C major seventh scale can be recorded; however, this may result in the recorded phrase not matching the chord when being played back.
- The rhythm part of the currently selected style is used as a rhythmic guide (in place of a metronome), playing back during recording. However, it is not recorded to the Multi Pad.

Stop recording

Press the **[H] (STOP)** button or the panel **STYLE/MULTI PAD [STOP]** button to stop recording when you've finished playing the phrase.

Turning Chord Match and Repeat On/Off

Repeat


Unless the Repeat function is on for the selected pad, playback will end automatically as soon as the end of the phrase is reached. A phrase can be stopped while it is playing by pressing the **MULTI PAD [STOP]** button.

Chord Match

If a Multi Pad is played while Style is playing and the Chord Match function for that pad is ON, the phrase will be automatically re-harmonized to match the accompaniment chords.

Step Recording or Editing Multi Pads — Edit

With this method, you can create a Multi Pad by entering notes and other data individually, without having to perform them in real time. The operations here apply to step 4 on page 109.




The actual recording process is the same as in Step Recording of songs (page 87), with the exception of the points described below. You can also edit each event from the Edit page, and the editing process the same as in editing songs (page 96).

- Just as with Song Recording, the End Mark position can be changed freely in the Multi Pad Creator. This allows you to finely adjust the phrase length for the Pad. This would be convenient, for example, in synchronizing repeat playback of a Pad (set to Repeat On) with the keyboard and auto accompaniment playback.
- Since the Multi Pads have only one track (channel), the track (channel) cannot be changed.

Adjust the Volume Balance and Changing Voices — Mixing Console

Set up just like a real mixing console, this display gives you comprehensive control over the sound.



NOTE

Mixing Console
This set of controls lets you adjust the balance of the voices and their stereo position, as well as the amount of effect that is applied to each voice.

You can call up additional basic mixing controls by using the [BALANCE] button and the [CHANNEL ON/OFF] button (page 58).

Operation

1



From the **MIXING CONSOLE** display, press the button repeatedly until the desired display is called up. Each press of the button switches among the displays listed below.

PANEL PART

Includes the keyboard-played parts (Main/Layer, Left), accompaniment parts, song.

STYLE PART


Accompaniment parts

SONG CH 1 - 8

Channels 1 - 8 of song playback

SONG CH 9 - 16

Channels 9 - 16 of song playback



NOTE

You can quickly and easily set all parts to the same value for the same parameter (except for the VOICE parameter). Simultaneously hold down the [A] - [J] button that corresponds to the parameter you want to change and use the [1] - [8] buttons or the [DATA ENTRY] dial to change the value.

NOTE

For details on parameters related to the **Sound Creator**, see page 80.

2

Select the other **Mixing Console** pages by using the [BACK]/[NEXT] buttons and set the desired parameters.

For information on the various parameters and settings and how to use them, refer to the explanations starting on page 113.



Close the **Mixing Console** display by pressing the [EXIT] button.

■ About the parameters

• VOL/VOICE (Volume/Voice) (page 113)

This contains settings related to the volume and voice of each part/channel. Here you can also enable the Auto Revoice feature — which automatically plays XG-compatible songs (page 143) with the rich and dynamic voices that are exclusive to the PSR-A1000. This gives you much more authentic and realistic instrument sounds for your song playback.

• FILTER (page 114)

These controls affect the tone quality of the voice, letting you add power, punch, or brightness to the sound.

• TUNE (page 114)

These give you various tuning controls.

• EFFECT (page 115)

These control the amount of effect applied to the sound.

Setting the Level Balance and Voice — Volume/Voice

The operations for this page apply to step 2 of the procedure on page 112.

1 Use these to select the **VOICE**, **PANPOT**, or **VOLUME** parameter rows.

Set this to ON to enable automatic replacement of the XG voices (in XG song data) with the special voices of the PSR-A1000. To use the normal XG voice set, turn this off.

Each press of this button switches among the various parts/channels.

These let you select the voice of each part, and adjust the panpot and volume.

VOICE
Calls up the **VOICE** display, from which you can select the desired voice (page 51). When the Style part is selected, neither Organ Flutes voices nor User voices can be selected. When the Song part is selected, User voices cannot be selected.

PANPOT
Determines the stereo position of the selected voice or track. A setting of 0 pans the sound hard left, while 64 is at center, and 127 is at hard right.

VOLUME
Determines the level of each channel, giving you fine control over the balance of all the parts.

NOTE
The **[RHY2]** categories in the **STYLE PART** display are only for the Drum Kit/SFX Kit (percussion) voice.

NOTE
The **[RHY1]** channel in the **STYLE PART** display can be assigned to any voice except for the Organ Flutes voice.

NOTE
When playing GM song data, channel 10 (in the **SONG CH 9 - 16** page) can only be used for a Drum Kit voice.

NOTE
When changing the rhythm/ percussion voices (drum kits, etc.) of the accompaniment style and song from the **VOICE** parameter, the detailed settings related to the drum voice are reset, and in some cases you may be unable to restore the original sound. In the case of song playback, you can restore the original sound by returning to the beginning of the song and playing back from that point. In the case of accompaniment style play, you can restore the original sound by selecting the same style again.

2

VOICE NAME	REVOICE TO		
EL. PIANO 1	COOL! E.PIANO	ALL REVOICE	
MUTED GUITAR	COOL! ELEC.GTR		
STRINGS 2	LIVE! ORCHSTRA	BASIC REVOICE	
TRUMPET	NO REVOICE		
TROMBONE	NO REVOICE		
SOPRANO SAX	NO REVOICE		
ALTO SAX	NO REVOICE		
TENOR SAX	NO REVOICE		
CLARINET	NO REVOICE		
FLUTE	NO REVOICE		
			ALL NO REVOICE

ALL REVOICE
Replaces all of the replaceable XG voices with the rich and authentic voices of the PSR-A1000.

BASIC REVOICE
Replaces only the recommended voices that are suitable for playing back the song.

ALL NO REVOICE
All the voices are returned to the original XG voices.

Executes the settings and closes the **Auto Revoice Setup** display.

Closes the **Auto Revoice Setup** screen without executing the settings.


Selects the XG voices to be replaced (voices usually used when playing back)

Selects the voices used to replace the XG voices (when **SONG AUTO REVOICE** is set to ON).

NOTE
Keep in mind that using the Revoice function may result in unnatural or unexpected sound, depending on the particular song data.

Changing the Tone of the Voice — Filter

The operations for this page apply to step 2 of the procedure on page 112.




NOTE
For details about the Filter, see page 81.

NOTE
Be careful with these controls. Depending on the selected voice, extreme settings may result in noise or distortion.




Changing Pitch-related Settings — Tune

The operations for this page apply to step 2 of the procedure on page 112.



NOTE
Portamento is used to create a smooth transition in pitch from one note to the next.



These increase/decrease (transpose) the pitch in semitone units.
MASTER ... Transposes both the pitch of the keyboard and that of the song playback.
SONG Transposes the pitch of the song playback.
KBD Transposes the pitch of the keyboard.

- PORTAMENTO TIME** When the part is set to Mono (page 55, 80), this determines the Portamento time. The higher the value, the longer the time it takes for the pitch to change. Portamento is only applied when you play legato (playing the next note before releasing the previous one).
- PITCH BEND RANGE** Determines the range of the PITCH BEND wheel for the corresponding part. The range is from “0” to “12” with each step corresponding to one semitone.
- OCTAVE**..... Determines the range of the pitch change in octaves, over two octaves up or down. The value of this parameter is added to the value set via the [UPPER OCTAVE] button.
- TUNING**..... Determines the pitch of the instrument.

Adjusting the Effects

The operations for this page apply to step 2 of the procedure on page 112.

NOTE

There are three effect sections: Reverb, Chorus, and DSP (which contains a variety of effect types). For details, refer to the Effect Block list (page 116).

1 Indicates the type name for each effect block.

Press this to edit and store the effect (page 115, 116).

Each press of this button switches among the various parts/channels.

Switches among the effect sections: **REVERB, CHORUS, and DSP.**

Determines the amount of effect that is applied to each part. For more information about the characteristics of each effect, see the **Effect Block** list on page 116.

2

When the **BLOCK** parameter is set to **REVERB, CHORUS, or DSP1-4/DSP**, press this to call up the display from which you can change the detailed settings for the effects.

These determine the effect block and let you assign the effect.

BLOCK..... Determines the effect block (group of similar or related effects).

PART Determines the part to which the Insertion effect is applied. It is effective only when **BLOCK** is set to "DSP," **PARAMETER** is set to "CONNECTION," and **VALUE** is set to "Insertion."

CATEGORY..... The various effect programs (in **Type** below) are grouped into categories. This parameter may not be available depending on the selected block.

TYPE Determines the type of effect that is assigned to the selected effect block. The actual effect types that are available may differ depending on the selected block.

3

Switches between the upper/lower parameters. For the lower parameter, the depth can be changed when the [VARIATION] button is on.

Determines the effect block.

Determines the effect category.

Determines the effect type.

Determines the effect parameter to be adjusted.

Calls up the display for storing the effect.

Determines the level of the effect (return level). This is not available when BLOCK is set to "DSP," PARAMETER is set to "CONNECTION," and VALUE is set to "Insertion."

Determines the value of the selected parameter.

4

Select the destination to which the effect is to be stored. The number of memory spaces available for the destination differs for each block (refer to the chart below).

Stores the effect settings you made above to a **User Effect** location (SYSTEM) for future recall. To call up the effect, select **USER** from the **CATEGORY** parameter and select the desired effect from the **TYPE** parameter.

Calls up the display for naming the User Effect (page 42).

NOTE
Keep in mind that in some cases noise may result if you adjust the effect parameters while playing the instrument.

Effect Block

Block	Parts	Characteristics	Number of User Effect
REVERB	All parts	Reproduces the warm ambience of playing in a concert hall or jazz club.	3
CHORUS	All parts	Produces a rich "fat" sound as if several parts are being played simultaneously.	3
DSP	Main, Layer, Left, Song (Ch. 1 - 16), Style	In addition to reverb and chorus effects, this section features a variety of special effects, including distortion.	3


Effect Structure

The PSR-A1000 features the following digital effect systems. The effect type, depth, and various parameters can be set with the panel controls.

About the Effect Connections – System and Insertion


All the effect blocks are connected or routed in one of two ways: System or Insertion. System applies the selected effect to all parts, while Insertion applies the selected effect to one specific part. Reverb and Chorus are System effects. The DSP effect can be configured for either System or Insertion routing.

The illustration below shows how the various effect blocks are set up and traces the signal flow for the send/return controls set on the PSR-A1000.



Making Global and Other Important Settings — Function

The Function mode gives you access to various advanced functions related to the instrument as a whole. These sophisticated functions let you customize the PSR-A1000 to your own musical needs and preferences.




Operation

1



2

Select the desired function.



3

Set the parameters of the selected function.

The operations for each function are covered in the following explanations.



To return to the previous display, press the [EXIT] button.

Adjusting the Pitch — Master Tune

■ Master Tune (page 120)

This allows you to make fine adjustments to the overall pitch of the instrument — letting you accurately match the tuning with that of other instruments.

Setting Song-related Parameters — Song Settings (page 121)

These allow you to set parameters related to song playback.

Setting Auto Accompaniment-related Parameters — Style Setting, Split Point, and Chord Fingering

■ Style Setting / Split Point (page 122)

These determine the auto accompaniment-related settings, and let you set the split point.

■ Chord Fingering (page 123)

This determines the method for playing/indicating chords when using the auto accompaniment features. You can even check how to play the chord, since the individual notes are indicated in the display.

Making Settings for the Pedals and Keyboard — Controller

■ Pedal (page 123)

These settings determine how the connected foot pedals (including foot controllers and footswitches) are used. They can be assigned to a variety of functions, letting you control operations with your feet — such as turning the accompaniment style on/off, or triggering Fill In patterns.

■ Keyboard / Panel (page 125)

These settings determine the touch sensitivity of the keyboard (how touch affects volume), and the pitch transpose settings (for the keyboard, song data, and entire instrument).

Setting the Registration Sequence, Freeze, and Voice Set

■ Registration Sequence (page 126)

This determines the order in which the Registration Memory presets (1 - 8) are called up — by using the [BACK][NEXT] buttons or the pedal.

■ Freeze (page 126)

This lets you specify the settings you want to be maintained or left unchanged, even when changing Registration Memory presets.

■ Voice Set (page 127)

This lets you determine whether certain voice-related settings (such as Effects, Harmony, etc.) are automatically called up or not when you select a voice.

Setting Harmony and Echo (page 127)

These let you set the type of Harmony or Echo effect applied to the keyboard-played voices, as well as the amount of effect.

Making MIDI Settings

■ System (page 129)

These determine various system messages settings (such as Clock, Start/Stop, System Exclusive), as well as Local Control on/off.

■ Transmit (page 130)

This determines how playback data is sent to connected MIDI devices — i.e., which parts are assigned to which MIDI Transmit channels. This also lets you specify the type of data to be transmitted over each channel.

■ Receive (page 131)

This determines how the parts of the PSR-A1000 respond to data from connected MIDI devices — i.e., which parts are assigned to which MIDI Receive channels. This also lets you specify the type of data to be received over each channel.

■ Root (page 131)

This determines the channel(s) recognized for the root notes, for use with the auto accompaniment.

■ Chord Detect (page 131)

This determines the channel(s) recognized for the chords, for use with the auto accompaniment.

Other Settings — Utility

■ Config 1 (page 132)

This page contains settings for Fade In/Out, Metronome, Parameter Lock, and the Tap sound.

■ Config 2 (page 133)

From this page, you can adjust the display, and change the voice number indication.

■ Disk (page 134)

From this page, you can format disks, and copy from disk to disk.

■ Owner (page 135)

From this page, you can set the language of the instrument, and input your own name — which is shown automatically every time the power is turned on.


■ System Reset (page 135)

This function restores the PSR-A1000 to its original factory settings. You can also specify which types of settings are to be restored, as well as store your own original settings for future recall.

Fine Tuning the Pitch — Master Tune

The explanations here apply to step #3 of the procedure on page 118.

Tuning the Overall Pitch — Master Tune



Determines the overall pitch of the PSR-A1000, from 414.8 - 466.8 Hz. Press the 4 or 5 [**▲▼**] buttons simultaneously to instantly reset the value to the factory setting of 440.0 Hz.

NOTE

Hz (Hertz)


This unit of measurement refers to the frequency of a sound, and represents the number of times a sound wave vibrates in a second.

NOTE

The Tune function does not affect the Drum Kit or SFX Kit voices.

Setting Song-related Parameters — Song Settings

The explanations here apply to step #3 of the procedure on page 118.



NOTE

Quick Start
On some commercially available song data, certain settings related to the song (such as voice selection, volume, etc.) are recorded to the first measure, before the actual note data. When Quick Start is set to "ON," the PSR-A1000 reads all initial non-note data of the song at the highest possible speed, then automatically slows down to the appropriate tempo at the first note. This allows you to start playback as quickly as possible, with a minimum pause for reading of data.

NOTE

Channel
Refers to the MIDI channel (page 141). The channels are assigned as follows:
Song 1 - 16
Accompaniment Style 9 - 16




NOTE

Phrase Mark
This data specifies a certain location in the song data.

Setting Auto Accompaniment-related Parameters — Style Setting, Split Point, and Chord Fingering

The explanations here apply to step #3 of the procedure on page 118.

Setting Auto Accompaniment-related Parameters — Style Setting and Split Point



These select the part to which the split point setting is applied: accompaniment, left-hand range, or both. Press the desired key for the split point while holding down one of these buttons. The pressed key is included in the range for the Auto Accompaniment area of the keyboard (ACMP) or the left-hand range (LEFT).
A+L (ACMP + LEFT)
 Allows you to simultaneously set the split point for both the left-hand range and the Auto Accompaniment area of the keyboard.

NOTE
About Section Set
 When any of the Main A-D sections is not included in the accompaniment style data, the nearest section is automatically selected. For example, when Main D is not contained in the selected accompaniment style, Main C will be called up.

L (LEFT)

Allows you to set the split point for the left-hand range of the keyboard.

A (ACMP)

Allows you to set the split point for the Auto Accompaniment area of the keyboard.

Determines the split points for the auto accompaniment (ACMP) and the left-hand range (LEFT). The same value can be set for both or for each independently, using buttons [F], [G], and [H] (see above). You can use these buttons by themselves to set the split point value.

Determines the default section that is automatically called up when selecting different accompaniment styles (when accompaniment is stopped).


Turns touch response for the accompaniment on/off. When this is set to "ON," the accompaniment volume changes in response to your playing strength (in the Auto Accompaniment area of the keyboard).

The PSR-A1000 lets you automatically enable Sync Stop (page 62) simply by quickly pressing/releasing keys in the Auto Accompaniment area of the keyboard. This parameter lets you set the length of the key-hold time.

Turns the Stop Accompaniment (ACMP) function on/off. When this is set to "ON," you can play the chord and bass sounds of the accompaniment by playing chords — even when the accompaniment style is not playing back.

About Split Point

Split point is the position on keyboard that separates the Auto Accompaniment area (ACMP) and left-hand area (LEFT) from the right-hand area (MAIN). The LEFT split point cannot be set lower than the ACMP split point, and the ACMP split point cannot be set higher than the LEFT split point.



Setting the Fingering Method — Chord Fingering

This determines how the notes you play on the keyboard indicate or play the chords of the accompaniment. To learn how to play certain chords, use the convenient Chord Tutor function (see note below).

CHORD NAME: C

● .. Required
○ .. Can be omitted
△ .. Either note can be omitted
▲ .. Can be omitted when the note indicated by ○ is omitted

Determines the fingering type (page 59).

Indicates the note that belongs to a chord in the music.

This lets you change the root note from the chord.

This lets you change the chord type.

NOTE
The chord indication in the display applies to the Fingering method, regardless if another method is actually selected.

NOTE
Chord Tutor
The Chord Tutor feature is essentially an electronic “chord book” that shows you appropriate fingerings for chords; it is useful when you want to play certain chords. Simply specify the desired chord via the [6▲▼] - [8▲▼] buttons, and the fingerings for the Fingering method are indicated in the display.

Making Settings for the Pedals and Keyboard — Controller

The explanations here apply to step #3 of the procedure on page 118.

Making Settings for the Pedals

Determines the particular pedal to which a function is to be assigned.

Determines the function to be assigned to the selected pedal. Any one of the available functions can be assigned to each pedal. For information on the assignable functions, see “Pedal-controllable Functions” on the next page.

Pedal on/off operation may differ depending on the particular pedal you’ve connected to the [FOOT PEDAL 1/2] jack. For example, pressing down on one pedal may turn the selected function on, while pressing a different make/brand of pedal may turn the function off. If necessary, use this setting to reverse the operation.

If necessary, you can turn the corresponding part ON/OFF or set the control depth (see the next page).

Pedal-controllable Functions

VOLUME*	Allows you to use a foot controller (FOOT PEDAL 2 only) to control the volume.
SUSTAIN	When the pedal is pressed notes played have a long sustain. Releasing the pedal immediately stops (damps) any sustained notes.
SOSTENUTO	If you press and hold the pedal here, only the first note will be sustained (the note that you played and held when pressing the pedal). This makes it possible to sustain a chord, for example, while other notes are played staccato.
SOFT	Pressing the pedal subtly reduces the volume and slightly changes the timbre of notes played. It only applies to certain voices — PIANO, for example.
GLIDE	When the pedal is pressed the pitch changes, and then back to normal pitch when the pedal is released.
PORTAMENTO	The portamento effect (a smooth slide between notes) can be produced while the pedal is pressed. Portamento is produced when notes are played legato style (i.e., a note is played while the preceding note is still held). The portamento time can be set via the Mixing Console display (page 114).
PITCHBEND*	Bend notes up or down while pedal is pressed (FOOT PEDAL 2 only). Same as the PITCH BEND wheel.
MODULATION*	Applies a vibrato effect to notes played on the keyboard. The depth of the effect increases while pedal is pressed (FOOT PEDAL 2 only). Same as the MODULATION wheel.
DSP VARIATION	Same as the [VARIATION] button.
HARMONY/ECHO	Same as the [HARMONY/ECHO] button.
SONG START/STOP	Same as the SONG [START/STOP] button.
STYLE START/STOP	Same as the STYLE [START/STOP] button.
TAP TEMPO	Same as the [TAP TEMPO] button.
SYNCHRO START	Same as the [SYNC. START] button.
SYNCHRO STOP	Same as the [SYNC. STOP] button.
INTRO	Same as the [INTRO] button.
MAIN A	Same as the [MAIN A] button.
MAIN B	Same as the [MAIN B] button.
MAIN C	Same as the [MAIN C] button.
MAIN D	Same as the [MAIN D] button.
FILL DOWN	A fill-in plays, automatically followed by the Main section of the button on the immediate left.
FILL SELF	Fill-in starts playing.
BREAK	Break starts playing.
FILL UP	A fill-in plays, automatically followed by the Main section of the button on the immediate right.
ENDING	Same as the [ENDING/rit.] button.
FADE IN/OUT	Same as the [FADE IN/OUT] button.
FING/ON BASS	The pedal alternately switches between the Fingered and On Bass modes (page 59).
BASS HOLD	While the pedal is pressed, the Accompaniment Style bass note will be held even if the chord is changed. If the fingering is set to "FULL KEYBOARD," the function does not work.
PERCUSSION	The pedal plays a percussion instrument selected by the [4▲▼] - [8▲▼] buttons. You can use the keyboard to select the desired percussion instrument.
MAIN ON/OFF	Same as the [MAIN] button.
LAYER ON/OFF	Same as the [LAYER] button.
LEFT ON/OFF	Same as the [LEFT] button.

* For best results, use the optional Yamaha FC7 Foot Controller.

The parameters below correspond to buttons [2▲▼] - [8▲▼], and their availability depends on the selected control Type. For example, if SUSTAIN is selected as the Type, the parameters "HALF PEDAL POINT", "MAIN", "LAYER" and "LEFT" automatically appear in the display.

SONG, STYLE, LEFT, LAYER, MAIN	These specify the part(s) that will be affected by the pedal.
HALF PEDAL POINT*	You can specify how far down you should press on the foot pedal until the damper effect starts working. This can be set for certain kinds of pedals, such as the foot pedal (YAMAHA FC7) (FOOT PEDAL 2 only).
UP/DOWN	When GLIDE or PITCH BEND is selected, this determines whether the pitch change goes up (is raised) or down (is lowered).
RANGE	When GLIDE or PITCH BEND is selected, this determines the range of the pitch change, in semitones.
ON SPEED	When GLIDE is selected, this determines the speed of the pitch change, when the pedal is pressed.
OFF SPEED	When GLIDE is selected, this determines the speed of the pitch change, when the pedal is released.
KIT	When PERCUSSION is assigned to the pedal, all available drum kits are shown here, letting you select the particular drum kit used for the pedal.
PERCUSSION	When PERCUSSION is assigned to the pedal, all sounds of the selected drum kit (in KIT above) are shown here. This determines the particular instrument sound assigned to the pedal.

* For best results, use the optional Yamaha FC7 Foot Controller.

Changing the Touch Sensitivity and Transpose — Keyboard/Panel

Keyboard Touch

The Touch feature lets you control the volume of the voices by your playing strength. These settings allow you to customize the keyboard's touch response (sensitivity) to your personal playing preferences.

Selects the desired parameter: Keyboard Touch or Transpose Assign.

Determines the Touch sensitivity setting (Keyboard Touch only; refer to the table at right).

Determines the fixed volume level when touch is set to "off" (Keyboard Touch only).

Determines whether Touch is on or not for the corresponding parts.

HARD 2	Requires strong playing to produce high volume. Best for players with a heavy touch.
HARD 1	Requires moderately strong playing for higher volume.
NORMAL	Standard touch response.
SOFT 1	Produces high volume with moderate playing strength.
SOFT 2	Produces relatively high volume even with light playing strength. Best for players with a light touch.

NOTE
The TOUCH setting affects all voices globally. Keep in mind that you can set each voice to a different touch sensitivity (TOUCH SENSE). For example, to play a pipe organ voice most authentically, you can set this so that the voice is not affected by touch (page 80).

Transpose Assign

This determines which aspect of the instrument is affected by the [TRANPOSE] button.

KEYBOARD

For this setting, Transpose affects the pitch of the keyboard-played voices (Main, Layer, and Left) and the accompaniment styles.

SONG

For this setting, Transpose affects only the pitch of the songs.

MASTER

For this setting, Transpose affects the pitch of the entire instrument (keyboard voices, accompaniment styles, and songs).


NOTE

The transpose function does not affect the Drum Kit or SFX Kit voices.

Transpose

Allows you to shift the pitch of the keyboard-played voices, accompaniment style playback, and song data in semitone units.

1 Press one of the [TRANPOSE] buttons.



2 A TRANPOSE pop-up window, selected via TRANPOSE ASSIGN, appears.



3 Adjust the value by using the [TRANPOSE] buttons.



Close the TRANPOSE windows by pressing the [EXIT] button.

• Selectively Transposing Keyboard/Song


These settings can be used to match both the song and your keyboard performance to a certain key. For example, let's say you wish to play and sing along with a certain recorded song. The song data is in F, but you feel most comfortable singing in D, and you are accustomed to playing the keyboard part in C. To match up the keys, keep the Master Transpose setting at "0," set the Keyboard Transpose to "2," and set Song Transpose to "-3." This brings the keyboard part up in pitch and the song data down to your comfortable singing key.

Setting the Registration Sequence, Freeze, and Voice Set

The explanations here apply to step #3 of the procedure on page 118.

Specifying the Order for Calling Up Registration Memory Presets — Registration Sequence

You can save your custom panel settings to the Registration Memory presets, and call them up by pressing the appropriate REGISTRATION MEMORY buttons [1] - [8]. The convenient Registration Sequence function lets you call up the presets in any order you specify, by simply using the [BACK]/[NEXT] buttons or the pedal as you play.



NOTE

Setting Registration Sequence Enable to "ON" overrides any other Pedal settings (for pedals assigned to "Regist (+) Pedal" and "Regist (-) Pedal" here). These include the pedal settings on page 123, and in Voice Set on page 127.

NOTE

When both "Regist (+) Pedal" and "Regist (-) Pedal" are set to "OFF," the pedals cannot be used to step through the Registration Sequence; only the [BACK]/[NEXT] buttons can be used in the MAIN display.

NOTE

When both "Regist (+) Pedal" and "Regist (-) Pedal" are set to the same pedal, "Regist (+) Pedal" takes priority.

NOTE

Registration Sequence data is included as part of the Registration Memory bank file. To save your newly programmed Registration Sequence, store the current Registration Memory bank file (page 35, 41). Any Registration Sequence data is lost when changing Registration Memory banks, unless you've stored it with the Registration Memory bank file.



Execute the settings by pressing the [EXIT] button.

Maintaining Panel Settings — Freeze

This lets you specify the settings you want to be maintained or left unchanged, even when changing Registration Memory presets. For details, see page 78.

Changing the Automatically Selected Voice Settings — Voice Set

When changing voices (selecting a voice file), the settings best matching the voice — the same as those set in the Sound Creator — are always and automatically called up. From this page, you can set the on/off status for each part. For example, each of the preset voices has its own LEFT PEDAL setting; however, even changing voices will not change the LEFT PEDAL setting, if it is set to “OFF” in this page.


Use these to select the desired part.

REGIST. SEQUENCE / FREEZE / VOICE SET			
REGIST.	SEQUENCE	FREEZE	VOICE SET
1	MAIN	✓	✓
2	LAYER	✓	✓
3	LEFT	✓	✓

VOICE	EFFECT	HARMONY/ECHO
ON	ON	ON
OFF	OFF	OFF

NOTE
Normally, these should all be set to “ON.”

NOTE
Harmony/echo cannot be set for the Layer and Left parts.



These determine whether the corresponding voice-related settings (Voice selection, Effects, and Harmony/echo assignment) are automatically called up or not when you select a voice. These settings can be turned on or off independently for each part.

Setting Harmony and Echo

The explanations here apply to step #3 of the procedure on page 118.

HARMONY / ECHO				
TYPE STANDARD DUET STANDARD TRIO FULL CHORD ROCK DUET COUNTRY DUET COUNTRY TRIO BLOCK 4-WAY CLOSE1 4-WAY CLOSE2 4-WAY OPEN 1+5 OCTAVE STRUM MULTI ASSIGN ECHO TREMOLO TRILL	VOLUME 54	SPEED 8 12 32	ASSIGN AUTO MULTI MAIN LAYER	CHORD NOTE ONLY
	TOUCH LIMIT 0			

Determines the Harmony type. For details, see page 128.

Determines the level of the Harmony effect.

Determines the speed of the Echo, Tremolo, and Trill effects. This parameter is only available when Echo, Tremolo, or Trill is selected in Type above.


Determines the lowest velocity value at which the harmony note will sound. This allows you to selectively apply the harmony by your playing strength, letting you create harmony accents in the melody. The harmony effect is applied when you play the key strongly (above the set value).

When this is set to “ON,” the Harmony effect is applied only to the note that belongs to a chord played in the Auto Accompaniment area of the keyboard. This parameter is not available when Multi Assign, Echo, Tremolo, or Trill is selected in Type above.

This lets you assign the Harmony effect to various parts. For details, see page 128.

About the Harmony Types

When a normal Harmony type (“Standard Duet” through “Strum”) is selected



When “Multi Assign” is selected

Multi Assign automatically assigns notes played simultaneously on the right-hand section of the keyboard to separate parts (voices). For example, if you play two consecutive notes, the first is played by the Main voice and the second by the Layer voice.

When “Echo” is selected

An echo effect is applied to the note played on the keyboard, in time with the currently set tempo.

When “Tremolo” is selected

A tremolo effect is applied to the note played on the keyboard, in time with the currently set tempo.

When “Trill” is selected

Two notes held on the keyboard are played alternately, in time with the currently set tempo.

About the Harmony Assignments

AUTO

Harmony notes are automatically assigned the MAIN and LAYER parts.

Multi

This automatically assigns the 1st, 2nd, 3rd, and 4th added harmony notes to different parts (voices). For example, if the Main and Layer parts are turned on and the “Standard Duet” type is selected, the note you play on the keyboard will be played by the Main voice, and the added harmony note will be played by the Layer voice.

Main


Harmony is applied only to the Main part. When the Main part is turned off, Harmony is not applied.

Layer

Harmony is applied only to the Layer part. When the Layer part is turned off, Harmony is not applied.

Setting the MIDI Parameters

In this section, you can make MIDI-related settings for the instrument. These settings can be stored all together from the USER display, for future recall. For general information and details about MIDI, see “What is MIDI?” (page 139). The explanations here apply to step #3 of the procedure on page 118.



3 Call up the User display and press this button to save the newly edited MIDI settings. Up to ten setups can be saved.

2 Call up the Edit display, then select and set the desired functions/parameters. For details about each of the MIDI edit displays, see the following pages.



Press the [EXIT] button to return to the previous display.

Preset MIDI Templates (Factory Set)

All Parts	Transmit all parts including Main, Layer and Left.
Master KBD	The PSR-A1000 functions as a master keyboard for controlling external tone generators or other devices.
KBD & Style	Transmit Upper and Lower keyboard play instead of the individual parts (Main/Layer/Left).
Song	All Transmit channels are set to correspond to the Song channels 1-16. Use this to play the PSR-A1000 song data with an external tone generator, or to record your entire performance to an external sequencer.
Clock Ext.	MIDI IN terminal receives MIDI clock and PSR-A1000 synchronizes with an external MIDI device.
MIDI Accord 1	An ideal setup for controlling the keyboard voice and accompaniment style with a MIDI accordion.
MIDI Accord 2	Chord and bass buttons on a MIDI accordion control the accompaniment style, as well as play the chord and bass parts.
MIDI Pedal 1	The MIDI pedal connected to MIDI IN terminal controls the bass note of the accompaniment.
MIDI Pedal 2	The MIDI pedal connected to MIDI IN terminal plays the bass part.
MIDI OFF	MIDI signals are neither sent nor received.


NOTE

The saved settings can be named (page 38) or deleted (page 40) in the User page.

Making Overall System Settings (Local Control, Clock, etc.) — System

Call up the display as described in step 2 above.

For editing the Clock, Transmit Clock, Receive Transpose, and Start/Stop parameters.



For editing the Local Control parameters.

For editing the Message Switch parameters.

Local Control

Turns the Local Control for each part on or off. When Local Control is set to “ON,” the keyboard of the PSR-A1000 controls its own (local) internal tone generator, allowing the internal voices to be played directly from the keyboard. If you set Local to “OFF,” the keyboard and controllers are internally disconnected from the PSR-A1000’s tone generator section so that no sound is output when you play the keyboard or use the controllers. For example, this allows you to use an external MIDI sequencer to play the PSR-A1000’s internal voices, and use the PSR-A1000 keyboard to record notes to the external sequencer and/or play an external tone generator.

Clock, Transmit Clock, Receive Transpose, Start/Stop

■ Clock

Determines whether the PSR-A1000 is controlled by its own internal clock or a MIDI clock signal received from an external device. "INTERNAL" is the normal Clock setting when the PSR-A1000 is being used alone. If you are using the PSR-A1000 with an external sequencer, MIDI computer, or other MIDI device, and you want the PSR-A1000 to be synchronized to the external device, set this function to "EXTERNAL." In the latter case, the external device must be connected to the PSR-A1000 MIDI IN terminal, and must be transmitting an appropriate MIDI clock signal.

■ Transmit Clock

Turns MIDI clock transmission on or off. When this is set to "OFF," no MIDI clock or START/STOP data is transmitted.

■ Receive Transpose

When this parameter is set to "OFF," note data received by the PSR-A1000 is not transposed, and when it is set to "ON," the received note data is transposed according to the current PSR-A1000 keyboard transpose (page 125) setting.

■ Start/Stop

Determines whether incoming FA (start) and FC (stop) messages affect song or style playback.

NOTE

FA, FC

MIDI messages for starting/stopping the song or style. The "FA" message corresponds to start, and "FC" corresponds to stop.

Message Switch

SYS/EX. Tx (TRANSMIT)..... Turns MIDI transmission of MIDI system exclusive message data ON or OFF.

SYS/EX. Rx (RECEIVE) Turns MIDI reception of MIDI exclusive data generated by external equipment ON or OFF.

CHORD SYS/EX. Tx (TRANSMIT) Turns MIDI transmission of MIDI chord exclusive data (chord detect — root and type) ON or OFF.

CHORD SYS/EX. Rx (RECEIVE)..... Turns MIDI reception of MIDI chord exclusive data generated by external equipment ON or OFF.

Transmitting MIDI Data — Transmit

This determines which parts will send MIDI data and over which MIDI channel the data will be sent.

Determines the channel for changing transmit settings.

CH	PART	NOTE	CC	PC	PB
1	MATH	✓	✓	✓	✓
2	LAYER	✓	✓	✓	✓
3	LEFT	✓	✓	✓	✓
4	OFF	—	—	—	—
5	MULTI PAD 1	✓	✓	✓	✓
6	MULTI PAD 2	✓	✓	✓	✓
7	MULTI PAD 3	✓	✓	✓	✓
8	MULTI PAD 4	✓	✓	✓	✓

The dots corresponding to each channel (1-16) flash briefly whenever any data is transmitted on the channel(s).

Determines the Part for the selected channel.

Turns transmission of the specified data type on or off. See below for details on the data types.

Data Types in the MIDI TRANSMIT/RECEIVE Display

Note	Messages which are generated when the keyboard is played. Each message includes a specific note number which corresponds to the key which is pressed, plus a velocity value based on how hard the key is played.
Control Change (CC)	Control change data includes pedal and any other controller data.
Program Change (PC)	Program change data corresponds to voice or "patch" numbers.
Pitch Bend (PB)	See page 124.
After Touch (AT)*	With this function, the PSR-A1000 senses how much pressure you apply to the keys while playing, and uses that pressure to affect the sound in various ways, depending on the selected voice. This allows you to play with greater expressiveness and add effects with your playing technique.

* Available in RECEIVE display only (page 131).

Receiving MIDI Data — Receive

This determines which parts will receive MIDI data and over which MIDI channel the data will be received.

Determines the channel for changing receive settings.

The dots corresponding to each channel (1 - 32) flash briefly whenever any data is received on the channel(s).

NOTE
The MIDI IN/OUT terminals and Port A of the TO HOST terminal (Port A of the CBX driver) correspond to channels 1 - 16. Port B of the TO HOST terminal (Port B of the CBX driver) corresponds to channels 17 - 32.

Determines the Part for the selected channel. See below for details about the receive parts.

Turns reception of the specified data type on or off. See page 130 for details on the data types.

MIDI Receive Parts

OFF	No MIDI data is received.
SONG	Normally, the part receiving the MIDI data corresponds to the part/voice used in playing back the song data. Channels 1 - 16 correspond to song channels 1 - 16, respectively.
MAIN	The MAIN part is controlled by the MIDI data received on the corresponding channel.
LAYER	The LAYER part is controlled by the MIDI data received on the corresponding channel.
LEFT	The LEFT part is controlled by the MIDI data received on the corresponding channel.
KEYBOARD	MIDI note data received by the PSR-A1000 plays the corresponding notes in the same way as if they are played on the keyboard.
ACMP RHYTHM1-2	The received notes are used as the accompaniment RHYTHM 1 and RHYTHM 2.
ACMP BASS	The received notes are used as the accompaniment BASS.
ACMP CHORD1-2	The received notes are used as the accompaniment CHORD 1 and CHORD 2.
ACMP PAD	The received notes are used as the accompaniment PAD.
ACMP PHRASE1-2	The received notes are used as the accompaniment PHRASE 1 and PHRASE 2.
EXTRA PART1-5	There are five parts specially reserved for receiving and playing MIDI data. Normally, these parts are not used by the instrument itself. When these five channels are enabled, you can use the instrument as a 32-channel multi-timbral tone generator.

Setting Root Note Channels — Root

The note ON/OFF messages received at the channel(s) set to “ON” are recognized as the root notes in the accompaniment section. The root notes will be detected regardless of the accompaniment ON/OFF and split point settings.

Selects the channels in groups of eight: 1 - 8, 9 - 16, 17 - 24, and 25 - 32, respectively.

NOTE
The MIDI IN/OUT terminals and Port A of the TO HOST terminal (Port A of the CBX driver) correspond to channels 1 - 16. Port B of the TO HOST terminal (Port B of the CBX driver) corresponds to channels 17 - 32.

NOTE
When several channels are simultaneously set to “ON,” the root note is detected from merged MIDI data received over the channels.

Sets the desired channel to ON or OFF.

Sets all channels to OFF.

Setting Chord Channels — Chord Detect

The note ON/OFF messages received at the channel(s) set to “ON” are recognized as the chord notes in the accompaniment section. The chords to be detected depend on the fingering type. The root notes will be detected regardless of the accompaniment ON/OFF and split point settings. The operation procedure is basically the same as that of the ROOT display above.


Other Settings — Utility

The explanations here apply to step #3 of the procedure on page 118.

Making Settings for Fade In/Out, Metronome, Parameter Lock, and Tap — CONFIG 1

Fade In Time, Fade Out Time, Fade Out Hold Time

These determine how long it takes for the accompaniment style and song to fade in or fade out.



Determines the time it takes for the volume to fade in, or go from minimum to maximum (range of 0 - 20.0 seconds).


Determines the time the volume is held at 0 following the fade out (range of 0 - 5.0 seconds).



Determines the time it takes for the volume to fade out, or go from maximum to minimum (range of 0 - 20.0 seconds).

Metronome


These let you make settings for the metronome-related parameters.



Determines the level of the metronome sound.


Determines which sound is used for the metronome.
Bell Off Conventional metronome sound, with no bell.
Bell On Conventional metronome sound, with bell.

Determines the time signature of the metronome sound.
 When you start the song or accompaniment style, the values matching to them are automatically set.




Parameter Lock

This function is used to “lock” the specified parameters so that they can only be changed directly via the panel controls — in other words, instead of via Registration Memory, or song and sequence data.



Selects the desired parameter for locking/unlocking.




Determines whether the selected parameter is locked (checked) or unlocked (empty).

Tap Count

This lets you change settings of the tap sound, used for the Tap Start function (page 48).




Determines the particular sound used for the Tap Start function. Any drum or percussion sound in the Standard Kit (page 52) can be selected.




Determines the level of the tap sound.

Making Settings for the Display and Voice Number Indication — CONFIG 2




Determines the brightness of the backlit display.




Determines whether or not the voice bank and number are shown in the PRESET page of the VOICE display (page 51). This is useful when you want to check the proper bank select MSB/LSB values and program number to specify when selecting the voice from an external MIDI device.

Copying and Formatting Disks — Disk



- F This function copies all the data from one disk to another, letting you back up all your important data before editing. For instructions, see "Copying from Disk to Disk" below.
- G
- H This function formats a floppy disk (see below).
- I
- J



Turns the Song Auto Open function on or off. When this is set to "ON," the PSR-A1000 automatically calls up the first disk song when a disk is inserted.


NOTE

- Copying cannot be done between a 2DD disk and 2HD disk. When copying, make sure both disks are the same type.
- Depending on the amount of data contained in the original source disk, you may have to swap the two disks several times until all of the data is properly copied.
- Make sure to read the section "Using the Floppy Disk Drive (FDD) and Floppy Disks" on page 7.

Copying from Disk to Disk

As shown below, first copy the data of the original (source) disk to the PSR-A1000, then copy the data to the backup (destination) disk.

- 1** Press the [F] button. A message appears, prompting you to insert the source disk.
- 2** Insert the disk containing the original data into the drive and press "OK." A "Now copying" message appears, and the PSR-A1000 begins copying data to internal memory. To abort the operation, press "CANCEL."
- 3** At the "Please insert a destination disk and press the OK button" prompt, eject the source disk and replace it with a blank, formatted disk, then press "OK." To abort the operation, press "CANCEL."
- 4** When the operation is finished (or when prompted), eject the destination disk.




NOTE

Commercially available music data is subject to protection by copyright laws. Copying commercially available data is strictly prohibited, except for your own personal use. Some music software is purposely copy-protected and cannot be copied.

Formatting a Disk

When using an unformatted disk for the first time, make sure to properly format it on the PSR-A1000. This includes blank disks as well as disks already initialized in a different format. Formatting erases all data on the disk.



Disk Lamp
When the power is turned on, the disk lamp (at the bottom left of the drive) lights to indicate the drive can be used.

Insert the disk with shutter facing away from you and the label side up. To start the Format operation, press the [H] (DISK FORMAT) button, in the DISK page above.

NOTE

The Format operation initializes a disk with a specific file system, allowing the corresponding device (in this case, the PSR-A1000) to access it properly. Since there are several types of formats and disks available, you should know which ones to use with the PSR-A1000. 2DD disks are formatted to a capacity of 720 KB, and 2HD disks are formatted to a capacity of 1.44 MB.

CAUTION

Formatting a disk completely erases all data on the disk. Make sure that the disk you're formatting does not contain important data!

Entering Your Name and Language Preference — Owner

The screenshot shows the UTILITY menu with the following options: CONFIG, COPY, DISK, OWNER, and SYSTEM RESET. The OWNER menu is selected, showing '1 OWNER NAME: LANGUAGE: ENGLISH'. Below this, there is a 'LANGUAGE' menu with options: ENGLISH, GERMAN, and FRENCH. To the right of the screen are five function keys labeled F, G, H, I, and J. Key I is labeled 'OWNER NAME'. Below the screen are eight numbered arrow keys (1-8).

Press this button to enter an Owner name (for instructions on naming see page 42). This name is automatically shown when you turn the power on.

Determines the language used for the display messages. Once you change this setting, all messages will be shown in the selected language.

Restoring the Factory-programmed Settings of the PSR-A1000 — System Reset

This operation lets you restore the PSR-A1000 to its original factory settings. These settings include System Setup, MIDI Setup, User Effect, and Files & Folders.

Restores the System Setup parameters to the original factory settings. You can also restore only the System Setup settings by simultaneously holding down the highest key on the keyboard (C6) and turning on the power.

The screenshot shows the UTILITY menu with the following options: CONFIG, COPY, DISK, OWNER, and SYSTEM RESET. The SYSTEM RESET menu is selected, showing 'FACTORY RESET', 'SYSTEM SETUP', 'MIDI SETUP', 'USER EFFECT', and 'FILES & FOLDERS'. Below these are checkboxes for 'SYSTEM SETUP', 'MIDI SETUP', 'USER EFFECT', and 'FILES & FOLDERS'. A 'CAUTION!' warning states: 'All User files and folders are lost when this item is selected and Factory Reset is executed.' To the right of the screen are five function keys labeled F, G, H, I, and J. Key I is labeled 'SYSTEM SETUP', key H is 'MIDI SETUP', and key J is 'USER EFFECT'. Below the screen are eight numbered arrow keys (1-8).

Restores the MIDI templates to the original factory settings.

Restores the User Effects (page 116) to the original factory settings.

Deletes all files and folders stored in the User page.

Executes the Factory Reset operation for all items checkmarked above.

NOTE

The functions and settings below do not apply to the Factory Reset operation. However, you can restore these to their original settings by calling up the preset System Setup files from the PRESET page in the SYSTEM SETUP Open/Save display.


- Language
- Owner Name
- LCD Brightness

These call up the corresponding Open/Save displays. These let you store the corresponding data as files for future recall. From the PRESET page, you can also recall the respective factory settings.

Using Your PSR-A1000 with Other Devices


⚠ CAUTION

Before connecting the PSR-A1000 to other electronic components, turn off the power to all the components. Before turning the power on or off to all components, set all volume levels to minimum (0). Otherwise, electrical shock or damage to the components may occur.



1 Using the Headphones (PHONES jack).

A standard pair of stereo headphones can be plugged in here for private practice or late-night playing. The internal stereo speaker system is automatically shut off when a pair of headphones is plugged into the PHONES jack (page 133).



2 Playing the sounds of the PSR-A1000 through an external audio system, and recording the sounds to an external recorder (AUX OUT/OUTPUT jacks)


You can connect the PSR-A1000 to a wide range of audio equipment by using the AUX OUT and OUTPUT jacks. Connect as shown in the illustrations below using standard audio cables.

NOTE

Use audio cables and adaptor plugs with no resistance.

⚠ CAUTION

When the PSR-A1000 AUX OUT and OUTPUT jacks are connected to an external audio system, first turn on the power to the PSR-A1000, then to the external audio system. Reverse this order when you turn the power off.



When these are connected (with RCA pin plug; LEVEL FIXED), the sound is output to the external device at a fixed level, regardless of the [MASTER VOLUME] control setting.

When these are connected (with standard phone plugs), you can use the [MASTER VOLUME] control to adjust the volume of the sound output to the external device.

NOTE

- If you connect the PSR-A1000 to a monaural device, use only the OUTPUT L/L+R jack.

3 Using the Pedal (footswitch) or Foot Controller (FOOT PEDAL 1/2 jack)

By connecting a Foot Switch (the FC4 or FC5) to one of the FOOT PEDAL jacks, you can replicate the function of some panel buttons, doing things like starting and stopping accompaniment.

By connecting an optional Foot Controller (such as the FC7) to the FOOT PEDAL 2 jack, you can control any one of a variety of important functions with your foot — such as dynamically adjusting the volume as you play (page 123).

NOTE

The polarity of the foot switch (normal or reverse) can also be changed (page 123).



CAUTION

Make sure to connect or disconnect the pedal only when the power is turned off.

4 Connecting external MIDI devices (MIDI terminals)

Using a standard MIDI cable, connect the external MIDI device to the MIDI terminal(s) of the PSR-A1000. Make sure to set the HOST SELECT switch (page 18) to MIDI when you use these connectors. For more information about connections, see “What You Can Do With MIDI” on page 142.

MIDI IN Receives MIDI messages from an external MIDI device

MIDI OUT Sends out MIDI messages generated by the PSR-A1000

For a general overview of MIDI and how you can effectively use it, refer to the following sections:

- What’s MIDI? (page 139)
- What You Can Do With MIDI (page 142)
- MIDI functions (page 129)

NOTE

- Never use MIDI cables longer than 15 meters.

5 Connecting to a Computer (MIDI terminals/TO HOST terminal)

Connect your PSR-A1000 to computer and take advantage of the wide range of powerful and versatile software for creating and editing music. The PSR-A1000 can be connected in three ways.

- Using the TO HOST terminal
- Using the MIDI terminals
- Connecting to a USB terminal by using an optional USB interface (UX series)

NOTE

- You'll need an appropriate music/MIDI software program (such as a sequencer), compatible with your computer platform.
- When connecting the PSR-A1000 to a personal computer, first turn off the power to both the PSR-A1000 and the computer before connecting any cables and setting the HOST SELECT switch. After making the proper connections and settings, turn on the power of the computer first, then that of the PSR-A1000.
- If you do not use the TO HOST terminal of the PSR-A1000, make sure you disconnect the cable from the terminal. If the cable is left connected, the PSR-A1000 may not function properly.
- When the HOST SELECT switch is set to "PC-1," "PC-2," or "Mac," you can use the TO HOST terminal, but the MIDI connectors are disabled since no data transfer occurs via the MIDI connectors. On the other hand, when the HOST SELECT switch is set to "MIDI," you can use the MIDI connectors, but not the TO HOST terminal since no data is transferred via the TO HOST terminal.

Note for Windows users (regarding MIDI driver)

To transfer data via the computer's serial port and the PSR-A1000's TO HOST terminal, you need to install a specified MIDI driver (Yamaha CBX driver for Windows). The Floppy Disk that came with your PSR-A1000 contains the compressed driver file "mididrv.zip." After extracting the file, execute the installation by double-clicking on the "Setup.exe" file in the "MidiDrv" folder and follow the on-screen directions. In addition, you can download this driver from the XG Library on the Yamaha Web site: <http://www.yamaha-xg.com>

Using the TO HOST terminal


Connect the serial port of the personal computer (RS-232C terminal or RS-422 terminal) to the TO HOST terminal of the PSR-A1000. For the connection cable, use the appropriate cable below (sold separately) that matches the personal computer type.

NOTE

If your system does not work properly with the connections and settings listed above, your software may require different settings. Check your software operation manual and set the HOST SELECT switch to the proper data transfer rate. (Data transfer rate of "PC-1" is 31,250 bps.)

■ IBM-PC/AT (Windows)


Connect the RS-232C terminal on the computer to the TO HOST terminal on the PSR-A1000 using a serial cable (D-SUB 9P → MINI DIN 8P cross cable). Set the PSR-A1000 HOST SELECT switch to the "PC-2." (Data transfer rate is 38,400 bps.)



■ Macintosh

Connect RS-422 terminal (modem or printer) on the computer to the TO HOST terminal on the PSR-A1000 using a serial cable (system peripheral cable, 8 bit). Set the PSR-A1000 HOST SELECT switch to the "MAC" (Data transfer rate is 31,250 bps).


Set the MIDI interface clock in the sequencer you are using to 1 MHz. For details, refer to the owner's manual for the particular software you are using.




Using the MIDI terminals

When using a MIDI interface device installed in the personal computer, connect the MIDI terminals of the personal computer and the PSR-A1000 with standard MIDI cables.

- When the computer has a MIDI interface installed, connect the MIDI OUT terminal of the personal computer to the MIDI IN terminal. Set the HOST SELECT switch to "MIDI."




- When using a MIDI interface with a Macintosh series computer, connect the RS-422 terminal of the computer (modem or printer terminal) to the MIDI interface, then connect the MIDI OUT terminal on the MIDI interface to the MIDI IN terminal of the PSR-A1000, as shown in the diagram below. Set the HOST SELECT switch to "MIDI."



- When the HOST SELECT switch is set to "MIDI," the TO HOST terminal is disabled.
- When using a Macintosh series computer, set the MIDI interface clock setting in the application software to match the setting of the MIDI interface you are using. For details, refer to the owner's manual for the particular software you are using.

Using the USB terminal on your computer with a USB/MIDI interface (UX256/UX96, etc.)

Connect the UX256/UX96 and the computer with a USB cable. Install the included UX256/UX96 driver to the computer, and connect the UX256/UX96 to the PSR-A1000 with a MIDI cable. Set the HOST SELECT switch on the PSR-A1000 to "MIDI." For details, refer to the owner's manual of the UX256/UX96.



For details about the necessary MIDI settings for computer and sequence software you are using, refer to the relevant owner's manuals.

What's MIDI?

Let's consider an acoustic piano and a classical guitar as representative acoustic instruments. With the piano, you strike a key, and a hammer inside hits some strings and plays a note. With the guitar, you directly pluck a string and the note sounds.


But how does a digital instrument go about playing a note?

Acoustic guitar note production



Pluck a string and the body resonates the sound.

Digital instrument note production




Based on playing information from the keyboard, a sampled note stored in the tone generator is played through the speakers.

As shown in the illustration above, in an electronic instrument, the sampled note (previously recorded note) stored in the **tone generator section** (electronic circuit) is played based on information received from the keyboard, and output through the speakers.


Now let's examine what happens when we play back a recording. When you playback a music CD (for example, a solo piano recording), you're hearing the actual sound (vibrations in air) of the acoustic instrument. This is called audio data, to distinguish it from MIDI data.

Recording and playing back the performance of an acoustic instrument (audio data)



In the above example, the actual acoustic sounds of the pianist's performance are captured in the recording as audio data, and this is recorded to CD. When you play back that CD on your audio system, you can hear the actual piano performance. The piano itself is not necessary, since the recording contains the actual sounds of the piano, and your speakers reproduce them.


Recording and playing back the performance of a digital instrument (MIDI data)



NOTE

In the case of digital instruments, the audio signals are sent through output jacks (such as AUX OUT) on the instrument.

The "controller" and "tone generator" in the illustration above are equivalent to the piano in our acoustic example. Here, the player's performance on the keyboard is captured as MIDI song data (see illustration below). In order to record the audio performance on an acoustic piano, special recording equipment is needed. However, since the PSR-A1000 features a built-in **sequencer** that lets you record performance data, this recording equipment is unnecessary. Instead, your digital instrument — the PSR-A1000 — allows you to both record and play back the data.



However, we also need a sound source to produce the audio, which eventually comes from your speakers. The **tone generator** of the PSR-A1000 fills this function. The recorded performance is reproduced by the sequencer, playing back the song data, using a tone generator capable of accurately producing various instrument sounds — including that of a piano. Looked at in another way, the relation of the sequencer and the tone generator is similar to that of the pianist and the piano — one plays the other. Since digital instruments handle playback data and the actual sounds independently, we can hear our piano performance played by another instrument, such as guitar or violin.

NOTE

Even though it is a single musical instrument, the PSR-A1000 can be thought of as containing several electronic components: a controller, a tone generator, and a sequencer.

Finally, we'll take a look at the actual data that gets recorded and that serves as the basis for playing the sounds. For example, let's say you play a "C" quarter note using the grand piano sound on the PSR-A1000 keyboard. Unlike an acoustic instrument that puts out a resonated note, the electronic instrument puts out information from the keyboard such as "with what voice," "with which key," "about how strong," "when was it pressed" and "when was it released." Then each piece of information is changed into a number value and sent to the tone generator. Using these numbers as a basis, the tone generator plays the stored sampled note.

■ Example Keyboard Data

Voice number (with what voice)	01 (grand piano)
Note number (with which key)	60 (C3)
Note on (when was it pressed) and note off (when was it released)	Timing expressed numerically (quarter note)
Velocity (about how strong)	120 (strong)

Panel operations on the PSR-A1000, such as playing the keyboard and selecting voices, are processed and stored as MIDI data. The auto accompaniment styles and songs also consist of MIDI data.

MIDI is an acronym that stands for Musical Instrument Digital Interface, which allows electronic musical instruments to communicate with each other, by sending and receiving compatible Note, Control Change, Program Change and various other types of MIDI data, or messages.

The PSR-A1000 can control a MIDI device by transmitting note related data and various types of controller data. The PSR-A1000 can be controlled by incoming MIDI messages which automatically determine the tone generator mode, select MIDI channels, voices and effects, change parameter values and of course play the voices specified for the various parts.

NOTE

- MIDI data has the following advantages over audio data:
- The amount of data is much less, letting you easily store MIDI songs to floppy disk.
 - The data can be effectively and easily edited, even to the point of changing voices and transforming the data.

MIDI messages can be divided into two groups: Channel messages and System messages.

■ Channel Messages

The PSR-A1000 is an electronic instrument that can handle 16 channels (or 32 channels, when using the TO HOST terminal). This is usually expressed as "it can play 16 instruments at the same time." Channel messages transmit information such as Note ON/OFF, Program Change, for each of the 16 channels.

Message Name	PSR-A1000 Operation/Panel Setting
Note ON/OFF	Messages which are generated when the keyboard is played. Each message includes a specific note number which corresponds to the key which is pressed, plus a velocity value based on how hard the key is played.
Program Change	Voice selecting (control change bank select MSB/LSB setting)
Control Change	Volume, panpot (Mixing Console), etc.


NOTE

The performance data of all songs and styles is handled as MIDI data.


MIDI channels

MIDI performance data is assigned to one of sixteen MIDI channels. Using these channels, 1 - 16, the performance data for sixteen different instrument parts can be simultaneously sent over one MIDI cable.

Think of the MIDI channels as TV channels. Each TV station transmits its broadcasts over a specific channel. Your home TV set receives many different programs simultaneously from several TV stations and you select the appropriate channel to watch the desired program.



MIDI operates on the same basic principle. The transmitting instrument sends MIDI data on a specific MIDI channel (MIDI Transmit Channel) via a single MIDI cable to the receiving instrument. If the receiving instrument's MIDI channel (MIDI Receive Channel) matches the Transmit Channel, the receiving instrument will sound according to the data sent by the transmitting instrument.




NOTE

The PSR-A1000's keyboard and internal tone generator are also connected by MIDI (page 129).

For example, several tracks (channels) can be transmitted simultaneously, including the style data (as shown below).

Example: Recording the auto accompaniment of the PSR-A1000 to an external sequencer



As you can see, it is essential to determine which data is to be sent over which MIDI channel when transmitting MIDI data (page 130). The PSR-A1000 also allows you to determine how the received data is played back. (page 131).

System Messages

This is data that is used in common by the entire MIDI system. System messages include messages like Exclusive Messages that transmit data unique to each instrument manufacturer and Realtime Messages that control the MIDI device.


Message Name	PSR-A1000 Operation/Panel Setting
System Exclusive Message	Effect type settings (Mixing Console), etc.
Realtime Messages	Clock setting, Start/stop operation

The messages transmitted/received by the PSR-A1000 are shown in the MIDI Data Format and MIDI Implementation Chart in the separate Data List.

What You Can Do With MIDI


The following MIDI settings can be made on the PSR-A1000:

- MIDI templates (preset MIDI setups for various applications) (page 129)
 - Transmit (page 130)
 - Receive (page 131)
 - Local Control (page 129)
 - Clock (page 130)
- Record performance data (1-16 channels) using the PSR-A1000 Auto Accompaniment features on a external sequencer (such as a personal computer). After recording, edit the data with the sequencer, then play it again on the PSR-A1000 (playback).



When you want to use the PSR-A1000 as an XG-compatible multi-timbral tone generator, set the receive part for MIDI channels 1 to 16 to "SONG" in MIDI Receive (page 131).

- Play and control the PSR-A1000 from a separate keyboard



Data Compatibility

This section covers basic information on data compatibility: whether or not other MIDI devices can playback the data recorded by PSR-A1000, and whether or not the PSR-A1000 can playback commercially available song data or song data created for other instruments or on a computer. Depending on the MIDI device or data characteristics, you may be able to play back the data without any problem, or you may have to perform some special operations before the data can be played back. If you run into problems playing back data, please refer to the information below.

Disk format

Floppy disks are the main storage medium for data used with various devices, including computers. Different devices have different systems of storing data, therefore it is necessary to first configure the floppy disk to the system of the device being used. This operation is called "formatting."

- There are two types of floppy disks: MF2DD (double sided, double density) and MF2HD (double sided, high density), and each type has different formatting systems.
- PSR-A1000 can record and playback with both types of floppy disks.
- When formatted by the PSR-A1000, a 2DD disk stores up to 720 KB (kilobytes) and a 2HD disk stores up to 1.44 MB (megabytes). (The figures "720 KB" and "1.44MB" indicate the data memory capacity. They are also used to indicate the format type of disk.)
- Playback is only possible when the MIDI device to be used is compatible with the format of the disk.

Sequence Format

The system which records song data is called “sequence format.”

Playback is only possible when the sequence format of the disk matches that of the MIDI device. The PSR-A1000 is compatible with the following formats.

■ SMF (Standard MIDI File)

This is the most common sequence format. Standard MIDI Files are generally available as one of two types: Format 0 or Format 1. Many MIDI devices are compatible with Format 0, and most commercially available software is recorded as Format 0.

- The PSR-A1000 is compatible with both Format 0 and Format 1.
- Song data recorded on the PSR-A1000 is automatically recorded as SMF Format 0.
- Song data loaded to the PSR-A1000 is automatically saved as SMF Format 0 regardless of the original format.

■ ESEQ

This sequence format is compatible with many of Yamaha’s MIDI devices, including the PSR-A1000 series instruments. This is a common format used with various Yamaha software.

■ XF

The Yamaha XF format enhances the SMF (Standard MIDI File) format with greater functionality and open-ended expandability for the future.

- The PSR-A1000 is capable of displaying lyrics when an XF file containing lyric data is played.

■ Style File

The Style File Format – SFF – is Yamaha’s original style file format which uses a unique conversion system to provide high-quality automatic accompaniment based on a wide range of chord types.

Voice Allocation Format

With MIDI, voices are assigned to specific numbers, called “program numbers.” The numbering standard (order of voice allocation) is referred to as the “voice allocation format.”

Voices may not play back as expected unless the voice allocation format of the song data matches that of the compatible MIDI device used for playback.

The PSR-A1000 is compatible with the following formats.

NOTE

Even if the devices and data used satisfy all the conditions above, the data may still not be completely compatible, depending on the specifications of the devices and particular data recording methods.

■ GM System Level 1

This is one of the most common voice allocation formats.

- Many MIDI devices are compatible with GM System Level 1, as is most commercially available software.

■ XG

XG is a major enhancement of the GM System Level 1 format, and was developed by Yamaha specifically to provide more voices and variations, as well as greater expressive control over voices and effects, and to ensure compatibility of data well into the future.

- Song data recorded on the PSR-A1000 using voices in the [XG] category is XG-compatible.

■ DOC

This voice allocation format is compatible with many of Yamaha’s MIDI devices, including the PSR series instruments. This is also a common format used with various Yamaha software.

Troubleshooting

Problem	Possible Cause and Solution
<ul style="list-style-type: none"> The PSR-A1000 does not turn on; there is no power. 	Make sure that the PSR-A1000 has been plugged in properly (page 16).
<ul style="list-style-type: none"> A click or pop is heard when the power is turned on or off. 	This is normal when electrical current is applied to the instrument.
<ul style="list-style-type: none"> Noise is heard from the PSR-A1000's speakers. 	Using a mobile phone in close proximity to the PSR-A1000 may produce interference. To prevent this, turn off the mobile phone, or use it further away from the PSR-A1000.
<ul style="list-style-type: none"> The display is too bright or too dark to read. 	The brightness of the display may be affected by the surrounding temperature; try adjusting the contrast (page 17).
<ul style="list-style-type: none"> The keyboard volume is low compared to that of the Auto Accompaniment or song playback. 	The overall keyboard volume or the independent volume level of the keyboard part may be set too low. Raise the MAIN/LAYER/LEFT volume voices or lower the STYLE/SONG volume in the BALANCE display (page 58).
<ul style="list-style-type: none"> The volume of the Auto Accompaniment or song playback is low compared to that of the keyboard. 	The volume level of one or more accompaniment parts or song channels is set too low. Raise the part or channel level(s) in the appropriate MIXER display (page 113).
<ul style="list-style-type: none"> The overall volume is low, or no sound is heard. 	<ul style="list-style-type: none"> The Master Volume is set too low; set it to an appropriate level with the [MASTER VOLUME] dial. The volume of the individual parts may be set too low. Raise the volume of MAIN, LAYER, LEFT, STYLE, and SONG in the BALANCE display (page 58). Make sure the desired channel is set to ON (page 58, 69). Headphones are connected, disabling the speaker output. Unplug the headphones. Make sure the Local Control function is set to ON (page 129).
<ul style="list-style-type: none"> Not all simultaneously-played notes sound. 	You may be exceeding the maximum polyphony of the PSR-A1000. When this happens, the earliest played notes will stop sounding, letting the latest played notes sound. See page 146 for information on the maximum polyphony.
<ul style="list-style-type: none"> Accompaniment style or Song playback does not start. 	<ul style="list-style-type: none"> MIDI Clock may be set to "EXTERNAL." Make sure this is set to "INTERNAL" (page 130). Make sure to press the appropriate [START/STOP] button. To play an accompaniment style, press the STYLE [START/STOP] button (page 58); to playback a song, press the SONG [START/STOP] button (page 67). "New Song" (a blank song) has been selected. Make sure to select an appropriate song in the SONG display (page 67). The song has been stopped at the end of the song data. Return to the beginning of the song by pressing the [TOP] button (page 69).
<ul style="list-style-type: none"> The Multi Pads do not play back, even when one of the MULTI PAD buttons is pressed. 	MIDI Clock may be set to "EXTERNAL." Make sure this is set to "INTERNAL" (page 130).
<ul style="list-style-type: none"> Only the rhythm channel plays. 	Make sure the Auto Accompaniment function is turned on; press the [ACMP] button.
<ul style="list-style-type: none"> The accompaniment style does not start, even when Synchro Start is in standby condition and a key is pressed. 	You may be trying to start accompaniment by playing a key in the right hand range of the keyboard. Make sure to play a key in the left-hand (accompaniment) range of the keyboard.
<ul style="list-style-type: none"> The desired chord is not recognized or output by the auto accompaniment. 	<ul style="list-style-type: none"> You may not be playing the correct keys to indicate the chord. Refer to "Chord Types Recognized in the Fingered Mode" (page 60). You may be playing the keys according to a different fingering mode, and not the one currently selected. Check the accompaniment mode, and play the keys according to the selected mode (page 59).
<ul style="list-style-type: none"> An unexpected result or malfunction occurred during an operation. 	If, during execution of an operation, you simultaneously press three or more buttons that are unrelated to the operation or normal procedure, unexpected or unusual results may occur.
<ul style="list-style-type: none"> Auto accompaniment chords are recognized regardless of the split point or where chords are played on the keyboard. 	This is normal if the fingering mode is set to "Full Keyboard" or "All Full Keyboard." If either of these is selected, chords are recognized over the entire range of the keyboard, irrespective of the split point setting. If desired, select a different fingering mode (page 59).

Problem	Possible Cause and Solution
<ul style="list-style-type: none"> Certain notes sound at the wrong pitch. 	<p>The Scale parameter has probably been set to something other than “Equal,” changing the tuning system of the keyboard. Make sure “Equal” is selected as the Scale in the Scale Tune page (page 72).</p>
<ul style="list-style-type: none"> Some channels do not properly play back when playing back song data. 	<p>Make sure that playback of the relevant channel(s) is turned on (page 69).</p>
<ul style="list-style-type: none"> The Harmony function does not operate. 	<p>Harmony cannot be used with the Full Keyboard or AI Full Keyboard fingering modes. Select an appropriate fingering mode (page 59).</p>
<ul style="list-style-type: none"> MIDI data is not transmitted or received via the MIDI terminals, even when MIDI cables are connected properly. 	<p>Make sure the HOST SELECT switch is set to “MIDI” (page 139). The MIDI terminals cannot be used for the other switch settings.</p>
<ul style="list-style-type: none"> When a voice is changed, the previously selected effect is changed. 	<p>Each voice has its own suitable preset values which are automatically recalled when the corresponding Voice Set parameters are turned on (page 127).</p>
<ul style="list-style-type: none"> There is a slight difference in sound quality between notes played on the keyboard. Some voices have a looping sound. Some noise or vibrato is noticeable at higher pitches, depending upon the voice. 	<p>This is normal and is a result of the PSR-A1000’s sampling system.</p>
<ul style="list-style-type: none"> Some voices will jump an octave in pitch when played in the upper or lower registers. 	<p>This is normal. Some voices have a pitch limit which, when reached, causes this type of pitch shift.</p>
<ul style="list-style-type: none"> Disk save operations take a long time. 	<p>This is normal. Keep in mind that it takes approximately 1 minute to save 1 megabyte of data to a floppy disk.</p>
<ul style="list-style-type: none"> The voice produces excessive noise. 	<p>Certain voices may produce noise, depending on the Harmonic Content and/or Brightness settings in the FILTER page of the Mixing Console display (page 114).</p>
<ul style="list-style-type: none"> The sound is distorted or noisy. 	<ul style="list-style-type: none"> The volume may be turned up too high. Make sure all relevant volume settings are appropriate. This may be caused by the effects. Try canceling all unnecessary effects, especially distortion-type effects (page 115). Some filter resonance settings in the Custom Voice Creator display (page 81) can result in distorted sound. Adjust these settings if necessary.
<ul style="list-style-type: none"> A strange “flanging” or “doubling” sound occurs. Also, the sound is slightly different each time the keys are played. 	<p>Both the Main and Layer parts are set to “ON,” and both parts are set to play the same voice. Set the Layer part to “OFF” (page 53) or change the voice for each part (page 51).</p>

Specifications

○: available

Model Name		PSR-A1000	
Sound Source		AWM Dynamic Stereo Sampling	
Display		320 × 240 dots backlit graphic LCD	
Keyboard		61 keys (C1 - C6 with Initial Touch)	
Voice	Polyphony (max)		32
	Number of Voices		276 regular voices + 480 XG voices + 20 Drum Kits
	Number of Oriental Voices		43
	Number of Oriental Drum Kits		6
	Number of Sweet Voices		3
	Number of Cool Voices		1
	Sound creator		○
Effects	Effect Blocks	Reverb	1
		Chorus	1
		DSP	1
	Effect Types	REVERB	23 Preset+3 User
		CHORUS	15 Preset+3 User
		DSP	93 Preset+3 User
Accompaniment Style	Number of Accompaniment Styles		190
	Number of Oriental Styles		123
	Number of Session Styles		4
	Fingering		Single Finger, Fingered, Fingered On Bass, Multi Finger, AI Fingered, Full Keyboard, AI Full Keyboard
	Style Creator		○
Song	Format		SMF (Format 0,1), ESEQ
	Preset Songs		○
	Lyrics		○
	Recording		Quick Recording, Multi Recording, Step Recording, Song Editing
		Record Channels	16
Multi Pad	Preset		4 Pads × 80 Banks
Memory Device	Floppy Disk (2HD,2DD)		○
	Flash Memory (internal)		260KB
	Flash Availability		Song (SMF), Style (SFF), Registration, Voice, etc.
Tempo	Tempo Range		5 - 500
	Tap Tempo		○
	Metronome		○
		Sound	Bell on/off

Model Name		PSR-A1000
Scale	Scale Tuning	○
	Scale Memory buttons	6
	Scale Template	Equal Temperament, Bayat, Rast, Pure Major, Pure Minor, Pythagorean, Mean-Tone, Werckmeister, Kirnberger
Registration Memory	Buttons	8
	Regist Sequence	○
	Freeze	○
Others	Demo	Function, Voice, Style
	Language	3 languages (English, German, French)
	Help	○
	Direct Access	○
	Master Volume	○
	Fade In/Out	○
	Transpose	Keyboard/Song/Master
	Tuning	○
Touch Response	5 level	
Jacks/Connectors	DC IN, PHONES, MIDI (OUT, IN), TO HOST, HOST SELECT SW, FOOT PEDAL1 (SWITCH), FOOT PEDAL2, AUX OUT (LEVEL FIXED) (L/R), OUTPUT (L/L+R)	
Pedal Functions	VOLUME, SUSTAIN, SOSTENUTO, SOFT, GLIDE, PORTAMENTO, PITCHBEND, MODULATION, DSP VARIATION, SONG START/STOP, STYLE START/STOP, etc.	
Amplifiers/ Speakers	Amplifiers	12 W × 2
	Speakers	(12 cm + 5 cm) × 2
Power Consumption	31 W	
Power supply	Yamaha AC adaptor PA-300 (included) *May not be included in your area. Please check with your Yamaha dealer.	
Dimensions [W × D × H] (without Music Stand)	973 × 399 × 161 mm [38-5/16" × 15-11/16" × 6-5/16"]	
Weight	10.0 Kg (22 lbs., 1 oz)	
Optional accessories	Headphones	HPE-150
	Foot Switch	FC4 / FC5
	Foot Controller	FC7
	Keyboard Stand	L-6, L-7

* Specifications and descriptions in this owner's manual are for information purposes only. Yamaha Corp. reserves the right to change or modify products or specifications at any time without prior notice. Since specifications, equipment or options may not be the same in every locale, please check with your Yamaha dealer.

Thanks

YAMAHA Corporation wishes to express our thanks to:

Mr. Mohammed Saleh (Lebanon)

Mr. Sairos Isa (Bahrain)

Mr. Wadea Al Kandari (Kuwait)

Mr. Fawaz Al Kandari (Kuwait)

Mr. Arash Adelpour (Iran)

Mr. Dimitris Vassiliou (Greece)

Mr. Ahmet Can Basar (Turkey)

Mr. Mehmet Dogdu (Turkey)

for composing Styles/Demos and their cooperation.

Index

Numerics

- 1 - 16 87, 96
- [1▲▼] - [8▲▼] buttons 19, 35–42

A

- A (ACMP) 122
- [A] - [J] buttons 19, 37
- Accent Type 105
- Accessories 6
- Accompaniment style parts 85
- [ACMP] button 18, 57
- ACMP TOUCH 122
- Adjust the Volume Balance and Changing Voices 112
- Adjusting the display contrast 17
- Adjusting the Effects 115
- Adjusting the Scale Tuning — Scale Tuning 72
- Adjusting the Tempo 47
- Adjusting the Volume Balance 58
- Adjusting the Volume Balance / Muting Specific Channels... 69
- Adjusting values 43
- AI 59
- AI FINGERED 59
- AI FULL KEYBOARD 59
- A+L (ACMP + LEFT) 122
- Applying Voice Effects 54
- Arranging the Style Pattern 61
- Assembling an Accompaniment Style 103
- ASSIGN (HARMONY) 82
- ATTACK (Regular Voice) 81
- AUTO 20
- AUTO CH SET 121
- [AUTO FILL IN] button 18, 63
- Auto Revoice 113
- AUX OUT (LEVEL FIXED) [L] [R] jacks 19, 136

B

- [BACK] button 19, 37, 43
- BALANCE 58
- [BALANCE] button 19, 58
- Bar Clear 106
- Bar Copy 106
- base note 72
- Basic Operations — Organizing Your Data 35
- Bass 85
- Bayat 73
- Beat Converter 104
- Boost/Cut 105
- [BREAK] button 18, 61
- BRIGHTNESS 81

C

- Cent 72
- Change the Rhythmic Feel 104
- Changing Pitch-related Settings 114
- Changing the Automatically Selected Voice Settings 127
- Changing the Icon 43
- Changing the Tone of the Voice 114
- Changing the Touch Sensitivity and Transpose 125
- Channel 58, 69, 93, 106, 121
- Channel Messages 141
- Channel Muting 58

- CHANNEL ON/OFF 58, 69
- [CHANNEL ON / OFF] button 19, 58, 69
- Channel Transpose 95
- CHD 97
- Chord 85
- Chord Detect 131
- Chord Events 97
- Chord Fingering 59, 123
- CHORD NOTE ONLY (HARMONY) 82
- Chord Tutor 123
- Chord Types Recognized in the Fingered Mode 60
- Chorus 117
- CHORUS DEPTH (Sound Creator) 82
- Clock 130
- COMMON 80
- COMPARE 79
- Compatible Song Types 66
- CONFIG 1 132
- CONFIG 2 133
- Connecting external MIDI devices 137
- Connecting to a Computer 138
- Controller 123
- Cool! 52
- COPY 40
- Copying and Formatting Disks 134
- Copying Files/Folders 40
- Copying from Disk to Disk 134
- Creating Accompaniment Styles 99
- Current Memory 36
- Customizing the Event List — Filter 98
- CUT 39

D

- Data Compatibility 142
- [DATA ENTRY] dial 19, 43
- Data Types in the MIDI TRANSMIT/RECEIVE Display 130
- DC IN terminal 19, 136
- DECAY 81
- DELETE (Basic Operations) 40
- Delete (Song Creator) 94
- Deleting Files/Folders 40
- [DEMO] button 14, 18, 49
- DEPTH 82
- DESTINATION 94
- [DIGITAL RECORDING] button 14, 18, 83, 99
- [DIRECT ACCESS] button 19, 44
- Direct Access Chart 45
- Disk 134
- Disk format 142
- Disk Orchestra Collection 17
- DISPLAY VOICE NUMBER 133
- Displaying the Lyrics 71
- Displaying Upper Level pages 41
- DOC 143
- Drum 52
- [DSP] button 19, 54, 117
- DSP DEPTH (Sound Creator) 82
- Dynamics 105

E

- ECHO 55, 127
- Edit 102

- Edit the Created Accompaniment Style 104
- Editing a Recorded Song 93
- Editing Channel-related Parameters 93
- Editing Chord Events 97
- Editing Note Events 96
- Editing System Events 97
- Editing the Channel Data 106
- Editing Voices 79
- EFFECT 82
- Effect Block 116
- Effect Connections 117
- Effect Structure 117
- Effects 115
- EG 81
- EG ATTACK (Sound Creator) 81
- EG DECAY (Sound Creator) 81
- EG RELES. (Sound Creator) 81
- Embellish and enhance your melodies
— with the automatic Harmony and Echo effects 29
- END Mark 91
- ENDING 63
- [ENDING / rit.] button 18, 30, 62
- [ENTER] button 19, 43
- Entering Characters 42
- Entering Chords and Sections (Chord Step) 90
- Entering miscellaneous characters (marks) 42
- Entering numbers 42
- Entering special character marks (umlaut, accent) 42
- Entering Your Name and Language Preference 135
- Equal Temperament 73
- ESEQ 143
- Example Keyboard Data 141
- [EXIT] button 19, 37
- exit from small pop-up windows 37
- Expand/Compress 105
- [EXTRA TRACKS (STYLE)] button 18, 70
- F**
-
- Fade In Time, Fade Out Time, Fade Out Hold Time 132
- [FADE IN / OUT] button 18, 62
- [FF] button 18, 69
- File 36
- File/Folder-related Operations 38
- Files/folders in a floppy disk 39
- Fill 63
- Filter 81, 98, 114
- FILTER BRIGHT (Sound Creator) 81
- FILTER HARMO. (Sound Creator) 81
- Fine 104
- FINGERED 59
- FINGERED ON BASS 59
- First Key On 92
- FLOPPY DISK drive 36
- FLOPPY DISK SONG AUTO OPEN 134
- Floppy disk drive 19, 7
- FOOT PEDAL 1/2 jack 137
- [FOOT PEDAL 1 (SWITCH)] jack 19, 137
- [FOOT PEDAL 2] jack 19, 137
- Formatting a Disk 134
- [FREEZE] button 19, 78
- Freeze 78, 126
- FULL KEYBOARD 59
- [FUNCTION] button 18, 118
- G**
-
- Gate Time 88
- GM System Level 1 17, 143
- Groove 104
- Groove parameters 104
- GROUP SELECT 76
- H**
-
- Handling the Floppy Disk Drive (FDD) and Floppy Disk 7
- Harmonic Content 81
- HARMONY 55, 82, 127
- Harmony Assignments 128
- Harmony Types 128
- [HARMONY / ECHO] button 19, 55
- Headphones 136
- Help messages can be displayed in any one
of the following languages 46
- [HELP] button 18, 46
- High Key 108
- [HOST SELECT] switch 19, 137
- Hz 120
- I**
-
- ICON 43
- ICON SELECT 43
- Inputting and Editing Lyrics 98
- Instant Selection of Displays 44
- INTRO 63
- [INTRO] button 18, 31, 61
- K**
-
- Kbd.Vel 88
- Keyboard Percussion 52
- Keyboard Touch 125
- Keyboard/Panel 125
- Kirnberger 73
- L**
-
- L (LEFT) 122
- Layer 53
- Layering Two Different Voices 53
- LCD 15
- [LCD CONTRAST] knob 19, 17
- Left 54
- [LEFT HOLD] button 19, 55
- Local Control 129
- Loop recording 99
- Lyrics 71, 98
- M**
-
- MAIN A/B/C/D 61
- MAIN [A] button 18, 61
- MAIN [B] button 18, 61
- MAIN [C] button 18, 61
- MAIN [D] button 18, 61
- Maintaining Panel Settings 126
- Making Global and Other Important Settings 118
- Making Overall System Settings (Local Control, Clock, etc.) 129
- Making Settings for Fade In/Out, Metronome,
Parameter Lock, and Tap 132
- Making Settings for the Display and Voice Number
Indication 133
- Making Settings for the Pedals and Keyboard 123
- Making Style File Format Settings 107
- Master Tune 120
- [MASTER VOLUME] dial 18, 17
- Mean-Tone 73

- Measure/Beat/Clock 88
- Memorizing the Scale Setting – Scale Memory 74
- [MEMORY] button (REGISTRATION MEMORY) 19, 76
- [MEMORY] button (SCALE MEMORY) 18, 74
- Message Switch 130
- Messages 8
- Metronome 132
- [METRONOME] button 18
- MIDI 129
- MIDI [OUT] [IN] terminals 19, 137
- MIDI channels 141
- MIDI IN 137
- MIDI OUT 137
- MIDI Receive Parts 131
- MIDI SET UP 135
- MIDI terminals 137, 138
- Mix 94
- [MIXING CONSOLE] button 18, 112
- [MONO] button 19, 55
- MONO POLY (Sound Creator) 80
- Moving Files/Folders 39
- MULTI FINGER 59
- MULTI PAD [1] - [4] buttons 19, 64
- Multi Pads 15
- Multi Recording 85
- Music Stand 17
- Muting Specific Parts 70
- N**
- NAME 38, 41
- Naming Files and Folders 38
- NEW (Folder) 41
- [NEXT] button 19, 37, 43
- Normal 92
- Note Events 96
- Note for Windows users (regarding MIDI driver) 138
- Note Limit 108
- Nrm 88
- NTR (Note Transposition Rule) 107
- NTT (Note Transposition Table) 108
- O**
- OCTAVE 114
- OCTAVE LEFT (Sound Creator) 80
- OCTAVE M/LYR (Sound Creator) 80
- Open/Save displays 35
- Organizing Files by Creating a New Folder 41
- Oriental Scales 72
- Original Beat 104
- Other Parameters in the Basic Display 102
- Other Playback-related Operations 69
- Other Settings 132
- OUTPUT [L / L+R] [R] jacks 19, 136
- Overdub recording 99
- Owner 135
- P**
- Pad 85
- PANEL SUSTAIN (Sound Creator) 82
- Parameter 107
- Parameter Lock 133
- PASTE 39, 40
- Pedal 123
- PEDAL 1/2 POLARITY 123
- PEDAL PUNCH IN/OUT 92
- Pedal-controllable Functions 124
- [PHONES] jack 18, 136
- Phrase 85
- Phrase Mark 69, 121
- PHRASE MARK REPEAT 121
- PITCH BEND 18, 55
- PITCH BEND RANGE 114
- Pitch settings for each scale 73
- Playback of Songs 21
- Playing a style 28, 56
- Playing a Style's Rhythm Channels only 58
- Playing Along with the PSR-A1000 32
- Playing Back Songs on Disk 69
- Playing Different Voices with the Left and Right Hands 27
- Playing Fill-in patterns automatically when changing
accompaniment sections 63
- Playing Several Sounds Simultaneously 53
- Playing Styles 28
- Playing the Demos 20, 49
- Playing the Internal Songs 67
- Playing the sounds of the PSR-A1000 through
an external audio system, and recording the sounds to
an external recorder 136
- Playing Two Voices Simultaneously 26
- Playing Voices 25
- Playing with the Songs 32
- PORTAMENT TIME (Sound Creator) 80
- PORTAMENTO TIME (Mixing Console) 114
- Power Supply 16
- Powering Up 17
- Power-on Procedure 16
- PRESET drive 36
- Preset MIDI Templates 129
- Punch In/Out 92
- Pure Major 73
- Pure Minor 73
- Pythagorean 73
- Q**
- Quantize 93, 106
- Quantize Size 93
- Quick Recording 84
- QUICK START 121
- Quick Start 121
- R**
- Rast 73
- Realtime Recording 101
- Realtime Recording Characteristics 99
- [REC] button 18, 83
- REC END 92
- Rec Mode 92
- REC START 92
- Recalling a Registration Memory Setup 78
- Recalling the Registered Settings 78
- Recalling the Scale Setting 75
- Receive 131
- Receive Transpose 130
- Receiving MIDI Data 131
- Recording 33
- Recording Chord Changes for the Auto Accompaniment 90
- Recording Individual Notes 87
- Recording Melodies 89
- Recording Your Performances and Creating Songs 83
- Registering Panel Setups 76
- REGISTRATION EDIT display 77
- Registration Memory 76

- REGISTRATION MEMORY [1] – [8] buttons 19, 76
 REGISTRATION MEMORY CONTENTS 76
 Registration Sequence 126
 RELEASE 81
 Remove Event 106
 Repeat Playback of a Specific Range 70
 [REPEAT] button 18, 70
 Resonance 81
 Restoring the Factory-programmed Settings
 of the PSR-A1000 135
 Reverb 117
 REVERB DEPTH (Sound Creator) 82
 [REW] button 18, 69
 Rhythm 85
 Root 131
 RTR (Retrigger Rule) 108
- S**
- S.STOP WINDOW 122
 SAVE 41
 Save 35, 41
 Saving Files 41
 Saving Your Registration Memory Setups 77
 Saving Your Scale Settings 74
 Scale 73
 Scale Memory 74
 [SCALE MEMORY] button 75
 SCALE MEMORY button 74
 Scale Setting 72
 [SCALE SETTING] buttons 72
 SCALE TUNE BANK display 75
 SCALE TUNE display 72
 SCALE TUNE EDIT display 75
 Scale Tuning 72
 [SCALE TUNING] button 72
 Section button indications
 — [BREAK], [INTRO], [MAIN], [ENDING] buttons 61
 SECTION SET 122
 sections 30
 Select the Recording Options: Starting, Stopping,
 Punching In/Out 92
 Selecting a Voice 51
 Selecting Files and Folders 37
 Selecting Intro and Ending Types 63
 Selecting items 43
 Selecting the Freeze Settings 78
 SEQUENCE END 126
 Sequence Format 143
 sequencer 140
 Set Up 95
 Setting an Oriental Scale 34
 Setting an Oriental Scale — Scale Setting 72
 Setting Auto Accompaniment-related Parameters 122
 Setting Chord Channels 131
 Setting Harmony and Echo 127
 Setting Root Note Channels 131
 Setting Separate Voices for the Left and Right Sections
 of the Keyboard 54
 Setting Song-related Parameters 121
 Setting the Fingering Method 123
 Setting the Level Balance and Voice 113
 Setting the MIDI Parameters 129
 Setting the Registration Sequence, Freeze, and Voice Set ... 126
 Setting the volume 17
 SFX 52
 Simultaneously Playing a Song and an Accompaniment Style ..
- SINGLE FINGER 59
 SMF (Standard MIDI File) 143
 Song 14, 66
 SONG [START / STOP] button 18, 67
 SONG AUTO REVOICE 113
 SONG CHAIN PLAY 121
 Song Creator 83
 Song Playback 21, 66, 67
 Song Recording 83
 Song Settings 121
 SOUND (SOUND CREATOR) 81
 Sound Creator Parameters 80
 [SOUND CREATOR] button 18, 79
 Source Root/Chord 107
 SOURCE1 94
 SOURCE2 94
 Specifying the Order for Calling Up Registration Memory
 Presets 126
 SPEED 82
 SPEED (HARMONY) 82
 Split Point 122
 [STANDBY/ON] switch 14, 18, 17
 Step Record 87
 Step Record (Chord) 90
 Step Record (Note) 89
 Step Recording 102
 STOP ACMP 122
 [STOP] button (MULTI PAD) 19, 64
 Stopping the Style Playback While Releasing Keys 62
 Strength 105
 Style 14, 56
 STYLE [START / STOP] button 18, 57
 STYLE buttons 18, 56
 Style Creator 99
 Style File 17, 143
 Style File Format 100
 Style Sections 30
 Style Setting 122
 sustain 81, 82
 [SUSUTAIN] button 19, 54
 Sweet! 52
 Swing 104
 [SYNC.START] button 18, 57
 [SYNC.STOP] button 18, 62
 SYS/EX. (System Exclusive) 97
 System 129
 System and Insertion 117
 System Events 97
 System Messages 142
 System Reset 135
 SYSTEM SET UP 135
- T**
- Tap Count 133
 [TAP TEMPO] button 19, 48
 TEMPO [◀] [▶] buttons 19, 47
 Tempo Indications — MAIN Display 48
 [TO HOST] terminal 15, 19, 138
 TO HOST terminal 138
 [TOP] button 18, 69
 TOUCH LIMIT (HARMONY) 82
 TOUCH SENSE (Sound Creator) 80
 [TOUCH] button 19, 54
 [TRACK 1 (R)] button 18, 70
 [TRACK 2 (L)] button 18, 70
 Transmit 130
 Transmit Clock 130

Transmitting MIDI Data	130
TRANPOSE [◀] [▶] buttons.....	19, 125
Transpose Assign	125
Tune.....	114
TUNING	114
Tuning the Overall Pitch	120
TYPE (HARMONY).....	82

U

[UPPER OCTAVE] button	19, 55
USER drive	36
USER EFFECT (Function).....	135
User Effect (Mixing Console)	116
Using Oriental Scales – Scale Setting/Scale Tuning/ Scale Memory	72
Using the USB terminal on your computer with a USB/MIDI interface (UX256, etc.).....	139
Using Your PSR-A1000 with Other Devices	136
Utility	132

V

[VARIATION] button	19, 55
Velocity.....	88, 105
Velocity Change.....	106
VIBRATO	82
VIBRATO DELAY (Sound Creator)	81
VIBRATO DEPTH (Sound Creator).....	81
VIBRATO SPEED (Sound Creator).....	81
Voice Allocation Format.....	143
VOICE buttons	15, 19, 51
Voice Characteristics.....	52
Voice Effects.....	54
VOICE PART ON / OFF [LAYER] button	19, 53
VOICE PART ON / OFF [LEFT] button	19, 53
VOICE PART ON / OFF [MAIN] button	19, 53
Voice Set	127
VOLUME (HARMONY).....	82
VOLUME (Sound Creator)	80
Volume/Voice	113

W

Werckmeister	73
What You Can Do With MIDI	142
What's MIDI?	139

X

XF	17, 143
XG	17, 143

MEMO

OBSERVERA!

Apparaten kopplas inte ur växelströmskällan (nätet) så länge som den är ansluten till vägguttaget, även om själva apparaten har stängts av.

ADVARSSEL: Netspændingen til dette apparat er IKKE afbrudt, så længe netledningen sidder i en stikkontakt, som er tændt — også selvom der er slukket på apparatets afbryder.

VAROITUS: Laitteen toisiopiiriin kytketty käyttökytkin ei irroita koko laitetta verkosta.

(standby)

For details of products, please contact your nearest Yamaha or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

CENTRAL & SOUTH AMERICA

MEXICO

Yamaha de Mexico S.A. De C.V.
Departamento de ventas
Javier Rojo Gomez No.1149, Col. Gpe Del Moral, Deleg. Iztapalapa, 09300 Mexico, D.F.
Tel: 686-00-33

BRAZIL

Yamaha Musical do Brasil LTDA.
Av. Rebouças 2636, São Paulo, Brasil
Tel: 011-853-1377

ARGENTINA

Yamaha de Panamá S.A. Sucursal de Argentina
Viamonte 1145 Piso2-B 1053,
Buenos Aires, Argentina
Tel: 1-4371-7021

PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES

Yamaha de Panamá S.A.
Torre Banco General, Piso 7, Urbanización Marbella,
Calle 47 y Aquilino de la Guardia,
Ciudad de Panamá, Panamá
Tel: 507-269-5311

EUROPE

THE UNITED KINGDOM

Yamaha-Kemble Music (U.K.) Ltd.
Sherbourne Drive, Tilbrook, Milton Keynes,
MK7 8BL, England
Tel: 01908-366700

IRELAND

Danfay Ltd.
61D, Sallynoggin Road, Dun Laoghaire, Co. Dublin
Tel: 01-2859177

GERMANY/SWITZERLAND

Yamaha Europa GmbH.
Siemensstraße 22-34, 25462 Rellingen,
F.R. of Germany
Tel: 04101-3030

AUSTRIA

Yamaha Music Austria
Schleiergasse 20, A-1100 Wien Austria
Tel: 01-60203900

THE NETHERLANDS

Yamaha Music Nederland
Kanaalweg 18G, 3526KL, Utrecht, The Netherlands
Tel: 030-2828411

BELGIUM

Yamaha Music Belgium
Keiberg Imperiastraat 8, 1930 Zaventem, Belgium
Tel: 02-7258220

FRANCE

Yamaha Musique France,
Division Claviers
BP 70-77312 Marne-la-Vallée Cedex 2, France
Tel: 01-64-61-4000

ITALY

Yamaha Musica Italia S.P.A.
Viale Italia 88, 20020 Lainate (Milano), Italy
Tel: 02-935-771

SPAIN/PORTUGAL

Yamaha-Hazen Electronica Musical, S.A.
Ctra. de la Coruna km. 17, 200, 28230
Las Rozas (Madrid) Spain
Tel: 91-201-0700

GREECE

Philippe Nakas S.A.
Navarinou Street 13, P.Code 10680, Athens, Greece
Tel: 01-364-7111

SWEDEN

Yamaha Scandinavia AB
J. A. Wettergrens Gata 1
Box 30053
S-400 43 Göteborg, Sweden
Tel: 031 89 34 00

DENMARK

YS Copenhagen Liaison Office
Generatorvej 8B
DK-2730 Herlev, Denmark
Tel: 44 92 49 00

FINLAND

F-Musiikki Oy
Kluuvikatu 6, P.O. Box 260,
SF-00101 Helsinki, Finland
Tel: 09 618511

NORWAY

Norsk filial av Yamaha Scandinavia AB
Grini Næringspark 1
N-1345 Østerås, Norway
Tel: 67 16 77 70

ICELAND

Skifan HF
Skeifan 17 P.O. Box 8120
IS-128 Reykjavik, Iceland
Tel: 525 5000

OTHER EUROPEAN COUNTRIES

Yamaha Europa GmbH.
Siemensstraße 22-34, 25462 Rellingen,
F.R. of Germany
Tel: 04101-3030

AFRICA

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: 053-460-2312

MIDDLE EAST

TURKEY/CYPRUS

Yamaha Europa GmbH.
Siemensstraße 22-34, 25462 Rellingen,
F.R. of Germany
Tel: 04101-3030

OTHER COUNTRIES

Yamaha Music Gulf FZE
LB21-128 Jebel Ali Freezone
P.O.Box 17328, Dubai, U.A.E.
Tel: 971-4-881-5868

ASIA

HONG KONG

Tom Lee Music Co., Ltd.
11/F., Silvercord Tower 1, 30 Canton Road,
Tsimshatsui, Kowloon, Hong Kong
Tel: 2737-7688

INDONESIA

PT. Yamaha Music Indonesia (Distributor)
PT. Nusantik
Gedung Yamaha Music Center, Jalan Jend. Gatot
Subroto Kav. 4, Jakarta 12930, Indonesia
Tel: 21-520-2577

KOREA

Yamaha Music Korea Ltd.
Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong,
Yongdungpo-ku, Seoul, Korea
Tel: 02-3770-0661

MALAYSIA

Yamaha Music Malaysia, Sdn., Bhd.
Lot 8, Jalan Perbandaran, 47301 Kelana Jaya,
Petaling Jaya, Selangor, Malaysia
Tel: 3-703-0900

PHILIPPINES

Yupangco Music Corporation
339 Gil J. Puyat Avenue, P.O. Box 885 MCPO,
Makati, Metro Manila, Philippines
Tel: 819-7551

SINGAPORE

Yamaha Music Asia Pte., Ltd.
11 Ubi Road #06-00, Meiban Industrial Building,
Singapore
Tel: 65-747-4374

TAIWAN

Yamaha KHS Music Co., Ltd.
10F, 150, Tun-Hwa Northroad,
Taipei, Taiwan, R.O.C.
Tel: 02-2713-8999

THAILAND

Siam Music Yamaha Co., Ltd.
121/60-61 RS Tower 17th Floor,
Ratchadaphisek RD., Dindaeng,
Bangkok 10320, Thailand
Tel: 02-641-2951

THE PEOPLE'S REPUBLIC OF CHINA AND OTHER ASIAN COUNTRIES

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: 053-460-2317

OCEANIA

AUSTRALIA

Yamaha Music Australia Pty. Ltd.
Level 1, 99 Queensbridge Street, Southbank, Victoria
3006, Australia
Tel: 3-9693-5111

NEW ZEALAND

Music Houses of N.Z. Ltd.
146/148 Captain Springs Road, Te Papapa,
Auckland, New Zealand
Tel: 9-634-0099

COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: 053-460-2312

HEAD OFFICE Yamaha Corporation, Pro Audio & Digital Musical Instrument Division
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: 053-460-3273



Yamaha PK CLUB (Portable Keyboard Home Page, English only)
<http://www.yamahaPKclub.com/>

Yamaha Manual Library
<http://www2.yamaha.co.jp/manual/english/>