YAMAHA

NATURAL SOUND SPEAKER SYSTEM

NS-1000 NS-1000 MONITOR OWNER'S MANUAL



We wish to thank you for your purchase of the Yamaha NS-1000/NS-1000M speaker.

With this latest addition to the Natural Sound series, Yamaha has created the finest bookshelf-type speaker system available today, and has made a major contribution to the act of music reconduction.

Before attempting to operate the NS-1000/NS-1000M, please read this owner's manual carefully, to avoid any errors which could result in irreparable damage. If the NS-1000/NS-1000M speaker is used with an amplifier whose power capacity is greater than that of the appakar's (max. input: 100W, Continuous: 50W), be careful not to exceed the speaker's capacity. When the amplifier volume is set at the middle position, the output will register 70% of the maximum input. After long periods of use at continuous input, the attenuous knob may become warmer. This will in no way affect reasker performance.

The "NORMAL" position of the attenuator level has been chosen as the result of various factors, including tests in anechoic chambers, power-handling characteristics and hearing tests in listening rooms. However, you may adjust the position according to your own preferences and to the particular acoustic conditions of your room.

Do not touch the beryllium diaphragms on the midrange or tweeter, nor cause them to be affected by any sharp movement.

IMPORTANT!

your unit in the space below Model Name

Serial No.

The serial number is located on the

rear of the cabinet.

Retain this Owner's Manual in a safe place for future reference.

Connecting the Amplifier

terminal (refer to the diagram).

Connect the input terminal on the rear of the speaker to the output terminal on the amplifier with the speaker cord which is included. Make sure the amplifier is turned off.

Connection
The input terminal on the speaker is a push-type

The red terminal is plus, the black terminal is minus. The lever below each terminal should be pushed, the proper cord inserted, and the lever released. This will look the open in place.



Connect the left speaker to the left (L.) ampliffer terminal, and the right speaker to the right R) Returned The connector cords must be connected the same way for both left and right speakers. One side of the speak cord is silven-colored. Use this side as the plus and the silven-colored. Use this side as the plus and the things of the side of side si

Impedance

The impedance of the NS-1000/NS-1000M is 80. If a transistor amplifier is used, the speakers can be connected without giving any consideration to impedance. If a tube-type amplifier is used, however, the speakers should be connected only to 80 curtust terminals.

Speaker Placement

If the speakers are placed directly on a carpet or rug, there is a danger of distortion of the bass tones. Place them on a solid base or shelf, or on the floor with blocks

them on a solid base or shelf, or on the floor with blocks under them.

The best location is one in which the speakers are placed with their backs against a hard wall. If the facing wall is hard, or has laree windows, a better effect will be ob-

tained by covering it with a curtain.

The speakers can be placed upright or lying down. The center of the speaker should be level with your ears

when in the listening position.

Be careful not to place the speakers too close to, facing, or on the same shelf with your turntable; this can cause hum.

Avoid locations exposed to direct sunlight, heat, dust or expessive dampness.

Grille Assembly (NS-1000)

The grille is packed in the bottom of the speaker carton for shipment.

To install the grille, first press one side against the front baffle as shown in the illustration, then press the other side into place.

Note: Be careful not to press too hard when installing the grille; excessive force can bend the grille frame.

Grille Removal (NS-1000)


The protect against vibrations of the grille frame when the speakers are used, the grille frame fits quite tightly into its groove on the speaker front baffle.


To remove the grille, hook your fingers into the protruding part of the frame, then pull down and out at the same time to loosen the top edge.

Be careful not to tear or stretch the grille cloth when removing the grille.














Specifications

Type
Impedance
Fundamental Resonance Frequency
Frequency Response
Standard Input
Maximum Input Capacity
Efficiency

Crossover Frequency Speaker Complement Woofer Squawker

Tweeter
Dimensions (H x W x D)

Weight

Infinite baffle, 3-way system 8 Ω 40 Hz 40 – 20,000 Hz

50W 100W 90dB (1 m 1 Watt Input) 500 Hz, 6,000 Hz

NS-1000: 39 kg (85.8 lbs.) NS-1000M: 31 kg (68.2 lbs.)

30 cm cone type (JA-3058I/NS-1000M: (JA-3058A) 8.8 cm dome type (JA-0801)

0.0 m dome type (JA-0801) 3cm dome type (JA-0801) NS-1000: 710 x 395 x 369 mm (28 x 15-1/2 x 14-1/2") NS-1000M: 675 x 375 x 326 mm (26-1/2 x 14-3/4 x 12-3/4")

