

# Dante Accelerator Driver V2.5.2 for Mac Release Notes

## Important Notice

- You need to update the Dante Accelerator Firmware to V2.6.0.

## V2.5.1 to V2.5.2

### Specification Changes

- Now supports macOS 10.12.
- Changed the system requirements to the following.  
OS X 10.9.5, OS X 10.10.5, OS X 10.11.x, macOS 10.12.x

### Known Issue

- Dante Accelerator Driver may not work if the Thunderbolt Expansion Box is connected to a Mac computer after starting the Mac. Make sure to connect the Thunderbolt Expansion Box to the computer before starting it.

## Update History

### V2.5.0 to V2.5.1

#### Specification Changes

- Now supports Nuendo 6.5.

#### Known Issue

- Dante Accelerator Driver may not work if the Thunderbolt Expansion Box is connected to a Mac computer after starting the Mac. Make sure to connect the Thunderbolt Expansion Box to the computer before starting it.

### V2.0.0 to V2.5.0

#### Specification Changes

- Now supports Mac Pro (Late 2013). You will need the Thunderbolt Expansion Box to connect Dante Accelerator to the Thunderbolt port of a Mac computer. Following models to be verified for use with Dante Accelerator.
  - Magma ExpressBox 1T/3T (non-Thunderbolt 2 compliant box)

- Sonnet Echo Express Pro/Echo Express

For the latest information on compatible devices, check the Yamaha Professional Audio website.

[http://www.yamahaproaudio.com/global/en/products/daw\\_systems/nuage/](http://www.yamahaproaudio.com/global/en/products/daw_systems/nuage/)

## **V1.0.1 to V2.0.0**

### **Specification Changes**

- Now supports Dante Redundancy. (The secondary port became available.)
- Changed the system requirements to the following.  
OS X 10.7.5 or 10.8.x

### **Fixed Bug**

- Solved the problem in which the Dante Accelerator for which Pull up/Pull down is set to enable does not work properly in OS X 10.8.

### **Known Issue**

- None.

## **V1.0.0 to V1.0.1**

### **Specification Changes**

- Disabled the Pull up/Pull down settings in OS X 10.8 which do not support Pull up/Pull down.

### **Fixed Bug**

- Solved the problem in which the audio sound would not play back properly when two audio applications were simultaneously using Dante Accelerator.

### **Known Issue**

- If the buffer size is set to 2048 when the audio buses in the VST Connections of Nuendo are set to less than 32 channels in OS X 10.6.8, continual noise may occur. Set the value to something other than 2048.

---

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2013-2016 Yamaha Corporation.

## Dante Accelerator Driver V2.5.2 for Mac リリースノート

### 重要なお知らせ

- ・ Dante Accelerator Firmware を V2.6.0 にアップデートしてお使いください。

### V2.5.1 → V2.5.2

#### 仕様変更

- macOS 10.12 に対応しました。
- 動作環境を変更しました。以下の環境が必要です。  
OS X 10.9.5, OS X 10.10.5, OS X 10.11.x, macOS 10.12.x

#### 既知の不具合

- Mac を起動してから、Thunderbolt 拡張 Box を Mac へ接続すると、Dante Accelerator Driver が動作しない場合があります。Mac を起動する前に接続してください。

### 過去のアップデート内容

#### V2.5.0 → V2.5.1

#### 仕様変更

- Nuendo 6.5 に対応しました。

#### 既知の不具合

- Mac を起動してから、Thunderbolt 拡張 Box を Mac へ接続すると、Dante Accelerator Driver が動作しない場合があります。Mac を起動する前に接続してください。

#### V2.0.0 → V2.5.0

#### 仕様変更

- Mac Pro (Late 2013)に対応しました。Mac 本体の Thunderbolt ポートへ接続するには Thunderbolt 拡張 Box が必要です。動作確認済みの Thunderbolt 拡張 Box は下記のとおりです。
  - Magma ExpressBox 1T/3T (Thunderbolt 2 非対応機種)
  - Sonnet Echo Express Pro/Echo Express最新の情報は、ヤマハプロオーディオのウェブサイトをご参照ください。

[http://www.yamahaproaudio.com/japan/ja/products/daw\\_systems/nuage/](http://www.yamahaproaudio.com/japan/ja/products/daw_systems/nuage/)

#### V1.0.1 → V2.0.0

#### 仕様変更

- Dante リダンダンシーに対応しました。(セカンダリーポートが使用可能になりました。)
- 動作環境を変更しました。以下の環境が必要です。  
OS X 10.7.5 または 10.8.x

#### **修正した不具合**

- Pull up/Pull down 設定された Dante Accelerator を、OS X 10.8 にインストールすると正常に動作しない問題を修正しました。

#### **既知の不具合**

- なし

#### **V1.0.0 → V1.0.1**

#### **仕様変更**

- OS X 10.8 では Pull up/Pull down をサポートしていないため設定を無効にしました。

#### **修正した不具合**

- Dante Accelerator を 2 つのオーディオアプリケーションで同時に使用したときに、音が正常に再生されない問題を修正しました。

#### **既知の不具合**

- OS X 10.6.8 で、Nuendo の VST コネクションのオーディオバスを 32 チャンネル以下に設定した状態でバッファサイズを 2048 にすると、継続的にノイズが出力されることがあります。2048 以外の値を設定してください。

---

本文に掲載されている会社名および商品名等は、各社の登録商標または商標です。

(C) 2013-2016 Yamaha Corporation.